

El Tunnel Manager Reference Manual

2026 May 07
Revision: 2.4.0.17




Table of Contents

Table of Contents	2
Legal Notices	4
Getting Started	5
About this Release	6
Release History	6
Tunnel Manager 2.3.1	6
Tunnel Manager 2.3	6
Tunnel Manager 2.2.1	7
Tunnel Manager 2.2	7
Logging In	8
EI Tunnel Manager Login Page	8
Default User Credentials	9
Discovering Devices on the Network	9
EI Tunnel Manager User Interface	11
About Pop-Up	11
Tunnel Analytics	12
Performance Dashboard	12
Live Dashboard	15
Result Browser	16
Events	33
Configuration Change History	33
Provisioning	36
DataMan	36
Remote Subnets	38
Device Management	39
DataMan	39
Other Devices	49
Feature Keys	52
Hybrid Switches	54
Tunnel Setup	59
Trigger Alignment	59
Dynamic Test	62
3D Field Calibration	74
Archiver	79
Download Center	79
Settings	83
Edge Intelligence	83
DataMan WebHMI	87
Firmware Upgrade	88
HTTPS	89
User Management	90
Users	90
Roles	92
Single Sign-On	93

Identity Provider Configuration	93
Role Mapping	94
Data Transfer	96
Data Forwarding	96
Notification Center	120
Notification Center Features	121
Notification Levels	124
Licensing	124
Update	124
Stitcher Settings	125
Troubleshooting	128
Remote Connection Troubleshooting	128
Enable Remote Access for Cognex Technical Support	129
Open Source Licenses	132

Legal Notices

The software described in this documentation is provided "as is" and "as available," without warranty of any kind, express or implied, including but not limited to the warranties of merchantability, fitness for a particular purpose, and non-infringement. In no event shall Cognex Corporation and its global affiliates (collectively, "Cognex") be liable for any claims, damages, or other liability arising from, out of, or in connection with the software or your use of the software.

Your use of this software is governed by the full terms and conditions of the Cognex Software License Agreement. For complete licensing details and legal terms, please visit <https://www.cognex.com/terms-and-conditions>.

The information in this document is subject to change without notice and should not be construed as a commitment by Cognex. Cognex is not responsible for any errors that may be present in either this document or the associated software.

Companies, names, and data used in examples herein are fictitious unless otherwise noted. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, nor transferred to any other media or language without the written permission of Cognex Corporation.

Portions of the hardware and software provided by Cognex may be covered by one or more U.S. and foreign patents, as well as pending U.S. and foreign patents listed on the Cognex web site at: [cognex.com/patents](https://www.cognex.com/patents).

In the event of any inconsistency between the English language version of this documentation and any other language version, the English language version shall take precedence.

Copyright © 2026. Cognex Corporation. All Rights Reserved.

The following are registered U.S. trademarks of Cognex Corporation:

2DMAX, 3D LIGHTBURST TECHNOLOGY, ADVANTAGE, ALIGNPLUS, ASSEMBLYPLUS, COGNEX, COGNEX VISION FOR INDUSTRY, CVL, DATAMAN, DVT, EASYBUILDER, EDGE INTELLIGENCE, HOTBARS, IDMAX, IN-SIGHT, LIGHTBURST, MX, OMNIVIEW, PATFIND, PATFLEX, PATINSPECT, PATMAX, PATMAX REDLINE, PATQUICK, POWERGRID, QUICKSORT, ULTRALIGHT, VISION SOLUTIONS, VISIONPRO, VISIONVIEW

The following are trademarks of the Cognex Corporation:

1DMAX, 3D SYMBOLIC LIGHT, 3D-LOCATE, 3DMAX, ONEVISION, PINPOINT, RANGEMAX, SLX, VIDI, OCRMAX, INSPECTEDGE, VISION SOLUTIONS

Portions copyright © Microsoft Corporation. All rights reserved.

Portions copyright © MadCap Software, Inc. All rights reserved.

Other product and company trademarks identified herein are the trademarks of their respective owners.


Getting Started

Tunnel Manager is a software that runs inside of an Industrial PC that manages the following processes between a Modular Vision Tunnel (MVT) and Cognex devices, for example, DataMan readers:

- Communication
- Data forwarding
- Image collection
- Device management
- Device setup

Tunnel Manager provides services through a simple web-based user interface, such as the following:

- Tunnel Analytics
- Data Analytics
- Performance Analytics
- Commissioning applications



The EI Tunnel Manager is a web-based software that allows you to manage your tunnel assets with some key features as below:

Main Features	Key elements
Device Management	Large storage for multi-day images and results
	Network Address Translation (NAT)
	Time Synchronization
Compatibility with DataMan Readers	Configurations, firmware, feature keys
	Multi-Reader Sync group setup
	DataMan WebHMI to configure readers

Main Features	Key elements
Flexible and scalable solution: Integration with Industrial Analytics	Reader results and metadata
	Built-in MQTT protocol
	Turnkey data connectivity to cloud-based systems (AWS, Azure)
Powerful Performance Monitoring tools	Real time performance with live dashboard
	Browse tunnel trigger results and images
	Device configuration changes

About this Release

Tunnel Manager 2.4 includes the following enhancements and changes:

- Removed case sensitivity when the file name is checked in the license update file.
- Fixed the handling of hybrid switch firmware updates so the firmware update finishes consistently and successfully.
- Bugfixes and stability improvements.

Release History

This section describes the changes in previous versions of Tunnel Manager.

Tunnel Manager 2.3.1

This version added the following fixes:

- Corrected the way error values were computed in 3D Field Calibration for cropped sensors. This prevented automatically loading the calibration results to devices, which required manual intervention from a skilled user.
- Fixed an issue where upgrading to Tunnel Manager 2.3 added multiple instances of the Performance Viewer app with **Unhealthy** status.
- Fixed an issue where the padding parameter was missing from the Stitcher tool.

Tunnel Manager 2.3

This version added the following new feature:

- No-read feedback results are now available on Tunnel Manager devices. This feature provides the following functions:
 - The Result Browser page highlights images with barcodes that were not successfully decoded.
 - The page provides detailed information about each no-read, including the reason for the failure.
 - The page also offers new customization options to add, remove, or rearrange elements on the page.

This version added the following enhancements and changes:

- Connections on the Other Devices page now automatically close after 30 minutes to improve security. When upgrading to this version, existing connections in the Other Devices page are closed.
- You can now snooze notifications in the Notification Center for ten minutes at a time. This feature is helpful during system commissioning.

- Tunnel Manager now supports more Modular Vision Tunnel variants for 3D-calibrated features, including Barcode Assignment and Image Stitching. Additional licenses are required. Image Stitching is only available on select hardware.

Tunnel Manager 2.2.1

This version added the following new features and enhancements:

- Added a new Hybrid Switches page for managing hybrid switches.
- The Data Forwarding page now supports Azure Storage Blob and REST connections.

Tunnel Manager 2.2

This version added the following new features:

- Support for the new EI-A3-TUNMGR- and EI-A9-TUNMGR-series devices.
- Image stitching across devices to allow single-image per side output on premium systems (add-on license).
- Pass-through access to web HMI's, including:
 - DataMan readers
 - 3D-A1000 dimensioning units
 - Mettler-Toledo TLD-950 dimensioning units
 - Remote Desktop

This version added the following enhancements and changes:

- Added the following additional protocols supported by Data Forwarding:
 - Amazon S3
 - Amazon SNS
 - Azure IoT Hub
 - FTP
 - MQTT
 - SFTP
- Added a photoeye testing step to the Dynamic Test Tunnel Setup app.
- You can now switch between a light mode theme and dark mode theme.
- General fixes and enhancements to the workflow of Tunnel Setup and commissioning apps.

Logging In

To access the EI Tunnel Manager web interface, simply log in using your credentials or single sign-on (SSO). If this is your first time logging in, use the default credentials. Once logged in, you can modify your settings and explore the apps available to you.

EI Tunnel Manager Login Page

1

2

3

4

Number	Element
1	Sign in using your credentials or SSO. Note: The Sign in with SSO button only appears in the login page if SSO is configured for the EI Tunnel Manager unit. For more information, see Single Sign-On on page 93.
2	Scan the QR code to register your EI Tunnel Manager unit on the cognex.com/mycognex website.

3	The information button opens the About Pop-Up on page 11 window that provides the following options and information: • Information about the EI Tunnel Manager unit, such as serial numbers, software version, and license expiration date. • The documentation link opens the reference manual stored on the device. • The System Diagnostics Data section allows you to collect, download, and delete device logs that you can send to Cognex support engineers for troubleshooting support. • The Network Interfaces section lists the available and connected network ports with their configurations. • The Components section lists the different features that run on the device.
4	The paint bucket icon allows you to change the website color theme.

Default User Credentials

The following users credentials are available by default:

User	Password	Default Permissions
admin	BnthWWSD	Has access to all apps and features. Admin users can modify the default user profiles, enable access permissions for the other user roles, or create new profiles.
engineer	TaRDpKVx	Has access to all apps and features.
operator	SxtXGmxs	User with read-only rights. The operator does not have access to the Device Management app and the Settings.

Note: Change the default credentials to avoid security risks. For more information, see [User Management on page 90](#).

Discovering Devices on the Network

The default IP address for the Ethernet 2 port of Cognex product name uppercase is 192.168.1.100. The Cognex product name uppercase device discovers every reader automatically if the Cognex product name uppercase is connected to the corresponding network.

The readers found on the network appear on the [DataMan on page 39](#) page of the Device Management app.

COGNEX E3 Tunnel Manager																																																																																																																																																																																																																											
License Expires: Nov 20, 2025, 1:00:00 AM																																																																																																																																																																																																																											
admin																																																																																																																																																																																																																											
Home • Device Management • DataMan																																																																																																																																																																																																																											
ADD SELECTED TO GROUP UPLOADED CONFIGURATION UPLOADED FIRMWARE DOWNLOAD AS CSV DISCOVER DEVICES																																																																																																																																																																																																																											
Standalone Devices <table> <thead> <tr> <th>☐</th> <th>Actions</th> <th>Password Protected</th> <th>Primary</th> <th>Name</th> <th>Type</th> <th>MAC Address</th> <th>Firmware Version</th> <th>Address Type</th> <th>IP Address</th> </tr> </thead> <tbody> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.1</td><td>192.168.1.1</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.2</td><td>192.168.1.2</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.3</td><td>192.168.1.3</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.4</td><td>192.168.1.4</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.5</td><td>192.168.1.5</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.6</td><td>192.168.1.6</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.7</td><td>192.168.1.7</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.8</td><td>192.168.1.8</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.9</td><td>192.168.1.9</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.10</td><td>192.168.1.10</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.11</td><td>192.168.1.11</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.12</td><td>192.168.1.12</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.13</td><td>192.168.1.13</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.14</td><td>192.168.1.14</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.15</td><td>192.168.1.15</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.16</td><td>192.168.1.16</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.17</td><td>192.168.1.17</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.18</td><td>192.168.1.18</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.19</td><td>192.168.1.19</td></tr> <tr><td>☐</td><td>    </td><td></td><td></td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXX</td><td>XXXXXXXXXXXX</td><td>XXXXXXXXXXXXXXXXXXXXXXXXXXXX</td><td>192.168.1.20</td><td>192.168.1.20</td></tr> </tbody> </table>										☐	Actions	Password Protected	Primary	Name	Type	MAC Address	Firmware Version	Address Type	IP Address	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.1	192.168.1.1	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.2	192.168.1.2	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.3	192.168.1.3	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.4	192.168.1.4	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.5	192.168.1.5	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.6	192.168.1.6	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.7	192.168.1.7	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.8	192.168.1.8	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.9	192.168.1.9	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.10	192.168.1.10	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.11	192.168.1.11	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.12	192.168.1.12	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.13	192.168.1.13	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.14	192.168.1.14	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.15	192.168.1.15	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.16	192.168.1.16	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.17	192.168.1.17	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.18	192.168.1.18	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.19	192.168.1.19	☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.20	192.168.1.20
☐	Actions	Password Protected	Primary	Name	Type	MAC Address	Firmware Version	Address Type	IP Address																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.1	192.168.1.1																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.2	192.168.1.2																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.3	192.168.1.3																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.4	192.168.1.4																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.5	192.168.1.5																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.6	192.168.1.6																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.7	192.168.1.7																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.8	192.168.1.8																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.9	192.168.1.9																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.10	192.168.1.10																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.11	192.168.1.11																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.12	192.168.1.12																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.13	192.168.1.13																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.14	192.168.1.14																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.15	192.168.1.15																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.16	192.168.1.16																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.17	192.168.1.17																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.18	192.168.1.18																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.19	192.168.1.19																																																																																																																																																																																																																		
☐	    			XXXXXXXXXXXX	XXXXXXXXXX	XXXXXXXXXXXX	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	192.168.1.20	192.168.1.20																																																																																																																																																																																																																		

Note: The readers that are not on the same 192.168.1.x local subnet have the Misconfigured state.

Cognex recommends that all readers be on the same network as Cognex product name uppercase device. Either change the IP address of every reader on the network to be on the same network as 192.168.1.x, or change the IP address of the Ethernet port of the Cognex product name uppercase device to match those of the readers.

To change the network settings of your Cognex product name uppercase device, go to the [Edge Intelligence on page 83](#) page.


EI Tunnel Manager User Interface



Number	Element	Description
1	App menu	Click the Menu icon in the upper left corner to open the navigation pane.
2	Navigation pane	Use the navigation pane to open a page under an app.
3	App window	Use the app window to access the functions of the open page.
4	Ribbon elements	• The ribbon displays the user that is signed in. • Click the Theme icon to switch between dark and light themes. • Click the Bell icon to view the notifications. Click on a notification to open it in the Notification Center on page 120. • Click the Info icon to open the About Pop-Up on page 11 • Click the Logout icon to log out.

About Pop-Up

The **About** pop-up window allows you to access documentation, collect diagnostics for troubleshooting support, and view network and component information for your EI Tunnel Manager unit.




Number	Description
1	Information about the EI Tunnel Manager unit, such as serial numbers, software version, and license expiration date.
2	The documentation link opens the reference manual stored on the device.
3	The System Diagnostics Data section allows you to collect, download, and delete device logs that you can send to Cognex support engineers for troubleshooting support. Note: The log files in the downloaded .zip file are password-protected. Only Cognex support engineers can access them.
4	The Network Interfaces section lists the available and connected network ports with their configurations.
5	The Components section lists the different features that run on the device.

Tunnel Analytics

The Tunnel Analytics app provides analytics options.


Performance Dashboard

The Performance Dashboard page provides a configurable set of saved charts that visualize the performance data of connected devices.



Setting a value you want for **Past**, **Interval***, **Date & Time Range Filter** fields helps you to see the visualization of the performance data for that specific time interval and date.

You can adjust the data point granularity using **Interval***.



To look at a smaller time intervals, choose a smaller value for **Interval***.
 For example, to see a data point for every hour in the past one day, set **Past** to *1 day*, **Interval*** to *1 hour*.

Edit the Dashboard

The **Edit Dashboard** function allows you to add, edit, delete, and sort charts.

1. Click **Add Chart**.

This screenshot shows the top of the dashboard configuration interface. At the top, there are three buttons: 'Save Dashboard' (dark blue), 'Cancel' (light gray), and 'Add Chart' (yellow). The 'Add Chart' button is highlighted with a red rectangle and a mouse cursor is clicking it. Below the buttons is a form area with two dropdown menus. The first dropdown is labeled 'Chart Type *' and currently shows 'Line'. The second dropdown is labeled 'Devices *' and is currently empty.

2. Select the chart type from the dropdown list.

This screenshot shows the 'Chart Type *' dropdown menu open. The menu is highlighted with a red rectangle and contains four options: 'Step', 'Line', 'Column', and 'Scatter'. The 'Line' option is currently selected and highlighted with a gray background. A mouse cursor is pointing at the 'Line' option. To the right of the dropdown menu is the 'Devices *' dropdown menu, which is currently empty.

3. Select the device type from the dropdown list.


This screenshot shows the 'Devices *' dropdown menu open. The menu is highlighted with a red rectangle and contains four options, each with a checkbox: 'INBD1_Top_0-Left', 'INBD1_Top_1', 'INBD1_Top_2', and 'INBD1_Top_3-Right_P'. The 'INBD1_Top_0-Left' option is currently selected and highlighted with a gray background. A mouse cursor is pointing at the 'INBD1_Top_0-Left' option. To the left of the dropdown menu is the 'Chart Type *' dropdown menu, which now shows 'Step'. To the right of the dropdown menu is the 'Data Fields *' dropdown menu, which shows 'Good Read Count'.

- Select the data field type from the dropdown list.

- Name the new chart. Click **Add Chart**.


- Repeat the procedure to add more charts to the Dashboard. You can sort, edit, and delete the charts from the Dashboard.

Click **Save Dashboard** when you are done.



Live Dashboard

The Live Dashboard page allows you to configure the live dashboard and the triggers that visualize the performance data of connected devices.




Using the buttons on the right side of the live view, you can manipulate the image on the live feed.

To reset the live dashboard, click on **Reset** on the top right corner.

You can choose the image sources you want to work with on the top left corner under the **Image Sources*** field.

Note: **Image Sources*** corresponds to readers.



In the bottom of the **Live Dashboard** page you can find saved triggers that are available to download.

Download	Timestamp	Result	Trigger Index	Read String	Length (mm)	Width (mm)	Height (mm)	Object Gap (mm)
	2:47:29 PM	✓	3,987,528	HUG-10984288	873	768	905	2,381
	2:47:27 PM	✓	3,987,527	61109233810; BLU-95...	847	818	949	7,474
	2:47:25 PM	✓	3,987,526	COL-54801863; 74091...	901	761	947	740
	2:47:24 PM	✓	3,987,525	PUR-159455; 0971128...	1,056	854	934	1,462
	2:47:22 PM	✓	3,987,524	ARI-87748001; 99973...	839	760	918	7,484
	2:47:22 PM	✓	3,987,523	HUG-46483632	900	767	926	2,783

Pause

Items per page: 10

1 - 10 of 300

<
<
>
>

You can also pause the saving of live triggers by clicking on **Pause**.

Set the number of items you want to see on each page in the **Items per page** field.

Result Browser

The Result Browser page allows you to filter the results that Cognex devices collect and to find the data that is the most important to you. By default, the page is in Table View. You can also switch to [Gallery View on page 22](#).

The screenshot displays the COGNEX EI Tunnel Manager interface. The top navigation bar includes the COGNEX logo, 'EI Tunnel Manager', and a license expiration date of Sep 6, 2024. The user is logged in as 'admin'. The main content area is titled 'Result Browser' and shows a table of trigger data. The table has columns for Timestamp, Result, Tags, Trigger Index, Read String, Length (mm), Width (mm), and Height (mm). The data shows 12 triggers, with most results marked as 'X' (failed) and one marked with a green checkmark (successful). The 'Read String' column contains various alphanumeric strings. The 'Trigger Index' column shows values ranging from 515075 to 515084. The 'Timestamp' column shows dates from 04/15/24, 01:06:37 PM to 04/15/24, 01:06:46 PM. The interface also includes a sidebar with a list of emulators, a top navigation bar with 'Home', 'Tunnel Analytics', and 'Result Browser', and a bottom status bar showing 'DEVICE INFO' and 'DATE AND TIME'.

	Timestamp ↓	Result	Tags	Trigger Index	Read String	Length (mm)	Width (mm)	Height (mm)
☐	04/15/24, 01:06:46 PM	X		515084		-	-	-
☐	04/15/24, 01:06:45 PM	X		515083		-	-	-
☐	04/15/24, 01:06:44 PM	X		515082	o07377000020000000829...	-	-	-
☐	04/15/24, 01:06:43 PM	X		515081	k07377000010000000348...	-	-	-
☐	04/15/24, 01:06:42 PM	X		515080	m07377000020000000031...	-	-	-
☐	04/15/24, 01:06:41 PM	✓		515079	e07377000020000000567...	-	-	-
☐	04/15/24, 01:06:40 PM	X		515078		-	-	-
☐	04/15/24, 01:06:39 PM	X		515077	m07377000020000000031...	-	-	-
☐	04/15/24, 01:06:38 PM	X		515076	g07377000020000000515...	-	-	-
☐	04/15/24, 01:06:37 PM	X		515075		-	-	-

Items per page: 10 1 - 10 of 85291

To download all triggers, select **Download All** in the **More Actions** menu. To avoid exceeding the trigger count, select the triggers you want to download before clicking **Download All**.

To filter out the data, you can use default filter fields, such as **Trigger Index**, **Result Type**, **Read String**, and **Date & Time Range Filter**.

The **Trigger Index** is an index number that the DataMan reader assigns to every trigger as an identifier. You can search for multiple triggers by typing in the index numbers of those triggers. You can search for:

- Simple index number, for example 1010.
- Several index numbers separated them by pressing **ENTER**, for example, 1010, 1013, 1014.
- Range of index numbers using a hyphen, for example 1010-1016. You can also add another range by pressing **ENTER** and add the new value.

The **Result Type** is the classification of the trigger. The result type can be the following:


- Good Read: the reader successfully decoded the correct codes.
- No Read: the reader did not read any codes, or read the wrong codes.
- Failed Validation: the reader read an invalid code because the code is improperly formatted, or does not meet specific requirements.

The **Read String** is the string the unit reads.

The **Date & Time Range Filter** provides options to type a time range directly into the input field, select a time range using the menu, or select from a list of relative time options. Use the options to set the range. Use the **clear** functions to delete all or a part of the range.



Date and Time Range Picker



Quick Relative Time Options

You can find more filter options by clicking on **More Filters** on the top right corner of the page:

Filters

Trigger Information

Multi Read

True

False

Trigger Index

e.g. 101 or 105-107 or >101 or <107 or >=101

Result Type

Decode Results

Dimensioner Results

Scale Results

Sorter Information

Cancel

Search

To use more filters, click on the **down arrow** next to the name of a filter group.

Decode Results

Read String

Symbology Name

Assignment Result

Assigned Surface

Dimensioner Results

Legal For Trade

True

False

Angle

e.g. 101 or 105-107 or >101 or <107 or >=101

Length

e.g. 101 or 105-107 or >101 or <107 or >=101

Width

e.g. 101 or 105-107 or >101 or <107 or >=101

Height

e.g. 101 or 105-107 or >101 or <107 or >=101

Object Gap

e.g. 101 or 105-107 or >101 or <107 or >=101

Side By Side

True

False

Scale Results

Legal For Trade

True
False

Weight

e.g. 101 or 105-107 or >101 or <107 or >=101

Sorter Information

Vendor Token

Filter Query

You can create a filter query by entering input into the filter fields. When you add an input into one of the fields, you create a search condition that limits your trigger results to those that meet the set condition.

For boolean values, you can set the value to:

- True: Search for results where this condition is true.
- False: Search for results where this condition is false.
- Neither: Do not filter the results by this field.

For fields that can have multiple string values, use the dropdown to select one or more values.

If you select a value, you are searching for results that match that value. For example, you can search for any results that contain a Code 128 code:



If you select more than one value, you are searching for results that match either of those values. For example, you can search for results that contain a Code 128 code, *OR* an l2of5, *OR* a UPC/EAN code:

Symbology Name

☒ Code 128

☐ Code 25

☐ Code 93

☐ Code 39

☐ Codabar

☒ Interleaved 2 of 5

☒ UPC/EAN

☐ MSI

Use the input fields for data that have a numerical value. The numerical input field supports the following input formats:

Condition	Example
Single value	Packages that have a reported length of 533 (length = 533).
Less than condition	Packages that have a reported length less than 533 (length < 533).
Less than or equal to	Packages that have a reported length that is less than or equal to 533 (length <= 533).
Greater than condition	Packages that have a reported length greater than 533 (length > 533).
Greater than or equal to	Packages that have a reported length that is greater than or equal to 533 (length >= 533).
Range	Packages that have a reported length between 500 and 550 (500 <= length <= 550).

You can add multiple inputs of the various format listed above. To add an additional input, press **ENTER** and begin typing the next input. Each input appears with a remove icon next to it. To remove any of the inputs, click on the remove icon next to the input you want to remove.

Height

100-150✕ <80✕ >=500✕ -1✕ Press ENTER to add new value...

e.g. 101 or 105-107 or >101 or <107 or >=101

Note: Any input field that has a text input field, or a dropdown that allows you to enter, or select multiple values are joined together with an *OR* function. This means that the results appear if any of the criteria meets any of the provided inputs.

For example, you can type in the following four inputs into the height filter field. This search filters the results by packages that have a reported height between 100 and 150, *OR* a height less than 80, *OR* a height greater than or equal to 500, *OR* a height that is -1.

Height

100-150✕ <80✕ >=500✕ -1✕ Press ENTER to add new value...

e.g. 101 or 105-107 or >101 or <107 or >=101

Combining Filter Queries

When you enter input to more than one of the filter fields, you create multi-conditional queries. The conditions from different filter fields are evaluated with an *AND* function.

For example, if you select True for the Multi Read filter, and add the following values:

- Code 128
- Interleaved 2 of 5
- UPC/EAN
- -1 and <100 values for the length filter

Then you created the following filter query:

Multi Read = TRUE AND (Symbology Name = Code 128 OR Symbology Name = Interleaved 2 of 5 OR Symbology Name = UPC/EAN) AND (Length = -1 OR Length < 100)

Symbology Name

- ☒ Code 128
- ☐ Code 25
- ☐ Code 93
- ☐ Code 39
- ☐ Codabar
- ☒ Interleaved 2 of 5
- ☒ UPC/EAN
- ☐ MSI

Length

-1 <100 Press ENTER to add new value...

e.g. 101 or 105-107 or >101 or <107 or >=101


This means the filter shows results that are tagged as multi-reads *AND* contain a code that is either a code 128 *OR* Interleaved 2 of 5, *OR* UPC/EAN *AND* the reported length of the package is either -1 *OR* less than 100.

Gallery View

By default, the Result Browser page is in Table View. Switch the page from Table View to Gallery View using the view controls at the top of the page. Toggle between the two views by clicking on the representative icon.



In Gallery View, the table is replaced by a grid of thumbnail images. All other components remain the same. Similar to the Table View, the Gallery View shows all the triggers within the filtered time range.



Click the **Select All** checkbox to select all the items displayed on the current page.


The **Image Source** dropdown lists all the devices. You can change the device source of the images displayed by selecting a different device name from the list.

The **Timestamp** sort option allows you to sort the triggers by timestamp in ascending or descending order.

Instead of trigger data shown in the columns of the table, the Gallery View shows a cell for each trigger.

Each cell contains:


- A single image from the selected device source.
- A Good Read or No-Read icon (top-right corner).
- The trigger index.
- The date and timestamp of the trigger (bottom-left).
- The data tags assigned to the trigger (bottom-right).



Click on a trigger cell to navigate to the [Trigger Review](#) page, which displays the rest of the images and the specific data for that trigger.

Trigger Review


The Trigger Review page shows all the images and data associated with a selected trigger. Navigate to the Trigger Review page by clicking on a table row in Table View or by clicking on a cell in the Gallery View. The Trigger Review page displays several cards containing information for the selected trigger.



Trigger Details


Click on the pop-out icon in the top right corner of the Trigger card to open a dialog with all the details of the trigger.

Note: The pop-out icon does not appear on cards that have no data. Instead, the card shows **No Data** indicating that no data was collected. This can happen if the system does not have a dimension or scale.



Code Content


The **Code Content** table is populated with read codes. Click on a row to populate the main image viewer with an image of the read code. The row also expands to display highlights of the result data in a second row, including Face Assignment, Code Size, and Occlusion. Additionally, in the case of an unsuccessful read, the expanded row also displays the returned NRF (No Read Feedback) message.



Click on the pop-out icon to the right of the result data highlights to open a dialog with all the details of the result.


Settings

The **Settings** icon in the upper right-hand corner of the Trigger Review page expands the settings panel for the page.



In the **All Images** section of the panel, check the **Display SVGs** checkbox to enable or disable displaying the SVG overlays. By default, the page displays the SVG overlays.

Check the **Normalize Images** checkbox to enable image normalization. Normalization brightens the contrast on dark images so the details are easier to see. By default, the normalization is off.



Note: Normalization adds additional processing time to the images and can cause the images in the gallery and main image viewer to load more slowly. Cognex recommends to only use the feature when images are too dark to see the details.

In the **Configure Cards** section of the settings panel, check or uncheck the checkbox next to each item to configure which data cards to display on the page.


Data Tagging

You can add, view, and remove data tags from the triggers.

In the Table View, the **Tags** column displays the tags for each trigger.


☐	Timestamp ↓	Result	Tags	Trigger Index	Read String	Length (mm)	Width (mm)	Height (mm)
☐	03/07/24, 09:25:03 AM	✓		100499	#07577000020000000000...	-	-	-
☐	03/07/24, 09:25:03 AM	✗		100498	#07577000020000000000...	-	-	-
☐	03/07/24, 09:25:02 AM	✓		100497	#07577000020000000000...	-	-	-
☐	03/07/24, 09:25:02 AM	✓		100496	#07577000020000000000...	-	-	-
☐	03/07/24, 09:25:01 AM	✗	NO	100495	#07577000020000000000...	-	-	-
☐	03/07/24, 09:25:01 AM	✗		100494	#07577000020000000000...	-	-	-
☐	03/07/24, 09:25:00 AM	✓		100493	#07577000020000000000...	-	-	-
☐	03/07/24, 09:25:00 AM	✗	NO	100492	#07577000020000000000...	-	-	-
☐	03/07/24, 09:24:59 AM	✗		100491	#07577000020000000000...	-	-	-
☐	03/07/24, 09:24:59 AM	✓		100490	#07577000020000000000...	-	-	-
☐	03/07/24, 09:24:58 AM	✓		100489	#07577000020000000000...	-	-	-
☐	03/07/24, 09:24:58 AM	✓		100488	#07577000020000000000...	-	-	-
☐	03/07/24, 09:24:57 AM	✗	NO	100487	#07577000020000000000...	-	-	-

In the Gallery View, the tags for each trigger are displayed in the bottom-right corner of each cell.



The tags appear as abbreviated versions. The letters from the first two words in the tag are displayed in a circular chip. For example, if the tag is "Flagged Label", the chip displays "FL" as the abbreviation. If the tag is "Side by Side", the chip displays the letters "SB". You can hover over the tags to see the full name.

In the [Trigger Review](#) page, the tags applied to the entire trigger result are shown in the **Trigger** section under **Data Tags**. The tags are displayed in the non-abbreviated form. Tags applied to specific images appear in the thumbnail image in the abbreviated form.



Tagging in the Result Browser

You can apply tags in bulk to multiple triggers or images in the Result Browser page.

To apply a tag in Table View, use the corresponding checkboxes in each row to select multiple triggers. Use the global checkbox to select all the triggers on a single page. The count next to the global checkbox shows the number of triggers selected.

[illegible]

To apply a tag in Gallery View, select the checkboxes located in the top left corner of the thumbnail in each trigger cell. Click the **Select All** global checkbox to select all the items on the current page. The count below the global checkbox shows the number of triggers selected.

COGNEX | El Tunnel Manager | El Tunnel Manager

License Expires: Sep 5, 2024

Home » Tunnel Analytics » Result Browser

Trigger Index: Result Type: Read String:

Only a Time Range Filter: 3/13/2024, 2:28 PM - 3/14/2024, 2:28 PM

More Filters More Actions

Download All Tag Selected

Select All 4 selected


Image Source: L_Top_Image_(Emulator)

Index	Timestamp	Image
Index: 100999	03/14/24, 09:26:40 AM	
Index: 100998	03/14/24, 09:26:38 AM	
Index: 100997	03/14/24, 09:26:37 AM	
Index: 100996	03/14/24, 09:26:36 AM	
Index: 100995	03/14/24, 09:26:35 AM	
Index: 100994	03/14/24, 09:26:34 AM	
Index: 100993	03/14/24, 09:26:33 AM	
Index: 100992	03/14/24, 09:26:32 AM	
Index: 100991	03/14/24, 09:26:31 AM	
Index: 100990	03/14/24, 09:26:30 AM	

Items per page: 10 1 - 10 of 1000

Note: In Gallery View, you apply the tag to the specific image shown. When you click on the trigger to navigate to the Trigger Review page, the tag is on the thumbnail image in the gallery. Tagging specific images also gives you the option to only download an image from the trigger rather than the entire set of images.

Click **More Actions**. Click the **Tag Selected** option to open the **Tag Results** dialog.



Previously-created tags appear in the table list. You can search for a specific tag using the search field above the list.

If the triggers selected do not have any existing tags, all the tag selections show an empty checkbox. If all the selected triggers have one or more of the same tags, those tags have a checked checkbox. If only some of the selected triggers have one or more of the tags, those tags have a partial checkbox.




You can remove tags from the selected triggers by unchecking the checkbox. To add a tag that exists on some of the triggers but not all, click once to clear the checkbox and then click again so the checkbox is checked. This applies the tag to the rest of the triggers which do not already contain the tag.


Note: Duplicate tags are not created for a single trigger.

Click **Apply** to add tags to the selected triggers. Click **Cancel** to discard changes or close the **Tag Results** dialog.

Create a New Tag

Click on the plus icon below the tag list in the **Tag Results** dialog. The **Create Tag** section appears within the dialog.




Provide a name for the tag and select a color. Choose from the default colors available or create a custom color by clicking on the palette icon. You can also provide a short description for the tag. Click **Create**, and the tag appears in the list above.

Note: Tags applied in the Table View are automatically applied generally to the entire trigger rather than to specific images.

Tagging in Trigger Review

You can tag triggers one at a time in the Trigger Review page. This is useful when sorting through no-reads and classifying the root cause one at a time.


To tag in the Trigger Review page, select images and click the **Tag** button. The **Tag Results** dialog appears. You can select, deselect, and add tags to the selected images.



Filtering by Tags

You can filter results by tag in the Result Browser page. Select **More Filters**. The **Filters** dialog appears. In the **Trigger Information** section, use the **Data Tags** dropdown to select one or more data tags to filter the results by.

Note: If you select more than one data tag from the list, the filter includes triggers that contain any one of the tags selected.




Click **Search**. The Result Browser now only shows the results within the filtered dataset. The **Active Filters** section shows the filters.



Downloading Tagged Images

You can download images in bulk from the Result Browser or individually from the Trigger Review page.

In the Result Browser, download the set of filtered data by selecting **More Options** and clicking **Download All**.



The **Download Data** dialog appears.

Download Data

Title*

Downloaded Data

15/255

Select data to be saved *

Trigger

Image

Select devices to save image data from *

	Name
☒	L_Top_Image_(Emulator)
☐	Leading-Top_1-Front_(Emulator)
☐	Leading-Top_2-Front_(Emulator)

☐ Only download images that have been tagged

Cancel

Submit

Provide a title for the download. Select Trigger and Image data to include in the download. The Trigger data is all the result data, such as trigger index, read code string, and dimensions, downloaded into a .csv file. The Image data is the .jpg for each trigger.

In the Image data section, you can choose to download the image data for all devices or only from select devices. You can select all devices by clicking the global checkbox.

Note: From Gallery View, the device you were already viewing is selected by default. From Table View, all devices are selected by default.

You can choose to only download tagged images by switching the **Only download images that have been tagged** toggle.

Click **Submit** to start the download.

Note: After filtering the triggers or images to specific tags, you can also download the tagged triggers or images specifically by the filter applied. For example, if you select "empty tray" as the filter for the data tags, when you click **Download All**, it downloads the triggers or images with just the "empty tray" tag, not the entire timeframe of data.

Events

The Events app allows you to track changes to the connected readers.

Configuration Change History

The Configuration Change History page tracks changes made to the configuration of all connected readers and shows changes in a customized fashion. The window displays the Device tree with available grouped and standalone readers. The page automatically links configurations with the respective usernames.

Actions	Date & Time ↓	Device Name	Username
☐	4/9/20, 7:05 AM	DM374-EI-Demo-Online	admin
☐	4/9/20, 7:03 AM	DM374-EI-Demo-Online	admin
☐	4/9/20, 5:06 AM	DM374-EI-Demo-Online	admin
☐	4/9/20, 5:04 AM	DM374-EI-Demo-Online	admin
☐	4/9/20, 3:06 AM	DM374-EI-Demo-Online	admin
☐	4/9/20, 3:04 AM	DM374-EI-Demo-Online	admin
☐	4/9/20, 1:06 AM	DM374-EI-Demo-Online	admin
☐	4/9/20, 1:04 AM	DM374-EI-Demo-Online	admin
☐	4/8/20, 11:06 PM	DM374-EI-Demo-Online	admin
☐	4/8/20, 11:04 PM	DM374-EI-Demo-Online	admin

Configuration Change Actions

☒ <input type="download"/> <input type="refresh"/>	
Icon	Action
☒	Selected checkbox
<input type="download"/>	Download Configuration File
<input type="refresh"/>	Restore Configuration

- Click the **checkbox** from the list in the left side of the rows to select a configuration.
- Click the **Download Configuration File** to download the selected Configuration files.
- Click **Restore Configuration** to revert to a previous configuration.
 - After clicking **Restore Configuration** enter your password and click **Restore** to revert configuration. Click **Cancel** to leave the popup window without restoring the selected configuration.

The screenshot displays the 'Configuration Change History' page in the EI Tunnel Manager. The page has a yellow header bar with 'admin' and a user icon. Below the header, there's a breadcrumb trail: 'Home > RTM > Configuration Change History'. A 'Compare Configurations' button is on the left, and a 'Date & Time Range Filter' is on the right, showing a range from 9/1/2021, 4:18 PM to 9/2/2021, 4:18 PM. The main table has columns: 'Actions', 'Date & Time', 'Device Name', and 'Username'. The table lists several configuration changes for 'Line42-N1-DM374' by 'admin'. One row is selected, and a 'Restore Configuration' popup is displayed over it. The popup contains a 'Password' field, a warning message, and 'Cancel' and 'Restore' buttons. The warning message states: 'Are you sure you want to restore configuration of Line42-N1-DM374 to that of 9/2/21, 4:14 PM? This action will also affect network configurations, which could cause IP conflicts.' The bottom of the page shows 'Items per page: 10' and '1 - 10 of 371'.

Dashboard overview:


Item	Description
Compare Configurations button	Select 2 checkbox to enable the button. Click the button to see configuration changes in a pop-up window. For more information see
Date & Time Range Filter	Use the time range to define a period of time from which performance data is collected for the charts. For more information see Date & Time Range Filter on page 1
Configuration tables	List of readers and groups available for comparison.

Note: Changes made from Dataman Setup Tool are labeled as admin changes.

Column Name	Description	Display
Date and time	Date and time of the configuration change.	3/3/20, 9:10 AM
Device name	Name of the reader on the network.	
Username	Name and type of the user who made the configuration change.	

Configuration Changes

To compare two configurations, select the readers to compare. Click the **Compare Configurations** button. A pop up window appears with a table that shows the compared configurations.




Item	Description
Configuration Changes	Lists variables that have different values in the compared versions
Read Setups	Display the name of the readers compared, and the difference in values pertaining to the row of the configuration scripts
Variable Name	Name of the variable which has different values in the compared versions
Script Name	Name of the recently modified script
Read Setup	Name of the read setup

Provisioning

The Provisioning app allows you to provision your connected devices and device groups, and allows you configure what data you want to collect from each of your devices, and manage your remote subnets.

DataMan

The DataMan page of the Provisioning app provides a list of standalone readers, as well as reader groups, and allows you configure what data you want to collect from each of your readers. You can also provision one or more of your readers at the same time, or individually by IP address.



To refresh the list of connected readers, click **Refresh** in the header.

To provision readers, click **Provision devices** and use the pop-up dialog to select the readers. To provision a reader by IP address, click **Provision device by IP** and enter the reader IP address.

Click **Save** to apply any changes you make to data collection settings.

Actions

You can perform actions on an individual reader by clicking on the icons in the **Actions** column of the row for the selected reader:

Actions	
 	
Icon	Action
	Flash LED
	Delete

- Click the **Flash LED** button to remotely trigger the LED of the reader for easy identification.
- Click the **Delete** button to remove the reader from the list.

Provisioning Devices

Click on **Provision devices** in the header to open the **Provision devices** pop-up dialog:

Provision devices

Discover Devices

Search

Standalone Devices

Actions

Primary

Name

Type

MAC Address

Firmware Version

Address Type

IP Address

Subnet Mask

Gateway

☒

Static

☐

Static

☐

Static

☐

Static

Cancel

Provision

The **Provision devices** dialog provides a list of connected readers. To provision one or more readers, check the checkbox for the selected readers, and click **Provision**.

To flash the LED on a reader for easier identification, click the **Flash LED** icon in the **Action** column of the row for the selected reader.

To refresh the list of connected readers, click **Discover Devices**.

To search for a specific reader in the list, enter the name or IP address in the **Search** bar.

Provision Device by IP

Click on **Provision device by IP** in the header to open the **Provision device by IP** pop-up dialog:

Provision device by IP

IP Address *

Cancel

Provision

Enter the IP address of the selected reader, and click **Provision**.

Data Collection Settings

You can modify collection settings for different types of data using the toggles in each column of the row for the selected reader:

Column	Description
Password	Provide the password for the reader to make any changes.
Collect Good Read Triggers	Enable this setting to collect good read trigger data from the reader.
Collect No Read Triggers	Enable this setting to collect no read trigger data from the reader.
Collect Validation Failure Triggers	Enable this setting to collect validation failure trigger data from the reader.
Collect Good Read Images	Enable this setting to collect good read image data from the reader.
Collect No Read Images	Enable this setting to collect no read image data from the reader.
Collect Validation Failure Images	Enable this setting to collect validation failure image data from the reader.
Collect Device Configuration Changes	Enable this setting to collect reader configuration change data from the reader.
Collect Statistics	Enable this setting to collect statistics from the reader.
Collect Tunnel Trigger Result	Enable this setting to collect tunnel trigger results from the reader.

To order the list of readers by type of data collection enabled, click on a data collection column header.


Remote Subnets

The Remote Subnets page provides a list of remote subnets, and allows you to add additional subnets.

Home » Provisioning » Remote Subnets				
Add Remote Subnet				
Actions	Name	IP Address	Subnet Mask	State
				Finished
				Finished

To remove a remote subnet from the list, click on the **Bin** icon in the **Actions** column of the row for the selected subnet.

Click on **Add Remote Subnet** to open the **Add Remote Subnet** pop-up dialog:

A dialog box titled "Add Remote Subnet" with three text input fields labeled "Name *", "IP Address *", and "Subnet Mask *". At the bottom right are "Cancel" and "Add" buttons.

Add Remote Subnet

Name *

IP Address *

Subnet Mask *

Cancel Add

Enter the name, IP address, and subnet mask for the remote subnet you want to add, and then click **Add**.

Device Management

The Device Management app provides a list of standalone devices and device groups, shows device information, and allows you to modify settings on individual devices as well as multiple devices simultaneously. You can also save entire tables of device configuration data to your local machine.

DataMan

The DataMan page of the Device Management app provides a list of standalone readers and reader groups, including reader data. You can edit the configuration, flash the LED, reboot, or access the DataMan WebHMI of individual readers. You can perform mass configuration or firmware updates for reader groups.

The screenshot shows the COGNEX EI Tunnel Manager interface. At the top, there's a yellow header with the COGNEX logo and 'EI Tunnel Manager'. Below it, a navigation bar includes 'Home', 'Device Management', and 'DataMan'. A search bar is on the right. Below the navigation bar, there are buttons for 'ADD SELECTED TO GROUP', 'UPLOAD CONFIGURATION', 'UPLOAD FIRMWARE', 'DOWNLOAD AS CSV', and 'DISCOVER DEVICES'. The main area is titled 'Standalone Devices' and contains a table with columns: Actions, Password Protected, Primary, Name, Type, MAC Address, Firmware Version, Address Type, and IP Address. The table lists several devices with their respective settings and icons for actions like edit, delete, and discover.

Item	Description												
Action ribbon	Provides quick access to actions you can perform on the selected readers. <table> <tr> <th>Button</th><th>Description</th></tr> <tr> <td>Add Selected to Group</td><td>Add selected readers to MRS group.</td></tr> <tr> <td>Upload Configuration</td><td>Upload a configuration file to the selected readers.</td></tr> <tr> <td>Upload Firmware</td><td>Upgrade firmware on selected readers.</td></tr> <tr> <td>Download as CSV</td><td>Download a list of readers as a CSV file.</td></tr> <tr> <td>Discover devices</td><td>Find readers on the local and remote networks, depending on the configuration on the Remote Subnets on page 38 page.</td></tr> </table>	Button	Description	Add Selected to Group	Add selected readers to MRS group.	Upload Configuration	Upload a configuration file to the selected readers.	Upload Firmware	Upgrade firmware on selected readers.	Download as CSV	Download a list of readers as a CSV file.	Discover devices	Find readers on the local and remote networks, depending on the configuration on the Remote Subnets on page 38 page.
Button	Description												
Add Selected to Group	Add selected readers to MRS group.												
Upload Configuration	Upload a configuration file to the selected readers.												
Upload Firmware	Upgrade firmware on selected readers.												
Download as CSV	Download a list of readers as a CSV file.												
Discover devices	Find readers on the local and remote networks, depending on the configuration on the Remote Subnets on page 38 page.												
Search Field	Allows for searching for a reader by any characteristic, such as name, model or firmware version.												
Standalone reader list	A table view of the settings of the standalone readers that are discovered on the network with options that can be enabled or disabled for the reader.												
Grouped reader list	Table views of the readers in a group sorted alphabetically by group name with options that can be enabled or disabled for the individual reader.												

Columns of the Table View


The table view of the standalone or group readers displays information and allows setting changes to the individual readers.

Column Title	Description
--------------	-------------

Actions	Click on the icons to perform actions on an individual reader.	
	    	
	Button	Description
	Edit Device Network Settings	Modify the name, IP address, Subnet Mask, and Default Gateway of the reader. Enter the reader password if required.
	Flash LED	Remotely trigger the LED of the reader for easy identification.
	Reboot	Reboot the reader.
	Show Device Logs	Opens a window that shows the reader logs. In this window, you can reload to pull the latest logs or download them as <i>.log</i> file.
	Open DataMan WebHMI	Open the DataMan WebHMI in a new tab. For more information, see DataMan WebHMI on page 41 .
Password Protected	Indicates whether the reader is password protected.	
Primary	A check mark signifies the primary reader.	
Name	A customizable name of the reader.	
Type	The model of the reader.	
MAC Address	The MAC address of the reader.	
Firmware Version	The version of firmware installed on the reader.	
Address Type	Indicates network address type (DHCP or static) for the reader.	
IP Address	The IP address of the reader.	
Subnet Mask	The subnet mask of the reader.	
Gateway	The gateway of the reader.	
Source Network Interface	The Ethernet port the reader uses for connection.	
State	Displays the state of the reader, which can be: • In Local Subnet • In Remote Subnet • In Remote Subnet Behind NAT • Waiting For DHCP • Misconfigured • Unknown	
Task Status	Displays the status of the task, such as rebooting, applying network settings, and name changes.	

DataMan WebHMI

The DataMan WebHMI provides a live view of reads, results and statistics, and allows you to pause the feed and scroll back to analyze or download individual result images. You can manually trigger or tune readers and adjust reader settings from the DataMan WebHMI.



You can access the DataMan WebHMI for a connected reader from the DataMan page by clicking the icon labeled **Open DataMan WebHMI** in the **Actions** column of the selected reader.

Home

The DataMan WebHMI **Home** page displays a live feed of the reader with statistics and result logs.

On the left side, the DataMan WebHMI home page shows statistics for:


- **Read Rate** percentage
- Number of **Good Reads**
- Number of **No Reads**
- Number of **Triggers**

The display on the right side of the page provides a live feed of the reader view with additional controls on the right side of the display for changing orientation and zoom:

Icon	Action
	Rotate Left 90°
	Rotate Right 90°
	Reset Rotation
	Zoom In

	
Icon	Action
	Zoom Out
	Zoom To Original Size
	Reset Zoom
	Move Center
	Reset All Settings

You can also filter the feed to display only **Good Read**, **No Read**, or **Validation Failure** results by clicking on the **Images** icon in the top right corner of the display.



The result logs of the last 50 captures are listed on the bottom of the page. You can browse the list using the navigation buttons in the bottom right corner of the pane.

Image	Result	Decode Time	Arrival Time	Read String	
	✓	13ms	12:03:18.947 PM	12	
	✓	12ms	12:03:17.783 PM	http://www.google.com	
	✗	13ms	12:03:16.586 PM		

 Pause

 Download Result Image(s)

Items per page 3

1 – 3 of 50




Click on the **Pause** button in the bottom left corner to pause the live feed. Pausing the feed allows you to select and download result images. Click on a log to put the result image on the display.

To download the image currently on the display, click on the **Download Result Image(s)** button without selecting any images from the result logs.

Check the checkboxes in the rightmost column of the result logs to select images for download, or check the checkbox in the table header to select all images. Click on **Download Result Image(s)** while multiple images are selected to download a ZIP file containing the selected result images.

Actions

The **Actions** page of the DataMan WebHMI allows you to manually trigger, start or stop, tune, or untrain the reader.



Click **Trigger** to trigger the reader manually.

Click **Live** to show the live feed of the reader.

Click **Tune** to initiate an automatic recalibration. Open the Tune dropdown to optimize brightness or focus individually.

Note: When you tune a reader, the reader stops triggering.

Click **Untrain** to untrain the reader.

Settings

The **Settings** page of the DataMan WebHMI allows you to manually change the reader configuration, upload, download, or save the current configuration, or reset the reader to a previously saved configuration.

Variable Name	Setup 0
Read Setup	
Name	Setup 0
Enabled	☒
Enable Distance Check	☐
Min Distance (mm)	0
Max Distance (mm)	10000
Starting Setup	0
Last Successful Decode	☐
Tuning	
Train Code	☒

- Click **Expand All** or **Collapse All** at the top of the page to expand or collapse the setting categories in the settings table.
- Click **Add New Read Setup** to create a new setup using default settings or an existing setup as a template.

- Click **Upload** to upload a local configuration file to the reader.
- Click **Download** to save the reader configuration locally.
- Click **Save** to save the configuration on the reader flash memory.
- Click **Reset** to reset the reader configuration to default or a saved configuration.

The settings table provides you with detailed and in-depth configuration options for all reader functionality. Each setting corresponds to a control command for the reader. For a detailed description of the available settings for the reader you are configuring, see the corresponding control commands for the reader in the *DataMan Control Commands Documentation*.

System

The **System** page of the DataMan WebHMI displays detailed reader information, reader statistics, feature keys, and reader time.

COGNEX

Home Actions Settings System

Device Information

Device Model:

Serial Number:

Device Name:

MAC Address:

IP Address:

Firmware Version:

Installed Hardware:
LiquidLens, Custom

Bootloader Version:

OS Version:

Reader Statistics

Total Triggers:
1,376,159

Total Reads:
1,225,743

Read Rate:
89.07%

Total No-Reads:
150,416

No-Read Rate:
10.93%

Missed Triggers:
0

Passed Validations:
0

Failed Validations:
0

Buffer Overflows:
0

Trigger Overruns:
0

Item Count:
0

Clear

Feature Keys

1DCodeQuality, 1DDataStitching, 1DExtendedRes, 2DCode, 2DCodeQuality, BarCode, DotCode, IDMax, FullSpeed, IDQuick, ImageDownload, ImageFiltering, ImageFoV_Full, IntImageBuffer, LadderAndPicket, MST, Omnidirectional, PostalCode, PowerGrid, Scripting, SignopticSig, Validation

Device Time

Local Time:
Jan 26, 2019, 2:36:11 AM

Uptime:
601h 36m 13s

Add DataMan Readers to Groups

Create device groups to organize and manage the configuration of your readers collectively.

Procedure

1. Click the **Menu** icon and go to the **DataMan** page of the Device Management app.
2. Select one or more readers or reader groups using the checkboxes.
3. Click the **Add Selected to Group** button.

COGNEX

EI Tunnel Manager

Home

Device Management

DataMan

Add Selected to Group

Upload Configuration

Upload Firmware

Download as CSV

Discover Devices

Standalone Devices

	Actions	Password Protected	Primary	Name
☒				
☒				
☒				
☐				
☐				

4. In the window that pops up:

Multi Device Edit

☒ Enable Group Triggering

Group* Primary Device* 4/31

Select an existing group or type a new group name. Select the primary device from the list.

Actions	Primary	Name	Group	Address Type	IP Address	Subnet Mask	Gateway	Task Status
		10.86.98.100		Static	10.86.98.100	255.255.255.0	10.86.98.1	
		10.86.98.101		Static	10.86.98.101	255.255.255.0	10.86.98.1	
		10.86.98.102		Static	10.86.98.102	255.255.255.0	10.86.98.1	

☒ Use DHCP

Mass Network Settings Generator Change network settings at once

- Type in the name of an existing group, or type a new group name.
- Select the primary reader in the group.
- Optionally, you can:
 - Reorder the readers in the group.
 - Flash the LEDs of the individual readers for easy identification.
 - Manually edit the network settings of each reader, or edit the network settings for every reader in the group with the **Use DHCP** toggle and the **Mass Network Settings Generator** option.

Note: When editing the IP address of readers in a group, the readers get sequential IP addresses. For example, if you enter 10.86.98.100 in the **IP Address** field, the first reader in the group gets the 10.86.98.100 address, and the other readers get 10.86.98.101, 10.86.98.102, and the subsequent addresses.

5. If editing a password-protected reader, enter the password.

6. Click **Submit**.


Upload Configuration to DataMan Readers

Upload a configuration file to one or more readers to apply the same configuration to multiple readers in one batch.

Procedure

- Click the **Menu** icon and go to the **DataMan** page of the Device Management app.
- Select one or more readers or reader groups using the checkboxes.

- Click the **Upload Configuration** button.



- Click **Browse** in the window that pops up.
- Select the configuration file for upload.
- If you want to apply network settings, enable the **Apply Network Settings** toggle.

Note: When uploading configuration to multiple readers, this option is disabled.

- If editing a password-protected reader, enter the password.
- Click **Submit**.


Upload Firmware to DataMan Readers

Upload a firmware file to one or more readers to update the firmware of multiple readers in one batch.

Procedure

- Click the **Menu** icon and go to the **DataMan** page of the Device Management app.
- Select one or more readers or reader groups using the checkboxes.

- Click the **Upload Firmware** button.



- Click **Browse** in the window that pops up.
- Select the firmware file for upload.
- If editing a password-protected reader, enter the password.
- Click **Submit**.

Other Devices

The Other Devices page allows you to create a connection between the production network and devices on the subnet of an EI Tunnel Manager unit. The connection uses port forwarding to access the device through the IP address of the EI Tunnel Manager unit. Using this method, you can connect to devices such as a reader, dimensioner, network switch, or computer.

The following examples are typical use cases for port forwarding:

- Accessing the WebHMI of a DataMan reader or a 3D-A1000 dimensioner
- Connecting to a laptop through remote desktop

Connection Behavior and Timeout

Connections automatically close after 30 minutes to support basic security principles. When a connection closes, all communications stop on that port. Processes in other apps that use the device through the connection also stop.

Connections operate based on the following behavior:

- Newly created connections start in a closed state.
- Editing a connection or opening the WebHMI changes the state to open.
- Opening the WebHMI refreshes the timeout of an active connection, keeping it open.
- To manually start or close a connection, click the **Start** or **Stop** action buttons in the user interface.

Features of the Other Devices User Interface

At first, the Other Devices page only provides an option to create a new connection. The connections you create appear in a list along with their name and network details. The list provides options to edit, delete, access, or filter your connections.

1

2

3

4

5

COGNEX | EI Tunnel Manager

Full License

admin

Search

ADD NEW

DELETE

Active

Connection active for

Name ↑

Destination

External port

29 minutes

Number	Name	Description														
1	Add New button	Opens the form where you can create a connection for a device.														
2	Delete button	Deletes the selected connections. This button only becomes active after you select one or more connections from the list.														
3	Actions	Several actions are available for each connection in the list. <table><thead><tr><th>Action</th><th>Description</th></tr></thead><tbody><tr><td>Start/Stop</td><td>Starts or stops the connection.</td></tr><tr><td>Edit</td><td>Allows you to edit the connection. This action opens the same form used when creating the port forwarding configuration.</td></tr><tr><td>Delete</td><td>Deletes a connection.</td></tr><tr><td>Copy Device Address</td><td>Copies the IP address and port number of the device to the clipboard. This action is available only if you select the Other Destination Type when creating the configuration.</td></tr><tr><td>Remote Desktop</td><td> Downloads an .rdp file for connecting remotely or copies the remote desktop address to the clipboard, depending on the sub-option you select. How to set up a remote desktop connection? Download RDP file Copy remote desktop address This action is available only if you select the Remote Desktop Destination Type when creating the configuration. Note: For more information about using an .rdp file, see the in-app help. </td></tr><tr><td>Open WebHMI</td><td>Opens the WebHMI of the device. This action is available only if you select the WebHMI Destination Type when creating the configuration.</td></tr></tbody></table>	Action	Description	Start/Stop	Starts or stops the connection.	Edit	Allows you to edit the connection. This action opens the same form used when creating the port forwarding configuration.	Delete	Deletes a connection.	Copy Device Address	Copies the IP address and port number of the device to the clipboard. This action is available only if you select the Other Destination Type when creating the configuration.	Remote Desktop	Downloads an .rdp file for connecting remotely or copies the remote desktop address to the clipboard, depending on the sub-option you select. How to set up a remote desktop connection? Download RDP file Copy remote desktop address This action is available only if you select the Remote Desktop Destination Type when creating the configuration. Note: For more information about using an .rdp file, see the in-app help.	Open WebHMI	Opens the WebHMI of the device. This action is available only if you select the WebHMI Destination Type when creating the configuration.
Action	Description															
Start/Stop	Starts or stops the connection.															
Edit	Allows you to edit the connection. This action opens the same form used when creating the port forwarding configuration.															
Delete	Deletes a connection.															
Copy Device Address	Copies the IP address and port number of the device to the clipboard. This action is available only if you select the Other Destination Type when creating the configuration.															
Remote Desktop	Downloads an .rdp file for connecting remotely or copies the remote desktop address to the clipboard, depending on the sub-option you select. How to set up a remote desktop connection? Download RDP file Copy remote desktop address This action is available only if you select the Remote Desktop Destination Type when creating the configuration. Note: For more information about using an .rdp file, see the in-app help.															
Open WebHMI	Opens the WebHMI of the device. This action is available only if you select the WebHMI Destination Type when creating the configuration.															

4	Connection details	The connection list shows details for each connection. • Active: The state of the connection, open or closed. • Connection active for: The elapsed duration of the current connection. Connections automatically time out after 30 minutes. • Name: The unique name given when adding a new connection. • Destination: The IP address and port of the device. • External Port: The port by which you can access the device through the EI Tunnel Manager unit.
5	Search field	Filters the connection list. Enter any detail (name, destination, external port) to quickly find a specific connection.

Connect to Other Devices

You can connect from the production network to devices on the subnet of an EI Tunnel Manager unit by creating a port-forwarding configuration.

Prerequisites

Obtain the IP address and the port of the device you want to access.

Procedure

To create a new connection:

1. Open the **Apps** menu and select the [Other Devices on page 49](#) page of the Device Management app.
2. Click **Add New**, which opens the form where you can configure port forwarding for a device.

The screenshot shows the 'Other Devices (Create)' form in the COGNEX EI Tunnel Manager interface. The form is titled 'Other Devices (Create)' and has a 'SAVE' button and a 'CANCEL' button. The form contains the following fields:

- Name***: A text input field with a note: 'The name of the communication forwarding setting, it must be unique.'
- Destination Type***: A dropdown menu with 'Web HMI' selected.
- Destination IP***: A text input field with a note: 'The destination IP address of the device.'
- Destination port***: A text input field with '80' entered. A note below it says: 'Example ports: HTTP - 80, HTTPS - 443 or RDP - 3389.'
- External port**: A text input field with a note: 'The port by which the device can be accessed via Edge Intelligence. This is an optional field and will be assigned automatically if nothing is entered.'

3. Fill in the required fields:

Required Fields	Description
Name	The unique name of the connection. The name can only contain lowercase and uppercase letters, numbers, spaces, periods, hyphens, and underscores.
Destination Type	The type of access you want to configure for the device. Select an option from the dropdown menu: • WebHMI: Adds a button on the Other Devices page that opens the WebHMI of the device. • Remote Desktop: Adds a button on the Other Devices page that downloads an <i>.rdp</i> file for connecting remotely or copies the remote desktop address to the clipboard. • Other: Adds a button to the Other Devices page that copies the IP address and port number of the device to the clipboard.
Destination IP	The IP address of the device that you want to access. Ensure that each Destination IP and Destination Port combination is unique among your connections.  Note: The Destination IP cannot be the IP address of the EI Tunnel Manager unit.
Destination port	The port of the device that you want to access. You can use any of the valid ports of the device. If you do not know which port to use, consider the following examples: • Port 80 for HTTP • Port 443 for HTTPS • Port 3389 for a remote desktop connection


4. Option: To configure a specific open port of the EI Tunnel Manager unit for port forwarding, fill out the **External port** field. You have to use a unique external port for each connection. The available range is 50000-59999.

 **Note:** If you leave the **External port** field empty, the EI Tunnel Manager unit automatically assigns a suitable port.

5. Click **Save**.

Feature Keys

The Feature Keys page shows the feature keys applied on each discovered reader.



The following actions are available:

- Uploading feature key files
- Downloading Feature Keys page information in CSV
- Discovering devices

Upload feature keys Download as CSV Discover devices	
Button	Description
Upload feature keys	Upload feature key files.
Download as CSV	Download device list with all data in CSV format.
Discover devices	Discover connected devices.

The Feature Keys page also allows comparing uploaded feature keys between readers in a group:

Feature Key Color	Description
BLUE	The feature is unlocked for the device.
RED	The feature is unlocked for some devices in the group, but not for the respective device.

Click the **Difference** dropdown menu to select the following menu items for comparison:

Unlocked

Unlocked

All

Common

Difference

Item	Description
Unlocked	Show unlocked feature keys for all devices.
All	Show unlocked and locked feature keys for all devices.
Common	Show feature keys which are unlocked for all devices.
Difference	Show feature keys which have a different status among the devices.

Click the **Upload feature keys** button to upload a feature key file from your computer:

Upload feature key files

Password

Only if device requires password for changes.

Browse

Browse files with extension: .xml

Verification	File Name	Device Name	Serial Number	Feature Keys in File
✓				PTP MST

Cancel Upload

Item	Description
Password	Password is only needed if the device requires a password.
Browse	Browse files with .xml extension on your computer.
Verification	Shows verified status.
File Name	Name of the feature key files.
Device Name	Name of the device which gets the new feature key file.
Serial Number	Serial number of the device.
Feature Keys in File	Feature keys contained in the file.

Hybrid Switches

The Hybrid Switches page of the Device Management app allows you to manage hybrid switches.

COGNEX EI Tunnel Manager Full License										
Home > Device Management > Hybrid Switches										
UPLOAD FIRMWARE DISCOVER DEVICES										
☐	Actions	Name	MAC Address	Firmware Version	Address Type	IP Address	Subnet Mask	Gateway	Source Network Interface	State
☐	  	Switch-1	00:0C:29:00:00:00	1.0.0.0 (Build: 1.1)	Static	10.10.10.100	255.255.0.0	10.10.10.255	eth0	In Local Subnet
☐	  	Switch-2	00:0C:29:00:00:01	1.0.0.0 (Build: 1.1)	Static	10.10.10.101	255.255.0.0	10.10.10.255	eth0	Misconfigured
☐	  	Switch-3	00:0C:29:00:00:02	1.0.0.0 (Build: 1.1)	Static	10.10.10.102	255.255.0.0	10.10.10.255	eth0	In Local Subnet

Item	Description						
Action ribbon	Provides quick access to actions you can perform on the selected switches. <table> <tr> <th>Button</th><th>Description</th></tr> <tr> <td>Upload Firmware</td><td>Upgrade firmware on selected switches.</td></tr> <tr> <td>Discover Devices</td><td>Find switches on the local and remote networks, depending on the configuration on the Remote Subnets on page 38 page.</td></tr> </table>	Button	Description	Upload Firmware	Upgrade firmware on selected switches.	Discover Devices	Find switches on the local and remote networks, depending on the configuration on the Remote Subnets on page 38 page.
Button	Description						
Upload Firmware	Upgrade firmware on selected switches.						
Discover Devices	Find switches on the local and remote networks, depending on the configuration on the Remote Subnets on page 38 page.						
Device list	A table view of the settings of the switches that are discovered on the network with options that can be enabled or disabled for the switch.						

Columns of the Table View

The table view of the switches displays information and allows setting changes to the individual switches.

Column Title	Description		
Actions	Click on the icons to perform actions on an individual switch.		
	Icon	Button Name	Description
		Edit Switch Network Settings	Modify the name, IP address, Subnet Mask, and Default Gateway of the switch.
		Flash LED	Remotely trigger the LED of the switch for easy identification.
		Open WebHMI	Opens the WebHMI in a pop-up window. For more information, see the WebHMI Window section in this topic. Note:  When you connect directly to the Tunnel Manager using a monitor, the Open WebHMI button is not available.
Name	A customizable name of the switch.		
MAC Address	The MAC address of the switch.		
Firmware Version	The version of firmware installed on the switch.		
Address Type	Indicates network address type (DHCP or static) for the switch.		
IP Address	The IP address of the switch.		

Subnet Mask	The subnet mask of the switch.
Gateway	The gateway of the switch.
Source Network Interface	The Ethernet port the switch uses for connection.
State	Displays the state of the switch, which can be: • In Local Subnet • In Remote Subnet • In Remote Subnet Behind NAT • Waiting For DHCP • Misconfigured • Unknown

Add Hybrid Switch

If the switch list does not contain switches or contains misconfigured switches, you can discover and configure switches.

To add a hybrid switch:

1. Click **Discover Devices**.
2. Find the switch whose state is **Misconfigured** in the switch list and click the **Edit Switch Network Settings** icon next to it.

The **Edit Switch Network Settings** window pops up.

Edit Switch Network Settings

Name*

17/63

☐ Use DHCP

IP Address *

Subnet Mask *

Gateway

CANCEL SUBMIT


3. Disable the **Use DHCP** toggle.
4. Edit the **IP Address**, **Subnet Mask**, and **Gateway** so that the switch is on the correct local or remote subnet.
5. Click **Submit**.

The state of the switch in the switch list is now **In Local Subnet**.

Upload Firmware to Hybrid Switches

To upload firmware to one or more switches:

1. Select one or more switch from the switch list.
2. Click the **Upload Firmware** button.




3. Click **Browse** in the window that pops up.
4. Select the firmware file for upload.
5. Click **Submit**.

Accessing the WebHMI Window

The WebHMI window provides a connection to the WebHMI interface of the hybrid switch. When you connect directly to the Tunnel Manager using a monitor, the **Open WebHMI** button is not available.


To access the WebHMI, click the **Open WebHMI** button in the action column. The WebHMI opens in a pop-up window and prompts you to log in:

Hybrid Switch WebHMI of *...*



After logging in, you have access to the WebHMI interface of the switch:

Hybrid Switch WebHMI of [murr-gibb hybridswitches](#)



You can click **Reload HMI** to reset the WebHMI, this prompts you to log in again. To return to the Hybrid Switches page, click **Close**


Tunnel Setup


The Tunnel Setup app allows you to perform dynamic tests and 3D calibration on your device.

Trigger Alignment

Tunnel Diagnostic Suite

Go to the Tunnel Diagnostic Suite page to begin the setup wizard (Encoder Test, Trigger Signal Test, and Trigger Alignment).





Encoder Test

1. Bring the conveyor belt up to full production speed.



2. Use a tachometer to measure the belt speed.
3. Enter the **Nominal Belt Speed (meter/sec)**.


Encoder Check
This step checks that each device is receiving an encoder signal. Run a box through the tunnel to see results.

Nominal Belt Speed (meters/sec) *

1.02


Enter the nominal belt speed as determined on-site

4. Run a box through the tunnel. Any orientation is acceptable.



5. Verify that the encoder resolution matches your expected values.
For the Modular Vision Tunnel, the expected values are 0.653 mm/tick for the **Encoder Resolution** and the **Double Rate** is **ON**.

6. Verify that the **Calculated** speed matches the speed of your conveyor.



Encoder Types supported:

- **Fixed Speed:** The user specifies a single speed value through DMST or DMCC. All primary and secondary DataMan devices operate at this speed. The speed remains constant until a new value is provided and replaces the current setting.
- **Encoder**
- **Encoder Upscaling:** Increases the resolution of an incoming encoder signal by generating additional ticks to match a user-defined target resolution.
- **Measured Speed Dual Input:** Conveyor speed is calculated from two hardware trigger inputs. The user defines the distance between devices, and the primary DataMan device computes speed from the timing between rising edges. This speed value is shared with each of the secondary cameras through MRS messaging.
- **Single Input Primary**
- **Invalid**

Status Messages:

- Device communication failure
- Failed to calculate primary device speed.
- Received invalid encoder rate from device.
- Received invalid encoder resolution from device.
- Calculated speed differs by \${percentage}% from the specified belt speed


7. Click **Next Step**.

Trigger Alignment

The Trigger Alignment page lets you add and tune a trigger delay. Send the Dynamic Test box down the conveyor and through the tunnel to get a baseline for the trigger.

Note: The green section is specific to your project. Calculate the distance between the green section and the leading edge of the package (or where you want to trigger the delay)

1. Enter the **Offset** ($\pm$).
In this example, it would be +150.
2. Click **Set**.
3. Run packages through the tunnel to test the delay.
4. Update the **Offset**, if necessary.
5. Click **Save and Apply**.
6. Use the **Results** section to confirm the delay.



Dynamic Test

Dynamic Test is a diagnostic tool in the Tunnel Setup app. The test allows you to validate the proper functioning of your vision tunnel. During the initial commissioning of the vision tunnel, Cognex engineers use this test to validate that the vision tunnel functions properly. The engineers ensure that the test is run correctly, and they address all issues. It is a standard procedure for new installations.

While the test is typically part of the installation process, you can rerun the test any time to validate that the vision tunnel still functions correctly. If you run into an error during the test, refreshing the page can likely solve the error. If the error persists, contact Cognex technical support for further assistance.

Note: The Dynamic Test can have variations to fit various vision tunnel designs. This document describes one common type of Dynamic Test but you might have a different variation. Despite this, most of the guidance here is still relevant.



- In some variations, the test includes only a center position, without the left- and right-justified tests.
- Certain variations allow you to skip the encoder check or do not include it at all. This is more common when using a non-belted conveyor, such as a tilt tray, crossbelt, or bomb-bay system.

Prepare the Target Box for the Test

The Dynamic Test uses a special target box that you have to build specifically for the purpose of the test. The box and a sheet of adhesive 1D and 2D code labels comes with the tunnel delivery.

Prerequisites


Locate the box and the sheet of adhesive 1D and 2D code labels.

Procedure


To prepare the box for the test:

1. Build the box.
2. Adjust the height of the box to the maximum height supported by the vision tunnel.

3. Apply each code label within the corresponding rectangular outline on the box.
 - a. Match the first two characters of the code content and the two characters printed within the rectangle.



- b. Apply the label within the rectangle printed on the box.



Steps of the Dynamic Test

During the Dynamic Test, you physically run a target box, specifically built for the test, through the vision tunnel multiple times. The readers take images of the box as it runs through the vision tunnel on the conveyor belt. While the box runs on the conveyor belt, you navigate through the steps of the test in the user interface of your Tunnel Manager unit. The test validates the proper functioning of the vision tunnel and gives you visual feedback and detailed test results in the user interface for each step.

The test consists of six steps, which you can access through the Dynamic Test page of the Tunnel Setup app. The user interface guides you through the steps. The test is mostly automatic and it requires little user input.

The following image shows the steps of the test in order.

Step	Description
1	The Welcome on page 64 step prepares the readers on the vision tunnel for the test.
2	Trigger Check on page 65 is an optional step, which validates whether the box passing through the vision tunnel correctly triggers the readers.
3	The Encoder Check on page 66 step validates whether each reader is receiving an encoder signal.


4	The Left-Justified Test on page 66 step validates that the readers properly read barcodes if the box is running on the left side of the conveyor belt.
5	The Right-Justified Test step is similar to the Left-Justified Test , but the box is running on the right side of the conveyor belt.
6	The Restore & Report on page 70 step restores the readers to their original settings and allows you to generate and download a report of the test results.

Welcome

This step prepares the readers on the vision tunnel for the test as follows:

1. Runs device discovery to discover the Multi-Reader Sync (MRS) group of the vision tunnel.
2. Makes backups of the reader settings.
3. Modifies the reader settings for the purposes of the test.

Note: At the end of the test, the app restores the original settings of your readers and reboots them. You can manually download the backups, but it is not necessary.




Number	Description
1	The progress bar gives you information about the status of the current step of the test.
2	Click the download button to manually download the backups.

3	Click the eye icon to access detailed information about the readers in the MRS group.
4	Click Cancel Test if you want to cancel the test for any reason. If you cancel the test, the app automatically restores the original settings of your reader.
5	Click Start to proceed to the next step.

Trigger Check

The **Trigger Check** step helps you to validate whether the box passing through the vision tunnel correctly triggers the readers. This is an optional step, which means that you can skip this step and still complete the test. If there is a problem with triggering, however, the test might fail because of it.

Vision tunnels typically use a photoeye to control the triggering. The photoeye, also known as a photoelectric sensor, detects the presence or absence of boxes using a light beam. When a box interrupts the light beam, the photoeye senses this change and sends out a signal that turns the trigger on. The test validates whether the trigger signal and the trigger delay settings are correct.




Number	Description
1	The green circle on the left side of the user interface shows that the trigger is currently on. If the circle is grey, the trigger is currently off. As the box passes through the vision tunnel, validate that the trigger turns on and off at the correct time.
2	The Trigger Check step shows instructions for fixing common problems with the photoeye. The instructions appear on the right side of the user interface.

Encoder Check

In the **Encoder Check** step, first specify the normal speed of your conveyor belt using the input field. Then run the target box through the vision tunnel to validate that each reader is receiving an encoder signal.

After the box passes through the vision tunnel, the results appear in the user interface. Each line represents a reader and provides the following details:



Element	Description
Device Name	The name of the reader.
Encoder Resolution	This is a setting of the reader.
Calculated Belt Speed	The calculated belt speed is computed based on encoder pulses received by the reader, the encoder resolution, and the trigger time. Note: Inconsistent calculated speed results can indicate physical (electrical wiring, mechanical coupling) problems or configuration errors.
Double Rate	This is a setting of the reader.
Pass	A green check mark or a red X, indicating whether the test passed or failed.
Status Message	Provides additional information about the reason why the test failed.

Left-Justified Test

The **Left-Justified Test** step involves running the target box through the vision tunnel. You place the box on the left side of the conveyor belt with the front of the box facing downstream. The test validates whether the readers can read the various codes on the target box in this position.

After the target box passes through the vision tunnel, the test results appear in the left side of the user interface, with one row for each test run. If you select a row, more detailed test results appear in the right side of the user interface. A green check mark indicates that the test passed, while a red **X** indicates that the test failed.

- At belt speeds of less than 300 fpm, every code needs to be read at least once.
- At faster belt speeds, each code needs to be read by the specific banks (group of readers on the vision tunnel).

Note: The **Right-Justified Test** step is similar to the **Left-Justified Test**, but the box is placed on the right side of the conveyor belt instead of the left side.

COGNEX | Ei Tunnel Manager
License Expires: Feb 11, 2026, 7:00:00 PM
cognex_engineer

Home • Tunnel Setup • **Dynamic Test**

Welcome Trigger Check Optional Encoder Check Left-Justified Test Right-Justified Test Restore & Report

FIRST TIME HERE? CLICK TO LEARN MORE. CLEAR TEST RESULTS

Actions	Trigger Index	Test Result	Belt Speed
	42	Fail	0.51 (meter/sec)
	43	Fail	0.51 (meter/sec)

Position Reference	Code Type	Side	Result	Lead Left	Lead Right	Lead Top	Trail Left	Trail Right	Trail Top	Devices
A1-FRONT	1D	Front	Fail	—	—	×	—	—	—	
A2-FRONT	1D	Front	Fail	×	—	—	—	—	—	
A3-FRONT	1D	Front	Fail	—	—	×	—	—	—	
A4-FRONT	1D	Front	Fail	×	—	—	—	—	—	
B1-TOP	1D	Top	Fail	—	—	×	—	—	×	
C1-LEFT	1D	Left	Fail	×	—	—	×	—	—	
E1-REAR	1D	Rear	Fail	—	—	—	—	—	×	
E2-REAR	1D	Rear	Fail	—	—	—	×	—	—	


- Bank not expected to read barcode
 ✓ Bank expected to read barcode and did successfully
 ✗ Bank expected to read barcode but did not

Items per page: 25 1 ~ 2 of 10 < > >>

PREVIOUS STEP CANCEL TEST NEXT STEP

✓ Barcode Results Images

1	In this section, the results of each test run appear after the box passes through the vision tunnel. • Actions column: • Click the download icon to download detailed information about the barcodes read by the readers. • Click the information button to see the same details in a pop-up window. • Trigger Index: The index number assigned by the reader associated with the test run. • Test Result: Can be Pass or Fail. • Belt Speed: The speed of the conveyor belt at the time of the read. To get more details about a test run in the right side of the user interface, click one of the rows. To clear the results in this section, click the Clear Test Results button.
---	--

2	This section provides more detailed information about the selected test result. Using this information, you can determine which specific tests passed or failed. The details only appear in this section after you have selected one of the tests in the previous section. The image shows the Barcode Results tab, which displays a table of the barcodes used in the test and the readers expected to read them. The Barcode Results tab provides the following information: • Position Reference: The area on the box where the specific barcode is applied. • Code Type: The type of the barcode, such as 1D or 2D. • Side: The side of the target box where the specific barcode is applied. • Result: Can be Pass or Fail. This indicates whether the bank was able to read the barcode as expected. • From Lead Left to Trail Top: These refer to the banks of your vision tunnel. Each bank is expected to read a specific barcode on the target box. • Devices: Click the icons in this column to access more details about your readers in a pop-up window. Not all banks are expected to read every barcode on the box. • A blank (-) appears in the table if a bank was not supposed to read a specific barcode. • A green check mark indicates that the bank was expected to read the barcode and it was a good read. • A red X indicates that the bank was expected to read the barcode but it was a no-read. If you click on a specific test in the Barcode Results tab, you are taken to the corresponding image in the Images tab. 
3	Click these buttons to switch between the Barcode Results view and the Images tabs.

Restore & Report

The **Restore & Report** step automatically restores the readers to the original settings and reboots them to ensure that all settings are effective. After the reboot, the test summary appears in the user interface. You can download the report as a *.pdf*.

The summary includes the number of attempts, indicating how many times you ran the target box through the vision tunnel, and the number of failed attempts. Ideally, the summary should show that the box ran through the vision tunnel a few times and the test passes every time.

Test Mode	Status	Total Attempts	Successful Attempts	Unsuccessful Attempts	Device Summary
Left	Fail	8	0	8	View Details
Right	Fail	3	0	3	View Details
Encoder	Pass	17	11	6	—

Number	Description
1	The Restore & Report section indicates the status of reader restoration and reboots. After the readers reboot, the results appear in the Test Summary section.

2	The Test Summary section provides a quick overview of the mandatory tests and their results. • Test Mode: Refers to the test, such as Left-Justified Test. • Status: Can be Pass or Fail. • Attempts: Refers to the number of times you ran the target box through the vision tunnel. The Test Summary lists the total number of attempts, and the number of successful and unsuccessful attempts. Click the buttons in the Device Summary column to access additional information about how many codes the different readers read. Right Justified Test Device Summary <table> <thead> <tr> <th>Name ↑</th><th>Read Count ↑</th></tr> </thead> <tbody> <tr> <td>2VD-Parcel-trail-top</td><td>7</td></tr> <tr> <td>2VD-Parcel-trail-right</td><td>7</td></tr> <tr> <td>2VD-Parcel-trail-left</td><td>9</td></tr> <tr> <td>2VD-Parcel-lead-top-primary</td><td>12</td></tr> <tr> <td>2VD-Parcel-lead-left</td><td>13</td></tr> <tr> <td>2VD-Parcel-lead-right</td><td>17</td></tr> </tbody> </table> CLOSE	Name ↑	Read Count ↑	2VD-Parcel-trail-top	7	2VD-Parcel-trail-right	7	2VD-Parcel-trail-left	9	2VD-Parcel-lead-top-primary	12	2VD-Parcel-lead-left	13	2VD-Parcel-lead-right	17
Name ↑	Read Count ↑														
2VD-Parcel-trail-top	7														
2VD-Parcel-trail-right	7														
2VD-Parcel-trail-left	9														
2VD-Parcel-lead-top-primary	12														
2VD-Parcel-lead-left	13														
2VD-Parcel-lead-right	17														
3	Click the Re-Run Device Restore and Reboot button to re-attempt failed reader restorations or reboots.														
4	Click the Generate Report button to download the test report as <i>.pdf</i> . For more information, see Generate Dynamic Test Report on page 74 .														
5	Click the Finish button to return to the Tunnel Manager home page.														

Run a Dynamic Test

The [Dynamic Test on page 62](#) involves running the target box through the vision tunnel multiple times, allowing the readers to take images and validate the proper functioning of the vision tunnel. The test consists of six steps, which are mostly automated and require minimal user input.

If you have to abort the test at any time, you can click on the **Cancel** button at the bottom of the page in each step.

Prerequisites

Before you start, ensure that the following prerequisites are met:

- Learn about the test and its various steps by reading [Steps of the Dynamic Test on page 63](#)
- [Prepare the Target Box for the Test on page 62](#)
- Add weight to the box to ensure it stays on the conveyor belt. Always give the box enough distance before the vision tunnel, so it moves through at full speed.

Procedure

To run the dynamic test:

1. Open the **Apps** menu and select the Dynamic Test page of the Tunnel Setup app. You are now at the [Welcome on page 64](#) step.
 - a. Wait until the app finishes preparing your readers.
 - b. To continue to the [Trigger Check on page 65](#) step, click **Start**.
2. Option: In the **Trigger Check** step, validate that the readers are triggered correctly.
 - a. To validate the trigger settings, run the box through the vision tunnel, and validate that the trigger turns on and off at the correct time.
 - b. If the check fails, follow the instructions on the right side of the user interface to fix common problems with the photoeye.
 - c. To continue to the [Encoder Check on page 66](#) step, click **Next Step**.
3. In the **Encoder Check** step, first set the **Nominal Belt Speed** to the actual speed of your conveyor belt.
 - a. Place the box on the conveyor belt.
 - b. Bring your conveyor belt up to full production speed and run the box through the vision tunnel.
 - c. If any of the readers fail the check:
 - i. Review and note the messages in the status message column.
 - ii. If errors are returned on subsequent runs, click **Cancel Test**, which restores the readers to the original settings.
 - iii. Fix the encoder errors, for example using DataMan Setup Tool then restart the Dynamic Test.
 - d. If every reader passes the test, click **Next Step** to continue to the [Left-Justified Test on page 66](#) step.

4. In the **Left-Justified Test** step:


- a. Place the box on the left side of the conveyor belt with the front side of the box facing downstream.



- b. Run the box through the vision tunnel. If possible, run the box at both slower (less than or equal to 300 ft/min or 1.52 m/s) and faster belt speed (greater than 300 ft/min or 1.52 m/s).
- c. As the box runs through the vision tunnel, the test results appear in the user interface.
- If any **Xs** appear, it indicates that a test failed.
 - To review the no-read image, click on the row that has an **X**. Reviewing the image can tell you why the reader could not read the barcode.
 - You might have to run the box multiple times through the vision tunnel to pass.
 - If all of the rows have green check marks, it means that the readers can read the barcodes correctly.
- d. To continue to the **Right-Justified Test** step, click **Next Step**.

5. In the **Right-Justified Test** step:

- a. Place the box on the right side of the conveyor belt with the front side of the box facing downstream. Otherwise, this step has the same workflow as the previous step.



- b. Run the box through the vision tunnel the same as in the previous step, then review the results.
- c. If all of the rows have green check marks, click **Next Step** and the **Complete Dynamic Test** pop-up appears.

6. To complete the test and continue to the next step, click **Confirm**.

After the Procedure

- The [Restore & Report on page 70](#) step automatically restores your readers to their original settings.
- Option: Generate and download a report of the test results. For more information, see [Generate Dynamic Test Report on page 74](#).

Generate Dynamic Test Report

In the **Restore & Report** step of the [Dynamic Test on page 62](#), you can download the test report in .pdf format.

To generate and download the test report:

1. In the **Restore & Report** step of the Dynamic Test, click **Download Report**.
2. Fill in the details in the pop-up window.
3. Click **Generate Report**, which automatically downloads the file into the download directory on your computer.

3D Field Calibration

The 3D Field Calibration page allows you to calibrate devices which consists of five different steps allowing for features such as barcode assignment.

Before getting started:

- Complete the **Dynamic Test** page steps.
- Make sure that the dimensioner collects the data.
- Disconnect DataMan Bottom Side Line Scan and Image-Only readers.

Home » Tunnel Setup » 3D Field Calibration

1

Setup

2

Pre-Calibration Validation

3

Data Collection

4

Calibration

5

Restore & Push Calibrations

Calibration Parameters

All parameters are required. ^

☐ Static Calibration Mode

Setting the calibration interval

- When running a calibration, the app will update the intervals for all selected devices and revert them in the final step of this app
- The calibration interval will be automatically calculated based on the production and calibration belt speeds
- For best results, perform the calibration at a belt speed that does not exceed **250 feet/minute (1.25 meter/second)**
- The calibration belt speed should not exceed the production belt speed
- To set the calibration interval manually, check the **Set Calibration Interval Manually** box below and enter the desired camera interval

☐ Set Calibration Interval Manually

Production Belt Speed *

feet/minute

Calibration Belt Speed *

feet/minute

The speed of the belt when run normally.

The speed of the belt when performing a calibration.

Vision Service Hostname

☒ This EI Box ()

☐ Tunnel RTM PC ()

☐ Other Server

This EI Box for the Vision Service Hostname and LGM-CALIBBOX-556 for the Calibration Box Type are by default selected values.

1. In the first step, start with setting the calibration interval. Enter conveyor parameters which are **Production Belt Speed** and **Calibration Belt Speed** and select readers:

Note: Consider the following aspects when setting the calibration interval:

- When running a calibration, the app updates the intervals for all selected devices and reverts them in the final step.
- The calibration interval is automatically calculated based on the production and calibration belt speeds.
- For best results, perform the calibration at a belt speed that does not exceed 250 feet/minute (1.25 meter/second).
- The calibration belt speed must not exceed the production belt speed.
- To set the calibration interval manually, check the **Set Calibration Interval Manually** box below and enter the desired camera interval.

Select devices to calibrate:

Search

Discover Devices

☒	Primary	Name	Type	MAC Address	Firmware Version	IP Address	Group
☒							2VDMVT580
☒							2VDMVT580
☒							2VDMVT580
☒							2VDMVT580
☒							2VDMVT580
☒							2VDMVT580
☐	☒						2VDMVT580
☒							2VDMVT580
☒							2VDMVT580
☒							2VDMVT580
☒							2VDMVT580
☒							2VDMVT580
☒							2VDMVT580

Next Step

Click on **Next Step** to switch to the **Pre-Calibration Validation** step.

2. In the **Pre-Calibration Validation** step, validate the test parameters. After the validation is complete, the *All validations successful.* message appears. Click on **Next Step**.

Pre-Calibration Validation

These validations will help determine if there are any issues with the tunnel/devices before data collection occurs.

All validations successful.

Validate entered parameters

New Camera Interval Calculated

Calibration Vision Service Set

Factory Calibrations available for all selected devices

Backups created for all selected devices

Expand here to review all devices and their new camera interval that will be set during data collection.

Download All Factory Calibrations

Download All Device Backups

Re-Run All Validations


Note:

All the devices being calibrated will require a configuration change. Remember to navigate to the end of the wizard and restore devices on the restore & push calibrations page before leaving this app.

Next Step

Note: If you receive an error that you cannot take backups and expanding the drop down shows an error about dirty configurations, either reload the backups taken from a previous run or re-run *Tunnel Commissioning* wizard.

3. In the **Data Collection** step, the calibration triggers are captured.



- Make sure that the calibration box is oriented correctly with the front side facing downstream on the conveyor and run the box through the tunnel at the calibration speed you set in the previous step.

Note: If the conveyor is wider than the calibration box by 5 inches, you have to run the box through at different positions on the belt:

- The left side of the belt.
- The right side of the belt.
- The center of the belt.

If the conveyor is narrow, place the box at the center of the belt and run it through twice.

- Select the best triggers from the triggers list and click on **Next Step** to calibrate.

	Date & Time	Trigger index	Length	Width	Height	Angle	Image Count	
☒	Jul 21, 2022, 1:13:42 PM	26					214	2VDMvT_LeadLeft_1-Top
☐	Jul 21, 2022, 1:14:05 PM	27	515	514	611	-1	167	2VDMvT_LeadLeft_2
☐	Jul 21, 2022, 1:14:28 PM	28	514	510	611	-4	174	2VDMvT_LeadLeft_3-Bottom
☐	Jul 21, 2022, 1:14:51 PM	29	516	511	612	1	167	2VDMvT_LeadRight_1-Top
☐	Jul 21, 2022, 1:17:55 PM	30	514	513	611	-5	174	2VDMvT_LeadRight_2
☒	Jul 21, 2022, 1:18:18 PM	31	513	513	611	2	174	2VDMvT_LeadRight_3-Bottom
Total images for selected triggers:							348	2VDMvT_LeadTop_1-Left
								2VDMvT_LeadTop_2
								2VDMvT_LeadTop_3
								2VDMvT_LeadTop_4-Right
								2VDMvT_TrailLeft_1-Top
								2VDMvT_TrailLeft_2
								2VDMvT_TrailLeft_3-Bottom
								2VDMvT_TrailRight_1-Top
								2VDMvT_TrailRight_2
								2VDMvT_TrailRight_3-Bottom
								2VDMvT_TrailTop_1-Left
								2VDMvT_TrailTop_2
								2VDMvT_TrailTop_3
								2VDMvT_TrailTop_4-Right

- The **Calibration** step appears. Click on **Re-run Failed Devices** to re-run the the failed device calibrations where the calibration process begins automatically and the calibration for each device takes place.

One or more calibration errors occurred. Expand here to learn more.

Re-run Failed Devices Re-run All Devices

Name	Status	Trigger Used	Image Used	Arrival Time	Max. Error (mm)	Side	Max. Error (mm)	Side
2VDMVT_Lead-Left_3-Bottom	Complete	28	3	7/21/22, 1:16 PM	13.784	Left	16.618	Front
2VDMVT_Lead-Left_1-Top	Complete	28	3	7/21/22, 1:16 PM	9.96	Left	12.946	Front
2VDMVT_Lead-Left_2	Complete	28	3	7/21/22, 1:16 PM	11.612	Left	15.436	Front
2VDMVT_Lead-Right_2	Complete	28	4	7/21/22, 1:16 PM	7.864	Right	---	---
2VDMVT_Lead-Right_1-Top	Complete	28	4	7/21/22, 1:16 PM	7.835	Right	---	---
2VDMVT_Lead-Right_3-Bottom	Complete	28	4	7/21/22, 1:16 PM	7.969	Right	---	---
2VDMVT_Lead-Top_1-Left	Code validation failure	0	0	7/21/22, 1:16 PM	---	---	---	---
2VDMVT_Lead-Top_2	Complete	28	1	7/21/22, 1:16 PM	8.259	Top	12.507	Front
2VDMVT_Lead-Top_3	Complete	28	1	7/21/22, 1:16 PM	8.914	Top	12.25	Front
2VDMVT_Lead-Top_4-Right	Complete	28	1	7/21/22, 1:16 PM	9.277	Top	12.067	Front
2VDMVT_Trail-Left_1-Top	Complete	28	3	7/21/22, 1:16 PM	5.366	Left	---	---
2VDMVT_Trail-Left_2	Complete	28	3	7/21/22, 1:16 PM	5.665	Left	---	---
2VDMVT_Trail-Left_3-Bottom	Complete	28	3	7/21/22, 1:16 PM	5.183	Left	---	---
2VDMVT_Trail-Right_1-Top	Complete	28	6	7/21/22, 1:16 PM	9.056	Right	11.298	Back
2VDMVT_Trail-Right_2	Complete	28	4	7/21/22, 1:17 PM	7.571	Right	14.667	Back

NO IMAGE

If necessary, after all the calibration is successfully complete, click on **Next Step**.

Trigger Info						Plane 1		Plane 2	
Name	Status	Trigger Used	Image Used	Arrival Time		Max. Error (mm)	Side	Max. Error (mm)	Side
2VDMVT_Lead-Left_3-Bottom	Complete	28	3	7/21/22, 1:16 PM		13.784	Left	16.618	Front
2VDMVT_Lead-Left_1-Top	Complete	28	3	7/21/22, 1:16 PM		9.96	Left	12.946	Front
2VDMVT_Lead-Left_2	Complete	28	3	7/21/22, 1:16 PM		11.612	Left	15.436	Front
2VDMVT_Lead-Top_2	Complete	28	1	7/21/22, 1:16 PM		8.259	Top	12.507	Front
2VDMVT_Lead-Top_3	Complete	28	1	7/21/22, 1:16 PM		8.914	Top	12.25	Front
2VDMVT_Lead-Top_4-Right	Complete	28	1	7/21/22, 1:16 PM		9.277	Top	12.067	Front
2VDMVT_Trail-Right_1-Top	Complete	28	6	7/21/22, 1:16 PM		9.056	Right	11.298	Back
2VDMVT_Trail-Right_2	Complete	28	4	7/21/22, 1:17 PM		7.571	Right	14.667	Back
2VDMVT_Trail-Right_3-Bottom	Complete	28	5	7/21/22, 1:17 PM		10.095	Right	10.859	Back
2VDMVT_Trail-Top_2	Complete	28	8	7/21/22, 1:17 PM		6.635	Top	4.663	Back
2VDMVT_Trail-Top_3	Complete	28	8	7/21/22, 1:17 PM		4.799	Top	9.083	Back
2VDMVT_Trail-Top_4-Right	Complete	28	7	7/21/22, 1:17 PM		4.01	Top	10.043	Back

The error value columns determine if the test result is pass or fail. It is expected that error values to be higher in the right column due to higher perspective on those faces:

- An optimal error value is less than 25 mm.
- An acceptable error value is between 25 and 50 mm.
- Any values over 50 mm are not accepted.

If you receive unacceptable values, you can return to the previous step and run another box for the area that failed by clicking on **Re-run Failed Devices** or **Re-run All Devices**.

The **Complete Calibration** pop-up appears. To complete the calibration, click on **Confirm**.

- The final step of **Restore & Push Calibrations** restores the devices to their original settings and automatically load calibration data to all devices. Once this process is complete, you can close the page.

Home » Archiver » Download Center					
Actions	Title	State	Queued At	Updated At	Files Count
	No Read Images 1:50PM-2:58PM	Completed	2/3/22, 8:57 PM	2/3/22, 8:57 PM	1
	Image + Trigger 1/20 10AM-1PM	Completed	1/20/22, 7:21 PM	1/20/22, 7:21 PM	1
	Image+trigger Jan4 1037-1237	Completed	1/5/22, 4:37 PM	1/5/22, 4:37 PM	1
Items per page: 10 ▾ 11 – 13 of 13 < < > > 					

Column	Description
State	The status of the archive. Displays one of the following states: • Idle • Collecting Data • Running • Completed • Canceled
Queued At	The time when download starts.
Updated At	The time of the last status update or when the download finishes.
Files Count	The total number of ZIP files in the archive.

The archive file has the following contents:

- One or more folders that contain the images. Unit organizes the folders by date, and each folder name has the format of YYYYMMDD.

The images in each folder follow a naming convention based on whether they originate from a standalone reader or from an MRS group:

- For standalone readers, the image name contains the device name, the trigger index, the image index, and the time stamp, in this order and separated by underscores. For example, *ST_1_DM470_566898_0_20211221T190905.jpg*.
- For readers in an MRS group, the image name contains the group name, the device name, the trigger index, the image index, the time stamp, and four random characters to prevent name collision, in this order and separated by underscores. For example, *Tunnel1_ST_3_DM470_1126_0_20220204T141531_6802.jpg*.

- One CSV file that contains trigger data. The name of the file contains the MRS group name when applicable, and the name of the primary device, for example, *Tunnel_1_ST1_DM470.csv*. The file organizes data into the following columns:
 - time: The time stamp of the image.
 - deviceMacAddress: The MAC address of the device.
 - group: The MRS group name.
 - type: The trigger type
 - triggerIndex: The index of the trigger.
 - goodRead: TRUE indicates a Good-read, FALSE indicates a No-read.
 - readString: The read string. For an MRS group, this column contains the overall result string.

Note: For an MRS group, the image folder(s) contain images from all readers, and the CSV file contains trigger data from the primary reader.

Extract a Single Archive File

1. In the **Download Center**, click on the row of the archive you want to download to see its contents.

Actions	Title	State	Queued At	Updated At	Files Count
	4/8 10:47-10:50	Completed	4/8/22, 4:52 PM	4/8/22, 4:52 PM	1
<i>Download only one file at a time. Simultaneous downloads severely impact device performance. Download all partial zip archives (if created) before opening the '.zip' file. You may need a third-party utility to automatically combine partial archives.</i>  ei-data-export-20220408_1452-f61cd806-3697-4d56-a9c8-1686cc5feec2.zip					

2. Click on the download icon to download the ZIP file.

Actions	Title	State	Queued At	Updated At	Files Count
	4/8 10:47-10:50	Completed	4/8/22, 4:52 PM	4/8/22, 4:52 PM	1
<i>Download only one file at a time. Simultaneous downloads severely impact device performance. Download all partial zip archives (if created) before opening the '.zip' file. You may need a third-party utility to automatically combine partial archives.</i>  ei-data-export-20220408_1452-f61cd806-3697-4d56-a9c8-1686cc5feec2.zip					

The default download location depends on the browser you are using.

3. Navigate to the folder on your computer that contains your downloaded file, and extract the contents of the file.

Extract a Multi-Archive File

When the size of the archive exceeds 1 GB, Unit creates multiple partial ZIP files from that archive.

Note: As the built-in Windows file extractor cannot handle partial ZIP files, you need to install 7Zip or a similar program to manage them.

1. In the **Download Center**, click on the row of the archive that you want to download to see its contents.

Actions	Title	State	Queued At	Updated At	Files Count
	2/13-2/14 Images + Triggers	Completed	2/14/22, 6:16 PM	2/14/22, 6:21 PM	6
<i>Download only one file at a time. Simultaneous downloads severely impact device performance. Download all partial zip archives (if created) before opening the '.zip' file. You may need a third-party utility to automatically combine partial archives.</i> <u>↓</u> ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.z01 <u>↓</u> ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.z02 <u>↓</u> ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.z03 <u>↓</u> ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.z04 <u>↓</u> ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.z05 <u>↓</u> ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.zip					

- Download each ZIP one at the time file by clicking on the download icon, and store them in the same location.

Actions	Title	State	Queued At	Updated At	Files Count
	2/13-2/14 Images + Triggers	Completed	2/14/22, 6:16 PM	2/14/22, 6:21 PM	6
<i>Download only one file at a time. Simultaneous downloads severely impact device performance. Download all partial zip archives (if created) before opening the '.zip' file. You may need a third-party utility to automatically combine partial archives.</i> ↓ ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.z01 ↓ ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.z02 ↓ ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.z03 ↓ ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.z04 ↓ ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.z05 ↓ ei-data-export-20220214_1716-4e4d06cf-c77f-4054-baff-e2940a9c920f.zip					

The default download location depends on the browser you are using.

- Navigate to the folder on your computer that contains all the downloaded partial ZIP files.
- Right-click on the file with ZIP extension.
- Click on the ZIP file extractor.
- Click on **Extract to** to merge all partial files.

Settings

The Settings app allows you to configure your device, enable or disable the DataMan WebHMI pages of your connected devices, and upgrade your device firmware.

Edge Intelligence

The Edge Intelligence page shows the network configuration, and allows you to edit and save the network settings of the EI Tunnel Manager device.

The screenshot displays the COGNEX EI Tunnel Manager web interface. The top navigation bar includes 'Home', 'Settings', and 'Edge Intelligence'. The main content area is divided into several sections:

- Network Configuration:** Contains fields for Hostname, Default Gateway, and Network Interfaces (ETH3 and ETH2). Each interface has checkboxes for 'Enable network interface' and 'Enable DHCP', along with fields for IP Address, Subnet Mask, and DNS Server.
- Clear Databases:** A button labeled 'CLEAR ALL'.
- Reboot Edge Intelligence:** A button labeled 'REBOOT'.
- Set Date & Time using Network Time Protocol (NTP) server:** A section for synchronizing the system time with an NTP server, including a 'SAVE' button.
- Manual Date & Time:** A section for manually setting the date and time, including a 'SAVE' button.
- Edge Intelligence as local NTP server:** A section showing the status of the local NTP server, with a 'Running' indicator and a 'SAVE' button.

Section	Item	Description
Network Configuration	Hostname	The hostname of the EI Tunnel Manager.
	Default Gateway	The Gateway of the EI Tunnel Manager.
	Network Interfaces	Configuration options for each of the Ethernet ports (1-3). For each Ethernet port: • Enable or disable the interface. • Enable using the DHCP protocol instead of static protocols. • See if the Ethernet cable is connected by checking the green and red icons next to the name of the interfaces.
	IP Address	The IP Address of the EI Tunnel Manager.
	Subnet Mask	The Subnet Mask of the EI Tunnel Manager.
	DNS Server	The DNS server of the EI Tunnel Manager.
	Network Address Translation (NAT)	Toggle the switch to enable the NAT. See Setting up the NAT on page 86 .

COGNEX EI Tunnel Manager		
Home Settings Edge Intelligence License Expires: Oct 6 2023 2:00:00 AM admin		
Network Configuration Hostmaster* 192.168.1.100 Default Gateway 192.168.1.1 Network Interfaces ETH3 Enable network interface Enable DHCP IP Address* 192.168.1.100 Subnet Mask* 255.255.255.0 DNS Server 192.168.1.1 ETH2 Enable network interface Enable DHCP IP Address* 192.168.1.100 Subnet Mask* 255.255.255.0 DNS Server 192.168.1.1	Clear Databases CLEAR ALL Reboot Edge Intelligence REBOOT	Set Date & Time using Network Time Protocol (NTP) server Synchronize the system time of Edge Intelligence with an NTP server. Address* + SAVE Manual Date & Time Manually setting date and time overrides NTP server based date and time. Set Date & Time Manually Date & Time* Time Zone* SAVE Edge Intelligence as local NTP server Synchronize the date and time of your devices with the system time of Edge Intelligence. Running OFF ON
Section	Item	Description
Clear Databases		Clear the device lists, data, and images from the Unit, and create a new state. Note: The Clear database option is only available with Admin level clearance.
Reboot Edge Intelligence		Reboot the EI Tunnel Manager device.
Set Date & Time using Network Time Protocol (NTP) server		Add an NTP server to set the system time: - Click +. Set Date & Time using Network Time Protocol (NTP) server Synchronize the system time of Edge Intelligence with an NTP server. Address* + SAVE - Enter the IP address of the NTP Server. - Click Save. Note: You need to log out and log back in after saving the system time.
Manual Date & Time		Toggle Set Date & Time Manually to specify the date, time and the time zone. Note: You need to log out and log back in after saving the system time.

COGNEX

EI Tunnel Manager

License Expires: Oct 6 2028 2:00:00 AM

admin

Home

Settings

Edge Intelligence

Network Configuration

Hostmaster *

192.168.1.100

Default Gateway

Set the default gateway and pairs it with a matching static interface. Disables reserving a default gatew...

Network Interfaces

ETH3

Enable network interface

Enable DHCP

IP Address *

192.168.1.100

Subnet Mask *

255.255.255.0

DNS Server

192.168.1.1

ETH2

Enable network interface

Enable DHCP

IP Address *

192.168.1.100

Subnet Mask *

255.255.255.0

DNS Server

Clear Databases

CLEAR ALL

Reboot Edge Intelligence

REBOOT

Set Date & Time using Network Time Protocol (NTP) server

Synchronize the system time of Edge Intelligence with an NTP server

Address *

192.168.1.100

+

SAVE

Manual Date & Time

Manually setting date and time overrides NTP server based date and time.

Set Date & Time Manually

Date & Time *

10/6/2028, 10:00:00 AM

Time Zone *

Europe/Brussels

SAVE

Edge Intelligence as local NTP server

Synchronize the date and time of your devices with the system time of Edge Intelligence.

Running

OFF

ON

Section	Item	Description
Edge Intelligence as local NTP server		Toggle the switch to synchronize the date and time of your devices with the EI Tunnel Manager device.

Setting up the NAT

Network address translation (NAT) remaps IP address spaces into other IP address spaces by modifying network address information in the IP header of information packets. Scroll down for the NAT option.

To set up the NAT:

1. Make sure that the Default Gateway of the DataMan readers is the IP address of the TM network port they are connected to.
2. Set the switch to enable NAT Settings.

Network Address Translation (NAT)

Enable

External IP *

Internal IP *

×


+

3. Click the + symbol to Add New Mapping.
4. Set the reader IP address as the Internal IP.
5. For the External IP, enter an available IP address you want to map to the reader.
6. Click Save.

NTP Server Function


The Unit device can act as a Network Time Protocol (NTP) server. NTP is an internet protocol for synchronizing clocks on a network to within a few milliseconds of universal coordinated time (UTC).

In the **Settings** menu, click on the **Edge Device** tab. Set the switch to **On** to enable NTP server and synchronize the date and time of your devices with the system time of Unit.



DataMan WebHMI

The DataMan WebHMI page allows you to enable or disable the pages displayed on the individual device DataMan WebHMI interfaces that are accessible through the DataMan page of the Device Management app.



Select the device for which you want to change the displayed DataMan WebHMI pages from the device list on the left side of the page. The device information for the selected device appears under the list.

If the selected device is password protected, provide the password in the **Device Password** section of the page, otherwise you will not be able to save your changes.

You can enable or disable the following DataMan WebHMI pages for the selected device in the **Enabled Pages** section of the page:

- Actions
- Match String
- Settings


Click **Save** at the top of the page to apply your changes.

Firmware Upgrade


The Firmware Upgrade page allows you to upload new firmware packages for upgrading device firmware.

If the EI Tunnel Manager unit is on version 1.2.1 or later, you can upgrade the EI Tunnel Manager firmware through the user interface by performing the following steps:


1. Make sure you are on the same network as EI Tunnel Manager Internal Ethernet port. The IP address of the Internal Ethernet port is in the form of 192.168.1.X.
2. Connect to the EI Tunnel Manager Internal Ethernet port..
3. Open a web browser and type the IP address of the EI Tunnel Manager unit into the address bar. The default static IP address is 191.168.1.100. The EI Tunnel Manager user interface opens up.
4. Navigate to **Settings > Firmware Upgrade** in the EI Tunnel Manager navigation pane.



- Click on the **Browse** button and select the latest firmware version available for download on the Cognex website. The firmware is a *.pkg* format file.




- Click on the **Upgrade** button and wait for upgrade to complete.



HTTPS

HTTPS connection provides secure browser access to the EI Tunnel Manager interface. HTTPS also enables the [Single Sign-On on page 93](#) feature.

HTTPS connection is enabled only if the Authority link in the [Identity Provider Configuration](#) uses the same HTTPS protocol. In this case, HTTP is disabled on the Identity Provider, and you are automatically redirected to HTTPS, which enforces a secure channel for authentication.



1. Click **Upload Certificate** to add a .pem file.
2. Click **Submit**.
3. Turn on the **Enable HTTPS** toggle. You are automatically logged out.
4. Log in again to the EI Tunnel Manager, either with the normal login or with Single Sign-On.

Username*

Password*

👁

Login

OR

Sign in with SSO

User Management

The Roles page allows an admin level user to create roles and define which EI features those roles have access to. The User page allows an admin level user to create users and assign them roles.

Users

The Users page allows creating new users and assigning Roles to them.

Item		Description
Create User		Brings up the pop-up window to add a new user.
User management table		Table listing the existing users, the assigned Username and roles.

The **Create User** button is available on the top ribbon. Set the following options for each user:

Create User

Username *

Role *

Password *

Confirm Password *

Cancel

Create

Item	Description
Username	The username of the user for logging in.
Role	The role of the user: • Admin • Engineer • Operator
Password	The password of the user for logging in.
Confirm Password	Reenter the password.

Note: A user with admin rights can also edit the same options for each user by clicking the **Edit** button.

The Users page lists the existing users. Edit or delete an existing user by clicking the appropriate icon.

Actions










Icon	Description
	Click Edit to edit the settings of a user.
	Click Delete to delete a user.

Roles

This page allows admin level users to create new roles and grant access to certain applications.

[Home](#) » [User Management](#) » [Roles](#)

Admin 

Engineer 

Operator 

+

Role Name *

Admin

☐ All application claims

☐ Access to ADWS app
The user has access to the ADWS application.

☒ Access to Customer Acceptance Test App
The user has access to the Customer Acceptance Test application.

☐ Access to Ignore Codes app
The user has access to the Ignore Codes application.

☒ Access to Multi-Reader Configuration App
The user has access to the Multi-Reader Configuration application.

☒ Access to Reporting app
The user has access to the Reporting application.

☒ Access to RTM App
The user has access to the Real-Time Monitoring application.

Reset

Save

Item	Description
Roles	List of roles.
Accesses	List of accesses for the specified role.

Default User Credentials

The following users credentials are available by default:

92

User	Password	Default Permissions
admin	BnthWWSD	Has access to all apps and features. Admin users can modify the default user profiles, enable access permissions for the other user roles, or create new profiles.
engineer	TaRDpKVx	Has access to all apps and features.
operator	SxtXGmxs	User with read-only rights. The operator does not have access to the Device Management app and the Settings.

Note: Change the default credentials to avoid security risks. For more information, see [User Management on page 90](#).

Single Sign-On

EI Tunnel Manager supports Single Sign-On (SSO). Single Sign-On is a session and user authentication service that permits you to use a single set of login credentials. For example, you can set up a username and password that allows you to access multiple applications.

When choosing SSO on the EI Tunnel Manager login page, you are directed to the authentication service login page where you provide your credentials. Once your credentials are validated, you are redirected back with the security token to EI Tunnel Manager and logged in. You need to

To configure this process on EI Tunnel Manager, set up HTTPS with uploading certificates. From there, configure roles and map these roles to an existing one in the customer identity provider.

Then, you have to setup EI Tunnel Manager as a client and configure return URLs. For more information, see [Role Mapping on page 94](#).

Note: Cognex product name uppercase only supports the OpenID Connect (OIDC) standard for Single Sign-On.

Identity Provider Configuration

To set up Single Sign-On (SSO) in EI Tunnel Manager, log in to EI Tunnel Manager using the admin credentials. The Identity Provider Configuration page of the Single Sign-On app allows you to enter the details of your configuration to setup the login with the existing environment.

After filling in the mandatory fields, click **Save** to proceed.

Input Field	Description
Authority *	
Client ID *	
Client Secret *	
Role Claim Type *	
User Name Claim Type *	


Authority	Your Identity Provider (IdP) Authority URL. This is the endpoint where EI Tunnel Manager redirects users to perform the login step with the IdP.
Client ID	Your EI Tunnel Manager fully qualified domain name and any variations.
Client Secret	You need to configure a client secret on your IdP and enter the EI Tunnel Manager domain entries as redirect URLs. Redirect URLs take the following form: <i>https://%3cEIhttps://<EI address>/identity-provider/api/v1/oidc-external/callback</i>
Role Claim Type	This field indicates the roles or groups of the user. If you do not use Role Based Access Control in your IdP, this might not be required.
User Name Claim Type	This field indicates the username of the individual.

Role Mapping

The Role Mapping page of the Single Sign-On app allows you to create external roles and map them to the internal roles.

To create role mapping:

1. Click on **Create** on the top left corner of the **Role Mapping** page.




2. The **Create Role Mapping** pop-up appears.

Create Role Mapping

+

- Fill in any external role name in the **External Role Name** field and select an **Internal Role Name** from the default options.


Create Role Mapping



The form titled "Create Role Mapping" has two input fields: "External Role Name *" and "Internal Role Name *". The "Internal Role Name *" field is open, showing a dropdown menu with three options: "Admin", "Engineer", and "Operator". A red box highlights the dropdown menu. Below the fields is a red box containing a "+" icon. At the bottom right are "Cancel" and "Submit" buttons.


- Click on the + to add more role mappings.

Create Role Mapping



The form titled "Create Role Mapping" shows two role mappings. The first mapping has "Admin" in the "External Role Name *" field and "Admin" in the "Internal Role Name *" dropdown. The second mapping has "Someone" in the "External Role Name *" field and "Engineer" in the "Internal Role Name *" dropdown. A red box highlights the "+" icon below the mappings. At the bottom right are "Cancel" and "Submit" buttons, with "Submit" highlighted in yellow.

- After filling in the given fields, click **Submit** to create the role mappings.



The screenshot shows the "Role Mapping" page in the EI Tunnel Manager interface. The page has a breadcrumb trail: "Home > Single Sign-On > Role Mapping". Below the breadcrumb is a "Create" button. The main content is a table with the following structure:


Actions	External Role Name	Internal Role Name
 	Admin	Admin
 	Someone	Engineer

At the bottom right of the table, there is a pagination control showing "Items per page: 10" and "1 - 2 of 2".

You can edit or delete any role mapping from the list by clicking on the corresponding button icons.

If you click on the **Pencil** icon, the **Edit Role Mapping** pop-up appears.

Edit Role Mapping



The form titled "Edit Role Mapping" has two input fields: "External Role Name *" and "Internal Role Name *". The "External Role Name *" field contains the text "Someone". The "Internal Role Name *" field is a dropdown menu. At the bottom right are "Cancel" and "Submit" buttons, with "Submit" highlighted in yellow.

To save your changes after editing, click on **Submit**.

Data Transfer

Unit collects, parses, formats, and collates data from several readers.

Data Forwarding

The Data Forwarding page allows you to manage how the Unit sends your device data to different destinations. On this page, you can:

- Set up a data forwarding connection.
- Check, edit, pause, and delete connections.
- If an error occurs, the error message appears with the associated timestamp.

The screenshot shows the 'Data Forwarding' page with a breadcrumb trail: Home » Data Transfer » Data Forwarding. A 'CREATE CONNECTION' button is at the top left. The main table has columns: Actions, Name, Type, Status, Last Message Sent, and Transfer Rate. It lists two connections: 'test' (Amazon S3, Connected, Just now, 9/9) and 'test_sftp_errorlist' (SFTP, Disconnected, --). Below the table is an 'Error' section with a 'Timestamp' column, showing three 'Failed to initialize forwarder: Connection refused' messages from July 22, 2025.

Actions	Name	Type	Status	Last Message Sent	Transfer Rate
	test	Amazon S3	Connected	Just now	9/9
	test_sftp_errorlist	SFTP	Disconnected	--	

Error	Timestamp
Failed to initialize forwarder: Connection refused	Jul 22, 2025, 10:18:13 AM
Failed to initialize forwarder: Connection refused	Jul 22, 2025, 10:18:44 AM
Failed to initialize forwarder: Connection refused	Jul 22, 2025, 10:18:47 AM

Note: To enable data forwarding, you need a license from Cognex. See [Licensing on page 124](#).

Unit supports the following connection types:

- MQTT
- SFTP
- Amazon SNS
- Amazon S3
- Azure IoT Hub
- Azure Storage Blob
- FTP
- REST

Set Up an MQTT Connection

You can set up data forwarding through an MQTT connection from the Data Forwarding page. Data forwarding through MQTT only supports transferring results data. To set up the connection, you need to provide the details of your MQTT broker.

Prerequisites


Before you start, ensure that the following prerequisites are met:

- The Unit is connected to the local network.
- You are subscribed to the devices from which you intend to forward data.
- The details of your MQTT broker are available.

Procedure

To set up an MQTT connection:

1. Click **Create Connection** on the Data Forwarding page.
2. Choose **MQTT**.



3. Configure your connection:
 - a. Provide the **Connection Name**.
 - b. Optionally, to help differentiate between connections, provide a custom **Client ID**.
 - c. Choose the **Authentication Method** from the drop-down menu. Once you have selected the authentication method, the **Connection Settings** section appears in the page.

Note: If you select TLS, you must upload a **CA certificate**. If you select mTLS, you must upload a **CA certificate** and a **Client pfx**.

Configure Your Connection

Connection Name*	Client ID
Authentication Method* mTLS	CA Certificate Choose a crt, cert, pem file. Client pfx* Choose a pfx, pem, p12 file.

4. Enter the connection details, QoS, and Protocol Version for the MQTT broker.

Connection Settings

Broker Address*

Broker Port*

Username

 Password 

Topic

QoS Level

☐ 0 - at most once ☐ 1 - at least once ☐ 2 - exactly once

Protocol Version

☐ 3.1.1 ☐ 5

5. Choose the application data you want to forward and from which device. Under **Device Data** and **Tunnel Data**, you can choose specific data from each device by checking the corresponding box.

Choose application data to forward ^

Device Data ^

Results Statistics

Summary, Test	Device	☐ Good Read Trigger	☐ No Read Trigger	☐ Validation Failure Trigger
Tunnel_([Simulator])	icm4300-4300g-Primary	☐	☐	☐
Trusted Devices	icm4300-4300g-Test-Top-1-L...	☐	☐	☐

6. Click **Save**.

Your connection is now listed on the Data Forwarding page. You can edit, pause, and delete connections here.

Set Up an SFTP Connection

You can set up data forwarding through an SFTP connection from the Data Forwarding page. Data forwarding through SFTP supports both transferring results data and images. To set up the connection, you need to provide a custom file path.

Prerequisites


Before you start, ensure that the following prerequisites are met:

- The Unit is connected to the local network.
- You are subscribed to the devices from which you intend to forward data.

Procedure

To set up an SFTP connection:

1. Click **Create Connection** on the Data Forwarding page.
2. Choose **SFTP**.



3. Configure your connection:
 - a. Provide the **Connection Name**.
 - b. Optionally, to help differentiate between connections, provide a custom **Client ID**.
 - c. Choose the **Authentication Method** from the drop-down menu. Once you have selected the authentication method, the **Connection Settings** section appears in the page.

Configure Your Connection

Note: If you select Private Key, you must upload a **Private Key** file.

4. Define a custom file path.

Define Your Custom File Path

File Path*

Click a token below to add it to the file path.

Event Information

- + <EventType>
Notifies if the result is an image event or data event.
- + <ID>
Unique ID for each event.
- + <FileExtension>
File extension of the incoming message.

Time Information

- + <Timestamp>
The timestamp recorded for the trigger result
- + <Date>
Date in format YYYYMMDD (e.g. 2020-12-31T01:02:03Z -> 20201231)
- + <Time>
Time in format hh:mm:ss (e.g. 2020-12-31T01:02:03Z -> 010203)
- + <Day>
Day from timestamp (e.g. 2020-12-31T01:02:03Z -> 31)
- + <Month>
Month from timestamp (e.g. 2020-12-31T01:02:03Z -> 12)
- + <Year>
Year from timestamp (e.g. 2020-12-31T01:02:03Z -> 2020)
- + <Hours>
Year from timestamp (e.g. 2020-12-31T01:02:03Z -> 01)
- + <Minutes>
Year from timestamp (e.g. 2020-12-31T01:02:03Z -> 02)
- + <Seconds>
Year from timestamp (e.g. 2020-12-31T01:02:03Z -> 03)
- + <Milliseconds>
Milliseconds from timestamp (e.g. 2020-12-31T01:02:03.560Z -> 560)

DataMan Information

- + <Group>
MRS group name the image is originating from.
- + <TriggerIndex>
Trigger index for which image is for.
- + <DeviceMacAddress>
MacAddress of the device which generated this image.
- + <SourceDeviceName>
Name of the device which generated this image.
- + <output.other>
Configurable in DataMan data formatting script (output.other)
- + <Extrainformation>
Any extra information embedded in the image. (Image Only)
- + <ImageIndex>
Image number for a trigger. (Image Only)
- + <IsGoodRead>
Overall result status (Results Only)

Stitched Image Information

- + <StitchedSurface>
Surface that is stitched

Note: You can use a mix of literals and tokens to set up the custom file path. Tokens are replaced object information at the time of forwarding (for example, triggerID, timestamp). Image information tokens are only available for forwarding images and are not replaced on other data types.

5. Enter the connection details based on which authentication method you have selected.

Connection Settings

Host Address*

SFTP Port (Default = 22)

Username*

 Passphrase
 ☐

- Choose the application data you want to forward and from which device. Under **Device Data** and **Tunnel Data**, you can choose specific data from each device by checking the corresponding box.

Choose application data to forward ^

Device Data ^

Results Statistics

Summary Test	Device	☐ Good Read Trigger	☐ No Read Trigger	☐ Validation Failure Trigger
Tunnel (Simulation)	simulator-edges-Primary	☐	☐	☐
Edge Device	simulator-edges-Test-Top-1-L...	☐	☐	☐

- Click **Save**.

Your connection is now listed on the Data Forwarding page. You can edit, pause, and delete connections here.

Set Up an Amazon SNS Connection

Set up data forwarding through an Amazon SNS connection from the Data Forwarding page. Data forwarding through Amazon SNS only supports transferring results data. To set up the connection, you need files and details that you can get from your AWS account.

Prerequisites

Before you start, ensure that the following prerequisites are met:

- The Unit is connected to the Internet.
- You are subscribed to the devices whose data you want to forward to an SNS topic.
- The certificate and private key files, generated from your AWS account, are available.

Procedure

To set up an Amazon SNS connection:

- Click **Create Connection** on the Data Forwarding page.
- Choose **Amazon SNS**.

COGNEX | EI Tunnel Manager Full License admin

Home > Data Transfer > Data Forwarding > Create Connection

SAVE CANCEL

Select Your Connection Type

MQTT

SFTP

Amazon SNS

Amazon S3

Azure IoT Hub

Azure Storage Blob

FTP

REST

3. Configure your connection:
 - a. Provide the **Connection Name**.
 - b. Optionally, to help differentiate between connections, provide a custom **Client ID**.
 - c. Upload the certificate and private key files generated from your AWS account.

Configure Your Connection

Connection Name*

Client ID

Authentication Method*

X509 Certificate

Certificate*

Choose a .crt, .cert, .pem file.

Private Key*

Choose a .pfx, .pem, .p12, .key file.

102

4. Provide the details for the **Connection Settings**. You can find these details in your AWS account.

Connection Settings

5. To choose the data you want to forward and the source devices, check the corresponding box.

Choose application data to forward ^

Device Data ^

Results Statistics

MarketingDEMO

Device	☐ Good Read Trigger	☐ No Read Trigger	☐ Validation Failure Trigger
192.168.1.100	☐	☐	☐
192.168.1.101	☐	☐	☐
192.168.1.102	☐	☐	☐
192.168.1.103	☐	☐	☐

Tunnel Data ^

Results

MarketingDEMO

Device	☐ Tunnel Trigger Result
192.168.1.103	☐

6. Click **Save**.

Your connection is now listed on the Data Forwarding page. You can edit, pause, and delete connections here.

Set Up an Amazon S3 Connection

Set up data forwarding through an Amazon S3 connection from the Data Forwarding page. Data forwarding through Amazon S3 supports both transferring results data and images. To set up the connection, you need to provide a custom file path, and files and details that you can get from your AWS account.

Prerequisites


Before you start, ensure that the following prerequisites are met:

- The Unit is connected to the Internet.
- You are subscribed to the devices whose data you want to forward to an S3 bucket.
- The certificate and private key files, generated from your AWS account, are available.

Procedure

To set up an Amazon S3 connection:

1. Click **Create Connection** on the Data Forwarding page.
2. Choose **Amazon S3**.



3. Configure your connection.
 - a. Provide the **Connection Name**.
 - b. Optionally, to help differentiate between connections, provide a custom **Client ID**.
 - c. Upload the certificate and private key files generated from your AWS account.

Configure Your Connection

Connection Name*

Client ID

Authentication Method*
X509 Certificate

Certificate*
Choose a .crt, .cert, .pem file.

Private Key*
Choose a .pfx, .pem, .p12, .key file.

4. Define a custom file path.

Define Your Custom File Path

File Path*

Click a token below to add it to the file path.

Event Information	Time Information	DataMan Information	Stitched Image Information
+ <EventType> Notifies if the result is an image event or data event.	+ <Timestamp> The timestamp recorded for the trigger result	+ <Group> MRS group name the image is originating from.	+ <StitchedSurface> Surface that is stitched
+ <ID> Unique ID for each event.	+ <Date> Date in format YYYYMMDD (e.g. 2020-12-31T01:02:03Z -> 20201231)	+ <TriggerIndex> Trigger index for which image is for.	
+ <FileExtension> File extension of the incoming message.	+ <Time> Time in format hh:mm:ss (e.g. 2020-12-31T01:02:03Z -> 010203)	+ <DeviceMacAddress> MacAddress of the device which generated this image.	
	+ <Day> Day from timestamp (e.g. 2020-12-31T01:02:03Z -> 31)	+ <SourceDeviceName> Name of the device which generated this image.	
	+ <Month> Month from timestamp (e.g. 2020-12-31T01:02:03Z -> 12)	+ <output.other> Configurable in DataMan data formatting script (output other)	
	+ <Year> Year from timestamp (e.g. 2020-12-31T01:02:03Z -> 2020)	+ <ExtraInformation> Any extra information embedded in the image. (Image Only)	
	+ <Hours> Hour from timestamp (e.g. 2020-12-31T01:02:03Z -> 01)	+ <ImageIndex> Image number for a trigger. (Image Only)	
	+ <Minutes> Minute from timestamp (e.g. 2020-12-31T01:02:03Z -> 02)	+ <IsGoodRead> Overall result status (Results Only)	
	+ <Seconds> Second from timestamp (e.g. 2020-12-31T01:02:03Z -> 03)		
	+ <Milliseconds> Milliseconds from timestamp (e.g. 2020-12-31T01:02:03.560Z -> 560)		

Note: You can use a mix of literals and tokens to set up the custom file path. Tokens are replaced object information at the time of forwarding (for example, triggerID, timestamp). Image information tokens are only available for forwarding images and are not replaced on other data types.

5. Provide the details for the **Connection Settings**. You can find these details in your AWS account.

Connection Settings

6. To choose the data you want to forward and the source devices, check the corresponding box.

Choose application data to forward
^

Device Data
^

Results

Statistics

MarketingDEMO

Device	☐ Good Read Trigger	☐ No Read Trigger	☐ Validation Failure Trigger
19871_TeleHealth	☐	☐	☐
19871_TeleJ	☐	☐	☐
19871_TeleJ2	☐	☐	☐
19871_TeleJRightP	☐	☐	☐

Tunnel Data
^

Results

MarketingDEMO

Device	☐ Tunnel Trigger Result
19871_TeleJRightP	☐

7. Click **Save**.

Your connection is now listed on the Data Forwarding page. You can edit, pause, and delete connections here.

Set Up an Azure IoT Hub Connection

Set up data forwarding through an Azure IoT Hub connection from the Data Forwarding page. Data forwarding through Azure IoT Hub only supports transferring results data. To set up the connection, you need to provide a custom file path.

Prerequisites


Before you start, ensure that the following prerequisites are met:

- The Unit is connected to the local network.
- You are subscribed to the devices from which you intend to forward data.

Procedure

To set up an Azure IoT Hub connection:

1. Click **Create Connection** on the Data Forwarding page.
2. Choose **Azure IoT Hub**.



3. Configure your connection:
 - a. Provide the **Connection Name**.
 - b. Optionally, to help differentiate between connections, provide a custom **Client ID**.
 - c. Choose the **Authentication Method** from the drop-down menu. Once you have selected the authentication method, the **Connection Settings** section appears in the page.

Configure Your Connection

Note: If you select X509 Certificate, you must upload a **Pfx File**.

4. Define a custom file path.

Define Your Custom File Path

Click a token below to add it to the file path.

Event Information	Time Information	DataMan Information	Stitched Image Information
+ <EventType> Notifies if the result is an image event or data event.	+ <Timestamp> The timestamp recorded for the trigger result	+ <Group> MRS group name the image is originating from.	+ <StitchedSurface> Surface that is stitched
+ <ID> Unique ID for each event.	+ <Date> Date in format YYYYMMDD (e.g: 2020-12-31T01:02:03Z -> 20201231)	+ <TriggerIndex> Trigger index for which is image is for.	
+ <FileExtension> File extension of the incoming message.	+ <Time> Time in format hh:mm:ss (e.g: 2020-12-31T01:02:03Z -> 010203)	+ <DeviceMacAddress> MacAddress of the device which generated this image.	
	+ <Day> Day from timestamp (e.g: 2020-12-31T01:02:03Z -> 31)	+ <SourceDeviceName> Name of the device which generated this image.	
	+ <Month> Month from timestamp (e.g: 2020-12-31T01:02:03Z -> 12)	+ <output.other> Configurable in DataMan data formatting script (output.other)	
	+ <Year> Year from timestamp (e.g: 2020-12-31T01:02:03Z -> 2020)	+ <Extrainformation> Any extra information embedded in the image. (Image Only)	
	+ <Hours> Hour from timestamp (e.g: 2020-12-31T01:02:03Z -> 01)	+ <ImageIndex> Image number for a trigger. (Image Only)	
	+ <Minutes> Minute from timestamp (e.g: 2020-12-31T01:02:03Z -> 02)	+ <IsGoodRead> Overall result status (Results Only)	
	+ <Seconds> Second from timestamp (e.g: 2020-12-31T01:02:03Z -> 03)		
	+ <Milliseconds> Milliseconds from timestamp (e.g: 2020-12-31T01:02:03.560Z -> 560)		

5. Enter the connection details based on which authentication method you have selected.

Connection Settings





Connection Settings

Connection Settings

6. Choose the application data you want to forward and from which device. Under **Device Data** and **Tunnel Data**, you can choose specific data from each device by checking the corresponding box.

Choose application data to forward

Device Data

Image Results Results Statistics

Device	☐ Good Read Image	☐ No Read Image	☐ Validation Failure Image	☐ Image SVGs
Image Results	☐	☐	☐	☐

Tunnel Data

Results

Device	☐ Tunnel Trigger Result
Image Results	☐

7. Click **Save**.

Your connection is now listed on the Data Forwarding page. You can edit, pause, and delete connections here.

Set Up an Azure Storage Blob Connection

Set up data forwarding through an Azure Storage Blob connection from the Data Forwarding page. Data forwarding through Azure Storage Blob only supports transferring results data. To set up the connection, you need to provide a custom file path.

Prerequisites

Before you start, ensure that the following prerequisites are met:

- The Unit is connected to the local network.
- You are subscribed to the devices from which you intend to forward data.

Procedure

To set up an Azure Storage Blob connection:



- Click **Create Connection** on the Data Forwarding page.
- Choose **Azure Storage Blob**.

COGNEX | EI Tunnel Manager Full License admin

Home » Data Transfer » Data Forwarding » Create Connection

SAVE CANCEL

Select Your Connection Type

 MQTT	 SFTP	 Amazon SNS	 Amazon S3	 Azure IoT Hub	 Azure Storage Blob	 FTP	 REST
---	---	---	--	--	--	--	---

3. Configure your connection:

- Provide the **Connection Name**.
- Optionally, to help differentiate between connections, provide a custom **Client ID**.
- Choose the **Authentication Method** from the drop-down menu. Once you have selected the authentication method, the **Connection Settings** section appears in the page.

Configure Your Connection

Note: If you select Certificate Credential, you must upload a **Pfx File**.

4. Define a custom file path.

Define Your Custom File Path

File Path*

Click a token below to add it to the file path.

Event Information

+ <EventType>
Notifies if the result is an image event or data event.

+ <ID>
Unique ID for each event.

+ <FileExtension>
File extension of the incoming message.

Time Information

+ <Timestamp>
The timestamp recorded for the trigger result

+ <Date>
Date in format YYYYMMDD (e.g. 2020-12-31T01:02:03Z -> 20201231)

+ <Time>
Time in format hh:mm:ss (e.g. 2020-12-31T01:02:03Z -> 010203)

+ <Day>
Day from timestamp (e.g. 2020-12-31T01:02:03Z -> 31)

+ <Month>
Month from timestamp (e.g. 2020-12-31T01:02:03Z -> 12)

+ <Year>
Year from timestamp (e.g. 2020-12-31T01:02:03Z -> 2020)

+ <Hours>
Year from timestamp (e.g. 2020-12-31T01:02:03Z -> 01)

+ <Minutes>
Year from timestamp (e.g. 2020-12-31T01:02:03Z -> 02)

+ <Seconds>
Year from timestamp (e.g. 2020-12-31T01:02:03Z -> 03)

+ <Milliseconds>
Milliseconds from timestamp (e.g. 2020-12-31T01:02:03.560Z -> 560)

DataMan Information

+ <Group>
MRS group name the image is originating from.

+ <TriggerIndex>
Trigger index for which is image is for.

+ <DeviceMacAddress>
MacAddress of the device which generated this image.

+ <SourceDeviceName>
Name of the device which generated this image.

+ <output.other>
Configurable in DataMan data formatting script (output other)

+ <Extrainformation>
Any extra information embedded in the image. (Image Only)

+ <imageIndex>
Image number for a trigger. (Image Only)

+ <IsGoodRead>
Overall result status (Results Only)

Stitched Image Information

+ <StitchedSurface>
Surface that is stitched

5. Enter the connection details based on which authentication method you have selected.

Connection Settings

Connection Settings

Connection String*

Blob Container Name*

- Choose the application data you want to forward and from which device. Under **Device Data** and **Tunnel Data**, you can choose specific data from each device by checking the corresponding box.

Choose application data to forward

Device Data

Image Results
 Results
 Statistics

Device	☐ Good Read Image	☐ No Read Image	☐ Validation Failure Image	☐ Image SVGs
Select Device	☐	☐	☐	☐

Tunnel Data

Results

Device	☐ Tunnel Trigger Result
Select Device	☐

- Click **Save**.

Your connection is now listed on the Data Forwarding page. You can edit, pause, and delete connections here.

Set Up an FTP Connection

Set up data forwarding through an FTP connection from the Data Forwarding page. Data forwarding through FTP only supports transferring results data. To set up the connection, you need to provide a custom file path.

Prerequisites


Before you start, ensure that the following prerequisites are met:

- The Unit is connected to the local network.
- You are subscribed to the devices from which you intend to forward data.

Procedure

To set up an FTP connection:

1. Click **Create Connection** on the Data Forwarding page.
2. Choose **FTP**.



3. Configure your connection:
 - a. Provide the **Connection Name**.
 - b. Optionally, to help differentiate between connections, provide a custom **Client ID**.

Configure Your Connection

Authentication Method*
Standard

4. Define a custom file path.

Define Your Custom File Path

Click a token below to add it to the file path.

Event Information	Time Information	DataMan Information	Stitched Image Information
+ <EventType> Notifies if the result is an image event or data event.	+ <Timestamp> The timestamp recorded for the trigger result	+ <Group> MRS group name the image is originating from.	+ <StitchedSurface> Surface that is stitched
+ <ID> Unique ID for each event.	+ <Date> Date in format YYYYMMDD (e.g. 2020-12-31T01:02:03Z -> 20201231)	+ <TriggerIndex> Trigger index for which image is for.	
+ <FileExtension> File extension of the incoming message.	+ <Time> Time in format hh:mm:ss (e.g. 2020-12-31T01:02:03Z -> 010203)	+ <DeviceMacAddress> MacAddress of the device which generated this image.	
	+ <Day> Day from timestamp (e.g. 2020-12-31T01:02:03Z -> 31)	+ <SourceDeviceName> Name of the device which generated this image.	
	+ <Month> Month from timestamp (e.g. 2020-12-31T01:02:03Z -> 12)	+ <output.other> Configurable in DataMan data formatting script (output other)	
	+ <Year> Year from timestamp (e.g. 2020-12-31T01:02:03Z -> 2020)	+ <Extrainformation> Any extra information embedded in the image. (Image Only)	
	+ <Hours> Hour from timestamp (e.g. 2020-12-31T01:02:03Z -> 01)	+ <imageIndex> Image number for a trigger. (Image Only)	
	+ <Minutes> Minute from timestamp (e.g. 2020-12-31T01:02:03Z -> 02)	+ <IsGoodRead> Overall result status (Results Only)	
	+ <Seconds> Second from timestamp (e.g. 2020-12-31T01:02:03Z -> 03)		
	+ <Milliseconds> Milliseconds from timestamp (e.g. 2020-12-31T01:02:03.560Z -> 560)		

Note: You can use a mix of literals and tokens to set up the custom file path. Tokens are replaced object information at the time of forwarding (for example, triggerID, timestamp). Image information tokens are only available for forwarding images and are not replaced on other data types.

5. Configure your connection:
 - a. Provide the **Server Address**.
 - b. Optionally, provide an **FTP Port**.
 - c. Provide a **Username**.
 - d. Optionally, provide a **Password**.

Connection Settings

6. Choose the application data you want to forward and from which device. Under **Device Data** and **Tunnel Data**, you can choose specific data from each device by checking the corresponding box.

Choose application data to forward ^

Device Data ^

Image Results Results Statistics

Device ☐ Good Read Image ☐ No Read Image ☐ Validation Failure Image ☐ Image SVGs

☐

Tunnel Data ^

Results

Device ☐ Tunnel Trigger Result

☐

7. Click **Save**.

Your connection is now listed on the Data Forwarding page. You can edit, pause, and delete connections here.

Set Up a REST Connection

You can set up data forwarding through a REST connection from the Data Forwarding page. Data forwarding through REST only supports transferring results data.

Prerequisites


Before you start, ensure that the following prerequisites are met:

- The Unit is connected to the local network.
- You are subscribed to the devices from which you intend to forward data.

Procedure

To set up a REST connection:

1. Click **Create Connection** on the Data Forwarding page.
2. Choose **REST**.



3. Configure your connection:
 - a. Provide the **Connection Name**.
 - b. Optionally, to help differentiate between connections, provide a custom **Client ID**.
 - c. Choose the **Authentication Method** from the drop-down menu. Once you have selected the authentication

method, the **Connection Settings** section appears in the page.

4. Enter the connection details based on which authentication method you have selected.

Connection Settings

REST API endpoint url*

Grant Type

☐ Client Credentials

Application Client ID*


 Client Secret



Token Generation URL*

Scope*

Headers (JSON)

//

Connection Settings

API URL *

Headers (JSON)

- Choose the application data you want to forward and from which device. Under **Device Data** and **Tunnel Data**, you can choose specific data from each device by checking the corresponding box.

Choose application data to forward

Device Data

Results
 Statistics

Summary Test	Device	☐ Good Read Trigger	☐ No Read Trigger	☐ Validation Failure Trigger
Tunnel (Simulator)	simulator-dragon-Primary	☐	☐	☐
Inflight Devices	simulator-dragon-Trail-Fog-V-L	☐	☐	☐


- Click **Save**.

Your connection is now listed on the Data Forwarding page. You can edit, pause, and delete connections here.

Notification Center


The Notification Center allows you to filter and sort the notifications that EI Tunnel Manager sends you. You can access the Notification Center from the main menu or from the notification bell icon.

Click the bell icon in the upper-right corner of the home page to see the latest notifications. Click the **See All** button to open the Notification Center. You can switch off getting notifications for 10 minutes by clicking the **Snooze 10 Minutes** button.




Notification Center Features


1 2 3 4	5 6	
Number	Element	Description



1	Sort Options	Click on the Sort By dropdown to sort your notifications according to the following options: • Service Name: Sorts the notifications according to service name of the notifications. • Created At: Sorts the notifications according to the date of creation. • Level: Sorts the notifications according to the level of the notification (Info, Warning, Error, or Critical). • Is Read: Sorts the notifications according to whether the notification is read. • Arrived At: Sorts the notifications according to the date of arrival. Click on Sort Direction dropdown to determine the order of the notifications: • Ascending • Descending
---	--------------	---

		
2	Filter Options	You can filter the notifications by using the following filter options: • Arrived At: When the notification arrived in the Notification Center. • Created At: When the notification is created. • Service Name: Type in the Service Name of the notification. • Title: Type in the title of the notification. • Details: Type in the details of the notification. • Is Read: Filters your notifications according to the status of the notification (Read/Unread). • Notification Level: Filters according to level (Info, Warning, Error, or Critical).
3	Mark Filtered as Read	Mark the filtered notifications as read.
4	Reset All Options	Clears the selected Sort and Filter options.
5	Notification	Click on the notification to see the details. Click on the Mark as read button to mark the notification as read.

1. Download the license request file by clicking on the **Download License Request File** icon from the license table.



Name	Product Code	Activated At	Expires At
Cognex.Generic	1		
No Sub-Licenses Found			
EdgeInt.Generic	120000		6/1/23, 8:00 PM
EdgeInt.VisionRuntimeBase	120010		6/1/23, 8:00 PM
EdgeInt.DeviceCount	120020		6/1/23, 8:00 PM
EdgeInt.RemoteMonitor	120030		6/1/23, 8:00 PM
EdgeInt.API	120040		6/1/23, 8:00 PM
EdgeInt.TA	121000		6/1/23, 8:00 PM
EdgeInt.TA.TunnelCount	121010		6/1/23, 8:00 PM
EdgeInt.TA.F1	121100		6/1/23, 8:00 PM
EdgeInt.TA.F2	121200		6/1/23, 8:00 PM
EdgeInt.3DFieldCalib	122000		6/1/23, 8:00 PM

2. Email the generated license request file with the *.WibuCmRaC* extension to Cognex Support:
TSupport@cognex.com.
3. Cognex Support emails the license file with the *.WibuCmRaU* extension back to you.
4. Click on **Update License**. Select the file you have received with the *.WibuCmRaU* extension and click on **Submit**.

Update License

Select license update file (.WibuCmRaU)

License *



Required field.

Cancel

Submit

5. Check if the **Expires At** column updates automatically to the new license expiration date, to verify successful license update.

You can search for any information on the page by using the **Search** field.

Stitcher Settings


The Stitcher feature stitches images together into one bigger image. The stitched images appear in the Results Browser as normal images.

Note: Only the EI-A9-TUNMGR-xxx hardware supports image stitching.

The screenshot shows the 'Stitcher Parameters' configuration page. Numbered callouts highlight the following elements:

- 1:** Points to the 'Stitcher Enabled' checkbox, which is checked.
- 2:** Points to the 'Image Format' dropdown menu, which is set to 'BMP'.
- 3:** Points to the 'Output Image Quality' slider, which is set to '0' (Lowest).
- 4:** Points to the 'MRS Group Selection' table, which contains one row with the group name 'usps-tips'.
- 5:** Points to the 'Sides to be stitched' list, which includes 'Bottom', 'Top', 'Back', 'Right', 'Front', and 'Left'. The 'Right' side is selected.

Number	Description
1	Click the Stitcher Enabled checkbox to enable the type. You can choose the type of the Stitcher feature: • Modular Vision Tunnel (MVT): A flexible scan tunnel in which the units can detect up to six sides of the boxes. Scalable for various speeds and gaps, without sacrificing accuracy. • Top Only No Perspective: For units that only aimed at the top of the boxes.
2	Choose the image format from the dropdown: • JPG • PNG • BMP Choose the image size from the following: • Full • Quarter • 1/16 • 1/64






1 2 3 4	
3	Adjust the quality of the output image on the slider or write a number in the box. Select the Dots per Inch (DPI) value of the output images for each trigger type: 100 DPI: lower quality, suitable for long-term storage and basic analysis. 150 DPI: sacrifice some quality to reduce storage size. 210 DPI: suitable for post-processing, for example OCR. - Do not stitch: you can choose not stitching the images together for that particular trigger type.
4	Select the Multi-Reader Sync (MRS) group. You can choose a group if there are multiple groups provisioned on the Edge Intelligence system.
5	Select which sides of the boxes you want to stitch into one image. For example, if you have a unit that detects the top and the front of a box, you can select only the top to be stitched into one image.

Troubleshooting

This section provides solutions to common issues, helping you troubleshoot and resolve issues quickly and efficiently.

Remote Connection Troubleshooting

This section lists the most common errors and their solutions.

Error	Illustration	Solution
Unit is not visible in the browser		Check cable connections and secure them if necessary.
Failed login error message		Check the credentials and reenter username and/or password.
Component load error message		Reboot unit and wait for services to start.
No data/images available		Check unit availability and setup.
Cannot access Cognex product name uppercase URL		Check that subnets do not overlap. The network administrator must ensure that the IPs do not overlap.

Note: For the best results, use Ethernet connection to your network, because Wi-Fi might not allow the connection depending on your network settings.

Note:
The login page lists the IP address of your devices.



About El-DemoUnit

Documentation

☒ [Click here to open documentation.](#)

Network Interfaces

Name	Operational	MAC Address	Address Type	IP Address	Subnet Mask	Gateway	DNS Server	Domain
	✓		DHCP					(none)
	✓		DHCP					(none)
	✓		Static					(none)

Enable Remote Access for Cognex Technical Support

Select the appropriate remote access solution depending on the specific requirements and infrastructure of your organization.

Virtual Private Networking (VPN) and Virtual Desktop Infrastructure (VDI) allow Cognex Technical Support to connect with network-connected devices remotely. VPN and VDI access solutions provide secure, authorized remote support personnel with access to impacted equipment when resolving issues. Make sure you have support for HTTP, HTTPS, SSH, or SCP when using these solutions.

These solutions require engagement between the IT groups of both parties so that they can properly configure the remote access solution.

Contact Cognex Technical Support to get started.

Note: For further assistance or specific configuration guidance, contact the Cognex Technical Support department directly.

Access Solution	Requirements
VPN	- A VPN-compatible router or firewall at your site or a software VPN (such as Hamachi or TeamViewer). - Known accessible hostname for setup. - VPN software to provide the Cognex Technical Support team with. Recommendations for Setup: - Configure your VPN device (router/firewall) to enable VPN tunnels. For example: - Set up a VPN server. - Define user access controls. - Select encryption protocols and specify permissions to ports. - Create user accounts for Cognex Technical Support personnel with unique credentials. Note: At least 20 access accounts are required to ensure all support personnel have individual access. - Assign the necessary permissions for accessing the required systems. - Provide the Cognex Technical Support team with the VPN connection details, including the server address, login credentials, two-factor authentication, and any required VPN client software. - Continuously maintain accounts and provide the Cognex Technical Support team with relevant updates on policies.

Virtual Desktop Infrastructure (VDI)	• VDI solution (such as VMware Horizon or Citrix). • Sufficient bandwidth to support remote desktop sessions. • Software or web browser to provide the Cognex Technical Support team with. Recommendations for Setup: 1. Set up a VDI instance within your network. For example: a. Configure a virtual desktop. b. Set resource allocations (CPU, RAM, storage, and necessary software to access Cognex equipment). c. Define access controls. 2. Create dedicated VDI user accounts for the Cognex Technical Support personnel. Note: At least 20 access accounts are required to ensure all support personnel have individual access. Note: Make sure that the support personnel only have access to the necessary applications and data. 3. Provide the Cognex Technical Support team with the connection details, including the VDI portal URL, login credentials, and two-factor authentication.
TeamViewer	• Latest TeamViewer software installed. • Internet connection for simultaneous connection between on-site equipment and Cognex Technical Support. Note: Make sure you have IT permission to change the Ethernet adapter settings on your laptop. Recommendations for Setup: 1. Make sure TeamViewer is installed and running on a Windows PC connected to the Unit box. 2. Open TeamViewer to obtain the session ID and password. 3. Share the session ID and password with the Cognex Technical Support team to enable a secure connection.

Video Conferencing Software	• Video conferencing software application installed, such as: ◦ Microsoft Teams ◦ Zoom ◦ Webex Note: Run the video conferencing software on a Windows PC connected to the Unit box. • Internet connection for simultaneous connection between on-site equipment and Cognex Technical Support. Note: Make sure that you have company permissions to share in a meeting and give remote control. Note: This access option is not recommended by the Cognex Technical Support team since it limits the ability of the support team to resolve problems. Recommendations for Setup: 1. Either party can schedule a meeting and share the meeting invitation link with the other party. 2. Use the provided meeting ID or link to join the meeting at the scheduled time. 3. Share your screen with the Cognex Technical Support.
-----------------------------	--

Open Source Licenses

The table below shows the open source licenses used by EI Tunnel Manager:

@amcharts/amcharts3-angular	Paid
angular-resize-event	MIT
angular2-moment	MIT
core-js	MIT
dateformat	MIT
daterangepicker	MIT
fullscreen	MIT
moment	MIT
ngx-daterangepicker-material	MIT
ngx-spinner	MIT
primeicons	MIT
rxjs	Apache-2.0
rxjs-compat	Apache-2.0
screenfull	MIT
socket.io	MIT
socket.io-client	MIT
Timescaledb	Apache-2.0
Timescale toolkit	Timescale License
zone.js	MIT

Copyright © 2026
Cognex Corporation. All Rights Reserved.

