

## DataMan<sup>®</sup> 280 Series Reference Manual



2026 July 30  
Revision: 26.2.0.16

# Legal Notices

The software described in this documentation is provided "as is" and "as available," without warranty of any kind, express or implied, including but not limited to the warranties of merchantability, fitness for a particular purpose, and non-infringement. In no event shall Cognex Corporation and its global affiliates (collectively, "Cognex") be liable for any claims, damages, or other liability arising from, out of, or in connection with the software or your use of the software.

Your use of this software is governed by the full terms and conditions of the Cognex Software License Agreement. For complete licensing details and legal terms, please visit <https://www.cognex.com/terms-and-conditions>.

The information in this document is subject to change without notice and should not be construed as a commitment by Cognex. Cognex is not responsible for any errors that may be present in either this document or the associated software.

Companies, names, and data used in examples herein are fictitious unless otherwise noted. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, nor transferred to any other media or language without the written permission of Cognex Corporation.

Portions of the hardware and software provided by Cognex may be covered by one or more U.S. and foreign patents, as well as pending U.S. and foreign patents listed on the Cognex web site at: [cognex.com/patents](http://cognex.com/patents).

In the event of any inconsistency between the English language version of this documentation and any other language version, the English language version shall take precedence.

Copyright © 2026. Cognex Corporation. All Rights Reserved.

---

The following are registered U.S. trademarks of Cognex Corporation:

2DMAX, 3D LIGHTBURST TECHNOLOGY, ADVANTAGE, ALIGNPLUS, ASSEMBLYPLUS, COGNEX, COGNEX VISION FOR INDUSTRY, CVL, DATAMAN, DVT, EASYBUILDER, EDGE INTELLIGENCE, HOTBARS, IDMAX, IN-SIGHT, LIGHTBURST, MX, OMNIVIEW, PATFIND, PATFLEX, PATINSPECT, PATMAX, PATMAX REDLINE, PATQUICK, POWERGRID, QUICKSORT, ULTRALIGHT, VISION SOLUTIONS, VISIONPRO, VISIONVIEW

The following are trademarks of the Cognex Corporation:

1DMAX, 3D SYMBOLIC LIGHT, 3D-LOCATE, 3DMAX, ONEVISION, PINPOINT, RANGEMAX, SLX, VIDI, OCRMAX, INSPECTEDGE, VISION SOLUTIONS

Portions copyright © Microsoft Corporation. All rights reserved.

Portions copyright © MadCap Software, Inc. All rights reserved.

Other product and company trademarks identified herein are the trademarks of their respective owners.

# Precautions

To reduce the risk of injury or equipment damage, observe the following precautions when you install the Cognex product:

- Connectivity is possible through the following options:
  - 24 VDC (+/- 10%) output connection using a UL or NTRL listed power supply
  - Power over Ethernet (PoE) 13 W power supply

Any other voltage creates a risk of fire or shock and can damage the components. Applicable national and local wiring standards and rules must be followed.

- This product is intended for industrial use in automated manufacturing or similar applications.
- The safety of any system incorporating this product is the responsibility of the assembler of the system.
- Do not install Cognex products where they are exposed to environmental hazards such as excessive heat, dust, moisture, humidity, impact, vibration, corrosive substances, flammable substances, or static electricity.
- Route cables and wires away from high-current wiring or high-voltage power sources to reduce the risk of damage or malfunction from the following causes: over-voltage, line noise, electrostatic discharge (ESD), power surges, or other irregularities in the power supply.
- Do not expose the image sensor to laser light. Image sensors can be damaged by direct, or reflected, laser light. If your application requires laser light that might strike the image sensor, use a lens filter at the corresponding laser wavelength. For suggestions, contact your local integrator or application engineer.
- This product does not contain user-serviceable parts. Do not make electrical or mechanical modifications to product components. Unauthorized modifications can void your warranty.
- Changes or modifications not expressly approved by the party responsible for regulatory compliance could void the user's authority to operate the equipment.
- Include service loops with cable connections.
- Ensure that the cable bend radius begins at least six inches from the connector. Cable shielding can be degraded or cables can be damaged or wear out faster if a service loop or bend radius is tighter than 10X the cable diameter.
- This device should be used in accordance with the instructions in this manual.
- All specifications are for reference purposes only and can change without notice.

# Symbols

The following symbols indicate safety precautions and supplemental information:

---

 **WARNING:** This symbol indicates a hazard that could cause death, serious personal injury or electrical shock.

---

---

 **CAUTION:** This symbol indicates a hazard that could result in property damage.

---

---

 **Note:** This symbol indicates additional information about a subject.

---

---

 **Tip:** This symbol indicates suggestions and shortcuts that might not otherwise be apparent.

---

# Table of Contents

|                                                                         |           |
|-------------------------------------------------------------------------|-----------|
| <b>Legal Notices</b>                                                    | <b>2</b>  |
| <b>Precautions</b>                                                      | <b>3</b>  |
| <b>Symbols</b>                                                          | <b>4</b>  |
| <b>Table of Contents</b>                                                | <b>5</b>  |
| <b>Getting Started</b>                                                  | <b>8</b>  |
| About the DataMan 280 Series                                            | 8         |
| Supporting Documentation                                                | 9         |
| DataMan 280 Series Accessories                                          | 10        |
| Lenses                                                                  | 10        |
| Illumination                                                            | 12        |
| Lens Covers                                                             | 13        |
| Mounting Brackets                                                       | 15        |
| Cables                                                                  | 16        |
| DataMan 280 Series Systems                                              | 16        |
| DataMan 280 Systems                                                     | 17        |
| DataMan 282 Systems                                                     | 18        |
| DataMan 280 EtherCAT Systems                                            | 19        |
| Illumination Options                                                    | 19        |
| <b>Setting Up Your DataMan 280 Reader</b>                               | <b>21</b> |
| Reader Layout                                                           | 21        |
| DataMan 280 Layout                                                      | 21        |
| DM282 Layout                                                            | 23        |
| DM280 EtherCAT Layout                                                   | 24        |
| Indicator LEDs                                                          | 25        |
| EtherCAT Indicators                                                     | 25        |
| Dimensions                                                              | 27        |
| DataMan 280 with 6.2 mm lens                                            | 27        |
| DataMan 280 with 16 mm Lens                                             | 28        |
| DataMan 280 with L-shaped extension, equipped with 6.2 mm Lens          | 29        |
| DataMan 280 with L-shaped extension, equipped with 16 mm Lens           | 30        |
| DataMan 280 EtherCAT with 6.2 mm lens                                   | 31        |
| DataMan 280 EtherCAT with 16 mm Lens                                    | 31        |
| DataMan 280 EtherCAT with L-shaped extension, equipped with 6.2 mm Lens | 32        |
| DataMan 280 EtherCAT with L-shaped extension, equipped with 16 mm Lens  | 32        |
| DataMan280 EtherCAT with Side Mirror Accessory                          | 33        |
| DataMan 282 with High-Power Integrated Torch                            | 34        |
| DataMan 282 with High-Power Integrated Torch - L-Shaped Extension       | 35        |
| DataMan 282 with Dome Front Cover                                       | 36        |
| DataMan 282 with Dome Front Cover - Right Angle Configuration           | 37        |
| Field of View and Reading Distance                                      | 38        |
| DataMan 280 EC and Standard Model Readers with 6.2 mm Lens              | 38        |
| DataMan 280 EC and Standard Model Readers with 16 mm lens               | 39        |
| DataMan 282 Readers with 8 mm Lens                                      | 41        |
| DataMan 282 Readers with 12 mm Lens                                     | 42        |

|                                                                        |           |
|------------------------------------------------------------------------|-----------|
| DataMan 282 Readers with 16 mm Lens .....                              | 43        |
| Connecting the Reader .....                                            | 44        |
| Installing and Changing Lenses .....                                   | 45        |
| Installing a C-Mount Lens .....                                        | 45        |
| Changing a 6.2 mm Lens to a 16 mm Lens .....                           | 49        |
| Installing a High Speed Liquid Lens .....                              | 53        |
| Installing Front Cover on High-Power Integrated Torch .....            | 57        |
| Mounting the Reader .....                                              | 57        |
| Mounting the Reader in Straight Configuration .....                    | 58        |
| Mounting the Reader in Right-Angle Configuration .....                 | 58        |
| Setting Focus .....                                                    | 58        |
| Manual Focus Lens .....                                                | 59        |
| Focus Feedback .....                                                   | 60        |
| Best Practices .....                                                   | 60        |
| Connection Options .....                                               | 62        |
| Connecting the Ethernet Cable to DataMan 280 Series Readers .....      | 62        |
| Connecting the EtherCAT Cable to the DataMan 280 EtherCAT Reader ..... | 62        |
| Connecting the Power and I/O Breakout Cable .....                      | 64        |
| Using your Device through USB .....                                    | 65        |
| <b>Using Your DataMan 280 Reader .....</b>                             | <b>69</b> |
| WebUI and WebHMI Browser Interfaces .....                              | 69        |
| Connect to DataMan WebUI .....                                         | 70        |
| Connect to DataMan WebHMI .....                                        | 71        |
| Installing the DataMan Setup Tool .....                                | 72        |
| Trigger Types .....                                                    | 72        |
| External Triggers .....                                                | 73        |
| Training the Reader .....                                              | 73        |
| Manual Training .....                                                  | 74        |
| Training Feedback .....                                                | 75        |
| Incremental Training for Multiple Symbologies .....                    | 75        |
| DM282 LED Configurations .....                                         | 76        |
| Industrial Protocols .....                                             | 79        |
| <b>Specifications .....</b>                                            | <b>80</b> |
| DataMan 280 Series Reader .....                                        | 80        |
| DataMan 280 Series Reader Image Sensor .....                           | 81        |
| LED Wavelengths .....                                                  | 81        |
| Acquisition Trigger Input .....                                        | 83        |
| High-Speed Outputs .....                                               | 84        |
| High Speed Output Wiring .....                                         | 85        |
| Ethernet Cable .....                                                   | 86        |
| EtherCAT Adapter Cable .....                                           | 87        |
| CCB-M12x12Fy-xx .....                                                  | 88        |
| CCBL-05-01 .....                                                       | 89        |
| CCB-PWRIO-05 .....                                                     | 90        |
| <b>Cleaning and Maintenance .....</b>                                  | <b>91</b> |
| Clean the Housing .....                                                | 91        |

|                                                         |           |
|---------------------------------------------------------|-----------|
| Clean the Reader Image Sensor Window .....              | 91        |
| Clean the Reader Lens Cover .....                       | 91        |
| <b>Regulations and Conformity .....</b>                 | <b>92</b> |
| 中国大陆 RoHS (Information for China RoHS Compliance) ..... | 93        |
| For European Community Users .....                      | 94        |

# Getting Started

This section provides general information about the DataMan 280 series reader and the accessories and systems.

## About the DataMan 280 Series

The DataMan 280 series readers are high-performance readers that offer:

- Premium class performance in a compact package
- Flexible Industry 4.0 connectivity options
- Unmatched modularity and ease of use



# Supporting Documentation

This document provides basic information about the DataMan 280 series readers. Additional information is available through the Windows **Start** menu or the DataMan Setup Tool **Help** menu after you install the DataMan software on your PC.

**Note:** For the latest documentation, visit: [support.cognex.com/documentation/dataman](http://support.cognex.com/documentation/dataman).

- The **DataMan Communications and Programming Guide** shows you how to integrate your DataMan reader into your particular automation and factory environment.  
Cognex > DataMan Software Revision: x.x.x> Documentation > Communications > DataMan Communications and Programming Guide
- The **DataMan Industrial Protocols Manual** provides information on how to integrate DataMan readers into your particular environment using industrial protocols.  
Cognex > DataMan Software Revision: x.x.x> Documentation > Communications > DataMan Industrial Protocols Manual
- The **DataMan Reader Configuration Codes** document provides printable 2-D codes that you can use to configure the DataMan reader.  
Cognex > DataMan Software Revision: x.x.x > Documentation > English > Reader Configuration Codes
- The **DM280 Quick Reference Guide** provides essential information about the DM280 reader.  
Cognex > DataMan Software Revision: x.x.x > Documentation > English > DM280 Series > DM280 Quick Reference Guide
- The **DataMan Fixed-Mount Readers Reference** is a complete online hardware reference for the DataMan fixed-mount ID readers.  
Cognex > DataMan Software Revision: x.x.x > Documentation > English > DM280 > Fixed-Mount Reference Manual
- The **DataMan Questions and Answers** document provides context-sensitive information. You can view this help inside the DataMan Setup Tool or as a stand-alone help file.  
Cognex > DataMan Software Revision: x.x.x > Documentation > DM280 > Questions and Answers
- The **DataMan Control Commands** lists DataMan Control Commands with all relevant information. You can view this help inside the Setup Tool or as a stand-alone help file.  
Cognex > DataMan Software Revision: x.x.x > Documentation > English > DataMan Control Commands
- The **Setup Tool Reference Manual** describes the user interface of the DataMan Setup Tool software.  
Cognex > DataMan Software Revision: x.x.x> Documentation > English > Setup Tool Reference Manual
- The **Release Notes** list detailed system requirements and additional information about the DataMan software release.  
Cognex > DataMan Software Revision: x.x.x > Documentation > DataMan Revision: x.x.x > Release Notes

# DataMan 280 Series Accessories

You can purchase the following components separately. For a list of options and accessories, contact your local Cognex sales representative.

## Lenses

| Accessory                                                                                                                                                                                                                                                                                            | Product Number  | Illustration                                                                         | DM280 | DM280<br>EC | DM282 |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------------------------------------------------------------------------------|-------|-------------|-------|
| 6.2 mm lens kit that includes: <ul style="list-style-type: none"> <li>• 6.2 mm optics mount</li> <li>• 6.2 mm lens</li> <li>• Manual lens cap (assembled)</li> <li>• Screws</li> </ul>                                                                                                               | DM280-LENS-62   |    | ✓     | ✓           |       |
| UV Light Kit for 6.2 mm lens (Risk Group Exempt acc. IEC 62471) <ul style="list-style-type: none"> <li>• UV light board (365 nm wavelength)</li> <li>• UV resistant front cover</li> <li>• Screws</li> </ul>                                                                                         | DM280-UV365-62  |    | ✓     | ✓           |       |
| 16 mm lens kit with extended optics mount (requires the use of an extended front cover and high-powered red LED). The kit includes: <ul style="list-style-type: none"> <li>• 16 mm optics mount</li> <li>• 16 mm lens</li> <li>• Manual lens cap (assembled)</li> <li>• Screws</li> </ul>            | DM260-LENS-16   |  | ✓     | ✓           |       |
| IR 6.2 mm lens kit, 3-position with IR LED includes: <ul style="list-style-type: none"> <li>• 6.2 mm optics mount</li> <li>• 6.2 mm lens (IR)</li> <li>• Standard Infrared Light for 6.2mm (Risk Group Exempt acc. IEC62471)</li> <li>• Manual lens cap (not assembled)</li> <li>• Screws</li> </ul> | DM280-KIT-IR-62 |  | ✓     | ✓           |       |

| Accessory                                                                                                                                                                                                                                                                                                                                                                                                | Product Number   | Illustration                                                                         | DM280 | DM280 EC | DM282 |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|--------------------------------------------------------------------------------------|-------|----------|-------|
| IR 16 mm lens kit that includes: <ul style="list-style-type: none"> <li>• 16 mm optics mount</li> <li>• 16 mm lens (IR)</li> <li>• Standard Infrared Light for 16mm (Risk Group Exempt acc. IEC62471)</li> <li>• Manual lens cap (assembled)</li> <li>• Screws</li> </ul>                                                                                                                                | DMA-KIT-IR-16    |    | ✓     | ✓        |       |
| High Speed Liquid Lens Module (HSLL) to be used with 6.2 mm lens or 16 mm lens                                                                                                                                                                                                                                                                                                                           | DMA-HSLL-280     |    | ✓     | ✓        | ✓     |
| 16 mm lens with ImageMax kit that includes: <ul style="list-style-type: none"> <li>• 16 mm optics mount</li> <li>• 16 mm lens</li> <li>• High Speed Liquid Lens Module (DMA-HSLL-280)</li> <li>• High Powered red LED illumination (DM260-LED-RED-HP) (Risk Group Exempt acc. IEC62471)</li> <li>• 2-LED half-polarized extended cover (DM260-LENS-16CVR-P) (Risk Group Exempt acc. IEC62471)</li> </ul> | DM280-KIT-IMGMAX |    | ✓     | ✓        |       |
| Blue bandpass filter                                                                                                                                                                                                                                                                                                                                                                                     | DM150-BP470      |  | ✓     | ✓        |       |
| Blue bandpass filter, 450 nm                                                                                                                                                                                                                                                                                                                                                                             | 280-TORCH-BP450  |  |       |          | ✓     |
| Red bandpass filter                                                                                                                                                                                                                                                                                                                                                                                      | DM150-BP635      |  | ✓     | ✓        |       |
| Red bandpass filter, 635 nm                                                                                                                                                                                                                                                                                                                                                                              | 280-TORCH-BP635  |  |       |          | ✓     |

## Illumination

| Accessory                                                                                                                             | Product Number   | Illustration                                                                       | DM280 | DM280 EC | DM282 |
|---------------------------------------------------------------------------------------------------------------------------------------|------------------|------------------------------------------------------------------------------------|-------|----------|-------|
| Red LED Light for 6.2 mm Lens (Risk Group Exempt acc. IEC 62471)                                                                      | DM150-LED-RED    |  | ✓     | ✓        |       |
| White LED Light for 6.2 mm Lens (Risk Group Exempt acc. IEC 62471)                                                                    | DM150-LED-WHT    |                                                                                    | ✓     | ✓        |       |
| Blue LED Light for 6.2 mm Lens (Risk Group Exempt acc. IEC 62471)                                                                     | DM150-LED-BLU    |                                                                                    | ✓     | ✓        |       |
| High-Powered Red LED Light for 16 mm Lens (Risk Group Exempt acc. IEC 62471) For maximum light power 24 V DC supply is recommended.   | DM280-LED-RED-HP |  | ✓     | ✓        |       |
| High-Powered White LED Light for 16 mm Lens (Risk Group Exempt acc. IEC 62471) For maximum light power 24 V DC supply is recommended. | DM280-LED-WHT-HP |  | ✓     | ✓        |       |

## Lens Covers

| Accessory                                                           | Product Number     | Illustration                                                                        | DM280 | DM280 EC | DM282 |
|---------------------------------------------------------------------|--------------------|-------------------------------------------------------------------------------------|-------|----------|-------|
| Standard front cover. Use with a 6.2 mm lens only.                  | DM280-CVR-62       |    | ✓     | ✓        |       |
| Standard front cover, half-polarized. Use with a 6.2 mm lens only.  | DM280-LENS-62CVR-P |    | ✓     | ✓        |       |
| Standard front cover, fully-polarized. Use with a 6.2 mm lens only. | DM280-LENS-62CVR-F |    | ✓     | ✓        |       |
| Extended front cover. Use with a 16 mm lens only.                   | DM260-LENS-16CVR   |    | ✓     | ✓        |       |
| Extended front cover, half-polarized. Use with a 16 mm lens only.   | DM260-LENS-16CVR-P |                                                                                     | ✓     | ✓        |       |
| Extended front cover, fully-polarized. Use with a 16 mm lens only.  | DM260-LENS-16CVR-F |                                                                                     | ✓     | ✓        |       |
| C-mount adapter, IP40                                               | DM280-CMNT-00      |    | ✓     | ✓        |       |
| C-mount cover, IP65                                                 | DM280-CMNT-CVR     |  | ✓     | ✓        |       |
| Cross-polarized cover for High-Power Integrated Torch               | 280-HPIT-COVPOL    |  |       |          | ✓     |
| Clear cover for High-Power Integrated Torch                         | 280-HPIT-COVCLR    |                                                                                     |       |          | ✓     |
| Diffuse cover for High-Power Integrated Torch                       | 280-HPIT-COVDIF    |                                                                                     |       |          | ✓     |
| Dome Diffuser cover for High-Power Integrated Torch                 | 280-TORCH-DOME     |  |       |          | ✓     |

**Note:** A reader with HPIT does not need a lens cover.

**CAUTION:** For 280-HPIT-COVPOL, 280-HPIT-COVCLR, and 280-HPIT-COVDIF equipped with a laser aimer, the device has been tested to be under the limits of a Class 1 Laser device.




## Mounting Brackets

| Accessory                                | Product Number  | Illustration                                                                       | DM280 | DM280 EC | DM282 |
|------------------------------------------|-----------------|------------------------------------------------------------------------------------|-------|----------|-------|
| Universal mounting bracket               | DM100-UBRK-000  |  | ✓     | ✓        | ✓     |
| Pivot mounting bracket                   | DM100-PIVOTM-01 |   | ✓     | ✓        | ✓     |
| Tilted angle pivot bracket               | DMBK-DMPIVOT-00 |   | ✓     | ✓        | ✓     |
| Logistics mounting bracket and plate kit | DMA-BKT-LGS     |  | ✓     | ✓        | ✓     |
| Adjustable mirror bracket                | DMA-262-MIR     |  | ✓     | ✓        |       |

## Cables

**Note:** Cables are sold separately.

| Accessory                                              | Product Number                                                           | Illustration                                                                         | DM280 | DM280 EC | DM282 |
|--------------------------------------------------------|--------------------------------------------------------------------------|--------------------------------------------------------------------------------------|-------|----------|-------|
| Ethernet Cable, X-coded M12-8 to RJ-45                 | CCB-84901-2001-xx (straight, xx specifies length: 2m, 5m, 10m, 15m, 30m) |    | ✓     | ✓        | ✓     |
| Ethernet Cable, X-coded M12-8 to RJ-45                 | CCB-84901-2002-xx (right-angled, xx specifies length: 2m, 5m, 10m)       |    | ✓     | ✓        | ✓     |
| Ethernet Cable, Robotic X-Coded M12-8 to RJ-45         | CCB-84901-2RBT-xx (straight, xx specifies length: 2m, 5m, 10m)           |    | ✓     | ✓        | ✓     |
| X-Coded to A-Coded Ethernet cable adapter, 0.5 m       | CCB-M12X8MS-XCAC                                                         |    | ✓     | ✓        | ✓     |
| Power and I/O Breakout Cable, M12-12 to Flying Lead    | CCB-M12x12Fy-05 (y = straight/angled, xx specifies length)               |    | ✓     | ✓        | ✓     |
| Power and I/O Breakout Cable, M12-12 to Flying Lead    | CCBL-05-01                                                               |    | ✓     | ✓        | ✓     |
| Power and I/O Breakout Cable, M12-12 to Flying Lead    | CCB-PWRIO- xx (straight, xx specifies length: 5m, 10m, 15m)              |    | ✓     | ✓        | ✓     |
| Power and I/O Breakout Cable, M12-12 to Flying Lead    | CCB-PWRIO-xxR (right-angled, xx specifies length: 5m, 10m, 15m)          |    | ✓     | ✓        | ✓     |
| I/O Module Cable                                       | CCB-PWRIO-MOD-xx (xx specifies length: 2m, 5m)                           |  | ✓     | ✓        | ✓     |
| RS-232 Connection Cable                                | CCB-M12xDB9Y-05                                                          |  | ✓     | ✓        | ✓     |
| I/O Extension Cable                                    | CKR-200-CBL-EXT                                                          |  | ✓     | ✓        | ✓     |
| Sealed USB Type C Cable to USB Type A, Straight, 2.5 m | DMA-STCBLE-IP65-25                                                       |  | ✓     | ✓        | ✓     |
| Sealed USB Type C Cable to USB Type A, Straight 3.6 m  | DMA-STCBLE-IP65-36                                                       |                                                                                      | ✓     | ✓        | ✓     |
| Sealed USB Type C Cable to USB Type A, Angled, 2.5 m   | DMA-RTCBLE-IP65-25                                                       |  | ✓     | ✓        | ✓     |
| Sealed USB Type C Cable to USB Type A, Angled, 3.6 m   | DMA-RTCBLE-IP65-36                                                       |                                                                                      | ✓     | ✓        | ✓     |
| EtherCAT Adapter Cable                                 | CCB-ECAT-30                                                              |  |       | ✓        |       |

## DataMan 280 Series Systems

## DataMan 280 Systems

|  | Omnidirectional 1D Codes | 1D Max with Hotbars | High Speed Decoding | 2DMax - Hard to Read 2D Codes | PowerGrid - Damaged 2D Codes | Multi-Reader Sync | Resolution  |
|-----------------------------------------------------------------------------------|--------------------------|---------------------|---------------------|-------------------------------|------------------------------|-------------------|-------------|
| DM-280L 1D Codes                                                                  |                          | ✓                   | ✓                   |                               |                              | ✓                 | 1440 x 1080 |
| DM-280QL 1D Codes                                                                 | ✓                        | ✓                   | ✓                   |                               |                              | ✓                 |             |
| DM-280S 1D/2D Codes                                                               | ✓                        | ✓                   |                     |                               |                              | ✓                 |             |
| DM-280Q 1D/2D Codes                                                               | ✓                        | ✓                   | ✓                   | ✓                             |                              | ✓                 |             |
| DM-280X 1D/2D Codes                                                               | ✓                        | ✓                   | ✓                   | ✓                             | ✓                            | ✓                 |             |

## DataMan 282 Systems




|  | Omnidirectional<br>1D Codes | 1D Max<br>with<br>Hotbars | High Speed<br>Decoding | 2DMax - Hard to<br>Read 2D Codes | PowerGrid -<br>Damaged 2D<br>Codes | Multi-<br>Reader<br>Sync | Resolution  |
|-----------------------------------------------------------------------------------|-----------------------------|---------------------------|------------------------|----------------------------------|------------------------------------|--------------------------|-------------|
| DM-<br>282L<br>1D<br>Codes                                                        |                             | ✓                         | ✓                      |                                  |                                    | ✓                        | 1920 x 1080 |
| DM-<br>282QL<br>1D<br>Codes                                                       | ✓                           | ✓                         | ✓                      |                                  |                                    | ✓                        |             |
| DM-<br>282S<br>1D/2D<br>Codes                                                     | ✓                           | ✓                         |                        |                                  |                                    | ✓                        |             |
| DM-<br>282Q<br>1D/2D<br>Codes                                                     | ✓                           | ✓                         | ✓                      | ✓                                |                                    | ✓                        |             |
| DM-<br>282X<br>1D/2D<br>Codes                                                     | ✓                           | ✓                         | ✓                      | ✓                                | ✓                                  | ✓                        |             |

## DataMan 280 EtherCAT Systems

|  | Omnidirectional 1D Codes | 1D Max with Hotbars | High Speed Decoding | 2DMax - Hard to Read 2D Codes | PowerGrid - Damaged 2D Codes | Multi-Reader Sync | Resolution  |
|-----------------------------------------------------------------------------------|--------------------------|---------------------|---------------------|-------------------------------|------------------------------|-------------------|-------------|
| DM-280L 1D Codes                                                                  |                          | ✓                   | ✓                   |                               |                              | ✓                 | 1440 x 1080 |
| DM-280QL 1D Codes                                                                 | ✓                        | ✓                   | ✓                   |                               |                              | ✓                 |             |
| DM-280S 1D/2D Codes                                                               | ✓                        | ✓                   |                     |                               |                              | ✓                 |             |
| DM-280Q 1D/2D Codes                                                               | ✓                        | ✓                   | ✓                   | ✓                             |                              | ✓                 |             |
| DM-280X 1D/2D Codes                                                               | ✓                        | ✓                   | ✓                   | ✓                             | ✓                            | ✓                 |             |

## Illumination Options

| Illumination Board                                                                                    | PoE Powered        |                 | 24 V Externally Powered |                 |
|-------------------------------------------------------------------------------------------------------|--------------------|-----------------|-------------------------|-----------------|
|                                                                                                       | Max. exposure time | Max. duty cycle | Max. exposure time      | Max. duty cycle |
| Standard Red<br>   | 1 ms               | 6%              | 1 ms                    | 6%              |
| High Power Red<br> | 1 ms               | 6%              | 10 ms                   | 10%             |
| Standard White<br> | 1 ms               | 6%              | 1 ms                    | 6%              |

| Illumination Board                                                                                                       | PoE Powered                |                 | 24 V Externally Powered |                 |
|--------------------------------------------------------------------------------------------------------------------------|----------------------------|-----------------|-------------------------|-----------------|
|                                                                                                                          | Max. exposure time         | Max. duty cycle | Max. exposure time      | Max. duty cycle |
| <b>High Power White</b><br>             | 1 ms                       | 6%              | 10 ms                   | 10%             |
| <b>Standard Blue</b><br>                | 1 ms                       | 6%              | 1 ms                    | 6%              |
| <b>IR</b><br>                           | 1 ms                       | 6%              | 1 ms                    | 6%              |
| <b>High Power IR</b><br>                | 1 ms                       | 6%              | 10 ms                   | 10%             |
| <b>High-Power Integrated Torch</b><br> | HPIT does not support PoE. |                 | 5 ms                    | 6.5%            |

## Setting Up Your DataMan 280 Reader

Read this section to learn how the reader connects to its standard components and accessories.

**Note:**

- Cables are sold separately.
- If a standard component is missing or damaged, immediately contact your Cognex Authorized Service Provider (ASP) or Cognex Technical Support.




**CAUTION:** All cable connectors are keyed to fit the connectors on the reader. Do not force the connections or damage may occur.


## Reader Layout

## DataMan 280 Layout

The image and table below shows the elements of the reader.




| Number | Description                        |
|--------|------------------------------------|
| 1      | Power I/O Breakout cable connector |
| 2      | USB-C slot (with plastic cover)    |
| 3      | Ethernet connector                 |
| 4      | Illumination LEDs                  |
| 5      | LED aimers                         |



| Number | Description                        |
|--------|------------------------------------|
| 6      | Trigger button                     |
| 7      | Tune button                        |
| 8      | User LED indicator                 |
| 9      | Power LED indicator                |
| 10     | Train/Trigger status LED indicator |
| 11     | Good/Bad read LED indicator        |
| 12     | Communication LED indicator        |
| 13     | Error LED indicator                |


## DM282 Layout

The image and table below shows the elements of the reader.



## DM280 EtherCAT Layout

The image and table below shows the elements of the reader.



| Number | Description                                 |
|--------|---------------------------------------------|
| 1      | Power I/O Breakout cable connector          |
| 2      | USB-C slot (with plastic cover)             |
| 3      | Network connector (EtherCAT)                |
| 4      | Ethernet connector                          |
| 5      | Illumination LEDs                           |
| 6      | LED aimers                                  |
| 7      | EtherCAT Link Activity Out LED <sup>1</sup> |
| 8      | Trigger button                              |
| 9      | EtherCAT Status LED <sup>1</sup>            |
| 10     | Tune button                                 |
| 11     | EtherCAT Link Activity In LED <sup>1</sup>  |
| 12     | Indicator LEDs                              |
| 13     | Power LED indicator                         |
| 14     | Train/Trigger status LED indicator          |
| 15     | Good/Bad read LED indicator                 |
| 16     | Communication LED indicator                 |
| 17     | Error LED indicator                         |

<sup>1</sup>For more information on the EtherCAT LEDs, see [EtherCAT Indicators on page 25](#).

## Indicator LEDs

The table summarizes the functions of the indicator LEDs on DataMan 280 series readers.

| Indicator                          | Color/Status    | Meaning                                                                                                                                                                                                        |
|------------------------------------|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| User LED indicator                 | GREEN, blinking | Light edges blink in GREEN when the reader performs a good read.<br><b>Note:</b> In case of a good read, the Good/Bad read indicator LED is also blinking in GREEN.                                            |
|                                    | RED, blinking   | Light edges blink in RED when the reader performs a bad read when it does not find a decoding after a timeout.<br><b>Note:</b> In case of a bad read, the Good/Bad read indicator LED is also blinking in RED. |
|                                    | WHITE           | Light edges are WHITE when you trigger the Identify function in DataMan Setup Tool. For more information, see <i>DataMan Setup Tool Reference Manual</i> .                                                     |
| Power LED indicator                | ON              | The reader is ON.                                                                                                                                                                                              |
|                                    | OFF             | The reader is OFF.                                                                                                                                                                                             |
| Train/Trigger status LED indicator | ON              | If the reader has a trained code, this LED is GREEN.                                                                                                                                                           |
|                                    | OFF             | If the reader has no trained code, this LED is OFF.                                                                                                                                                            |
| Good/Bad read LED indicator        | GREEN, blinking | The reader performs a good read.<br><b>Note:</b> In case of a good read, light edges are also blinking in GREEN.                                                                                               |
|                                    | RED, blinking   | The reader performs a bad read when it does not find a decoding after a timeout.<br><b>Note:</b> In case of a bad read, light edges are also blinking in RED.                                                  |
| Communication LED indicator        | ON              | This LED is ON when the DataMan 280 series established the Ethernet connection.                                                                                                                                |
|                                    | OFF             | This LED is OFF when there is no Ethernet connection.                                                                                                                                                          |
| Error                              | ON              | This LED is ON when the DataMan 280 series reader detects an error.                                                                                                                                            |

## EtherCAT Indicators

The following table summarizes the functions of the EtherCAT-specific indicator LEDs.

| Indicator | Color/Status   | Meaning                                                            |
|-----------|----------------|--------------------------------------------------------------------|
| LA IN     | ON             | The Link Activity LED is ON when there is an EtherCAT connection.  |
|           | ON, flickering | The Link Activity LED flickers when data is going back and forth.  |
|           | OFF            | The Link Activity LED is OFF when there is no EtherCAT connection. |

|        |              |              |                                                                                                    |
|--------|--------------|--------------|----------------------------------------------------------------------------------------------------|
| ST     | GREEN        | ON           | The Status LED is steady GREEN when the EtherCAT connection is running.                            |
|        |              | blinking     | The Status LED blinks GREEN when the EtherCAT connection is in PRE-OPERATIONAL state.              |
|        |              | single flash | The Status LED flashes once GREEN when the EtherCAT connection is in SAFE-OPERATIONAL state.       |
|        |              | OFF          | The GREEN, blinking Status LED is OFF when the EtherCAT connection is in INIT state.               |
|        | RED          | ON           | The Status LED is RED when a critical communication or application controller occurs.              |
|        |              | double flash | The Status LED is RED when an EtherCAT Watchdog Timeout error occurs.                              |
|        |              | single flash | The Status LED is RED when a local error occurs.                                                   |
|        |              | blinking     | The Status LED is RED when a general configuration error occurs.                                   |
|        |              | OFF          | The Status LED is RED when there is no error, the EtherCAT communication of the device is running. |
|        |              |              |                                                                                                    |
| LA OUT | ON           |              | The Link Activity LED is ON when there is an EtherCAT connection.                                  |
|        | ON, blinking |              | The Link Activity LED blinks when data is going back and forth.                                    |
|        | OFF          |              | The Link Activity LED is OFF when there is no EtherCAT connection.                                 |

# Dimensions

The following sections list dimensions of the reader.


**Note:**



- Dimensions are in millimeters and are for reference purposes only.
- All specifications are for reference purposes only and can change without notice.


## DataMan 280 with 6.2 mm lens

The following image shows the dimensions of DataMan 280, equipped with 6.2 mm lens.




## DataMan 280 with 16 mm Lens

The following image shows the dimensions of DataMan 280 equipped with 16 mm lens.




## DataMan 280 with L-shaped extension, equipped with 6.2 mm Lens

The following image shows the dimensions of DataMan 280 equipped with L-shaped extension and 6.2 mm lens.




## DataMan 280 with L-shaped extension, equipped with 16 mm Lens

The following image shows the dimensions of DataMan 280 equipped with L-shaped extension and 16 mm lens.




## DataMan 280 EtherCAT with 6.2 mm lens

The following image shows the dimensions of DataMan 280 EtherCat, equipped with 6.2 mm lens.




## DataMan 280 EtherCAT with 16 mm Lens

The following image shows the dimensions of DataMan 280 EtherCAT equipped with 16 mm lens.




**DataMan 280 EtherCAT with L-shaped extension, equipped with 6.2 mm Lens**

The following image shows the dimensions of DataMan 280 EtherCAT equipped with L-shaped extension and 6.2 mm lens.




**DataMan 280 EtherCAT with L-shaped extension, equipped with 16 mm Lens**

The following image shows the dimensions of DataMan 280 EtherCAT equipped with L-shaped extension and 16 mm lens.




## DataMan280 EtherCAT with Side Mirror Accessory

The following image shows the dimensions of DataMan280 EtherCAT equipped with the side mirror accessory




# DataMan 282 with High-Power Integrated Torch

The following image shows the dimensions of DataMan 282 equipped with High-Power Integrated Torch.




## DataMan 282 with High-Power Integrated Torch - L-Shaped Extension

The following image shows the dimensions of DataMan 282 equipped with a High-Power Integrated Torch and L-shaped extension.




# DataMan 282 with Dome Front Cover

The following image shows the dimensions of DataMan 282 equipped with a dome front cover.




## DataMan 282 with Dome Front Cover - Right Angle Configuration

The following image shows the dimensions of DataMan 282 equipped with L-shaped extension and dome front cover.



## Field of View and Reading Distance

This section provides the Field of View (FoV) values for 6.2 mm and 16 mm lenses.



### DataMan 280 EC and Standard Model Readers with 6.2 mm Lens

6.2 mm lenses can be focused to 105 mm (short range) and to 190 mm (long range).

#### Short Range (Focused to 105 mm)

The following tables show the Field of View (FoV) widths of the 6.2 mm lens focused to 105 mm at various distances.

| Working distance in mm | Horizontal values in mm | Vertical values in mm |
|------------------------|-------------------------|-----------------------|
| $Z_1 = 40$             | $X_1 = 38$              | $Y_1 = 29$            |
| $Z_2 = 65$             | $X_2 = 58$              | $Y_2 = 44$            |
| $Z_3 = 105$            | $X_3 = 90$              | $Y_3 = 68$            |

| Distances in mm | 2D min. code in mil | 1D min. code in mil |
|-----------------|---------------------|---------------------|
| 40              | 4                   | 2                   |
| 65              | 5                   | 3                   |
| 105             | 10                  | 5                   |


#### Long Range (Focused to 190 mm)

The following table shows the Field of View (FoV) widths of the 6.2 mm lens focused to 190 mm at various distances.

| Working distance in mm | Horizontal values in mm | Vertical values in mm |
|------------------------|-------------------------|-----------------------|
| $Z_1 = 190$            | $X_1 = 159$             | $Y_1 = 119$           |
| $Z_2 = 225$            | $X_2 = 187$             | $Y_2 = 140$           |
| $Z_3 = 375$            | $X_3 = 307$             | $Y_3 = 230$           |
| $Z_4 = 1000$           | $X_4 = 808$             | $Y_4 = 606$           |

| Distances in mm | 2D min. code in mil | 1D min. code in mil |
|-----------------|---------------------|---------------------|
| 150             | 10                  | 6                   |
| 190             | 12                  | 8                   |
| 225             | 15                  | 8                   |
| 375             | 20                  | 15                  |
| 500             | 30                  | 20                  |
| 1000            | 60                  | 35                  |

## DataMan 280 EC and Standard Model Readers with 16 mm lens




The following tables list the Field of View (FoV) widths of the 16 mm lens at various distances:

| Working distance in mm | Horizontal values in mm | Vertical values in mm |
|------------------------|-------------------------|-----------------------|
| $Z_1 = 150$            | $X_1 = 46$              | $Y_1 = 34$            |
| $Z_2 = 225$            | $X_2 = 69$              | $Y_2 = 52$            |

| Working distance in mm | Horizontal values in mm | Vertical values in mm |
|------------------------|-------------------------|-----------------------|
| $Z_3 = 375$            | $X_3 = 116$             | $Y_3 = 87$            |
| $Z_4 = 1000$           | $X_4 = 310$             | $Y_4 = 232$           |

| Distances in mm | 2D min. code in mil | 1D min. code in mil |
|-----------------|---------------------|---------------------|
| 80              | 2                   | 2                   |
| 150             | 3                   | 2                   |
| 190             | 4                   | 3                   |
| 225             | 5                   | 3                   |
| 375             | 8                   | 5                   |
| 500             | 10                  | 7                   |
| 1000            | 20                  | 15                  |


DataMan 282 Readers with 8 mm Lens



| Working distance in mm | Horizontal values in mm | Vertical values in mm |
|------------------------|-------------------------|-----------------------|
| $Z_1 = 300$            | $X_1 = 223$             | $Y_1 = 125$           |
| $Z_2 = 750$            | $X_2 = 526$             | $Y_2 = 295$           |
| $Z_3 = 1200$           | $X_3 = 828$             | $Y_3 = 466$           |

| Working Distance in mm | 2D min. code in mil | 1D min. code in mil |
|------------------------|---------------------|---------------------|
| 300                    | 12                  | 7                   |
| 750                    | 18                  | 12                  |
| 1200                   | 22                  | 15                  |


## DataMan 282 Readers with 12 mm Lens



| Working distance in mm | Horizontal values in mm | Vertical values in mm |
|------------------------|-------------------------|-----------------------|
| $Z_1 = 300$            | $X_1 = 141$             | $Y_1 = 79$            |
| $Z_2 = 750$            | $X_2 = 343$             | $Y_2 = 193$           |
| $Z_3 = 1200$           | $X_3 = 545$             | $Y_3 = 306$           |

| Working Distance in mm | 2D min. code in mil | 1D min. code in mil |
|------------------------|---------------------|---------------------|
| 300                    | 10                  | 6                   |
| 750                    | 18                  | 11                  |
| 1200                   | 22                  | 15                  |

DataMan 282 Readers with 16 mm Lens



| Working distance in mm | Horizontal values in mm | Vertical values in mm |
|------------------------|-------------------------|-----------------------|
| $Z_1 = 300$            | $X_1 = 105$             | $Y_1 = 59$            |
| $Z_2 = 750$            | $X_2 = 256$             | $Y_2 = 144$           |
| $Z_3 = 1200$           | $X_3 = 407$             | $Y_3 = 229$           |

| Working Distance in mm | 2D min. code in mil | 1D min. code in mil |
|------------------------|---------------------|---------------------|
| 300                    | 8                   | 5                   |
| 750                    | 16                  | 9                   |
| 1200                   | 22                  | 14                  |

# Connecting the Reader



| 1 | <a href="#"><i>Installing a C-Mount Lens on page 45</i></a>                                   |
|---|-----------------------------------------------------------------------------------------------|
| 2 | <a href="#"><i>Mounting the Reader on page 57</i></a>                                         |
| 3 | <a href="#"><i>Connecting the Ethernet Cable to DataMan 280 Series Readers on page 62</i></a> |
| 4 | <a href="#"><i>Connecting the Power and I/O Breakout Cable on page 64</i></a>                 |

---

## Installing and Changing Lenses

This section provides an overview about installing and changing different kinds of lenses.

**Note:** Use a Phillips screwdriver with drive size #1 for all Phillips screws that are reachable from the front side.


**Note:** Disconnect the reader from power before changing lenses or mounts.

**CAUTION:** Perform all lens modification procedures in a dust-free and ESD safe area.

---

### Installing a C-Mount Lens

1. Unscrew the four M2x12mm Phillips Pan head screws, then take off the metal cover from the reader.



- 
2. Remove the illumination module.



3. Unscrew the two M2x5mm Phillips head screws, remove the 6.2 mm lens mount and the 6.2 mm lens.




4. Place the C-Mount cover on the front of the device, and tighten the screws.



**Note:**

Observing the tightening sequence below, tighten all six M2 x 12 mm Phillips Pan screws to 12 Ncm using a torque wrench.




5. Place the lens cover adapter plate on the C-Mount cover, and tighten the screws.



- 
6. Thread the lens into the reader.



7. Screw the lens cover onto the lens cover adapter.




---

## Changing a 6.2 mm Lens to a 16 mm Lens

This section provides a step-by-step process for changing the 6.2 mm lens to a 16 mm lens on the reader.

1. Unscrew the four M2x12mm Phillips Pan head screws, then take off the metal cover from the reader.




2. Remove the illumination module.




- 
3. Unscrew the two M2x5mm Phillips head screws, remove the 6.2 mm lens mount and the 6.2 mm lens.




4. Attach the 16 mm lens mount and lens, and screw in the two M2x5mm Phillips head screws. Focus, if necessary. For more information, see [Setting Focus on page 58](#).



- 
5. Attach the 16 mm lens illumination module.




6. Attach the 16 mm lens front cover.



**i** **Note:** The rib in the front cover must be oriented to the top side.

**Note:**

Observing the tightening sequence below, tighten all four M2 x 12 mm Phillips Pan screws to 16 Ncm using a torque wrench.




---

## Installing a High Speed Liquid Lens

This section shows the process of installing a liquid lens onto the DataMan 280 with a 6.2 mm lens.

1. Unscrew the four M2 x 12 mm Phillips Pan head screws, then take off the metal cover from the reader.



2. Remove the illumination module.



3. Turn the lens cap to the 105 mm position.



4. Carefully remove the lens cap from the imager lens.



**Note:** In order not to lose focus calibration, do not rotate the imager lens while the lens cap is removed.

5. Attach the liquid lens accessory by aligning the 2x2 connectors of the liquid lens with the 2x2 sockets on the optics mount.




- 
6. Press the liquid lens onto the imager lens until you reach the stop.



7. Re-attach the illumination module.




- 
8. Re-attach the front cover.



**Note:** The rib in the front cover must be oriented to the top side.

**Note:**

Observing the tightening sequence below, tighten all four M2 x 12 mm Phillips Pan screws to 16 Ncm using a torque wrench.




---

## Installing Front Cover on High-Power Integrated Torch


1. Screw in the four screws from the light module housing into the front cover.

The following image depicts the dome front cover. The same instructions apply to polarized and diffuse front covers.



### Note:

Observing the tightening sequence below, tighten all four M2.5 x 34 mm Phillips Pan screws to 0.25 Ncm using a torque wrench.




## Mounting the Reader

The reader provides mounting holes for attachment to a mounting surface.

**CAUTION:** The reader has to be grounded, either by mounting the reader to a fixture that is electrically grounded or by attaching a wire from the reader's mounting fixture to frame ground or Earth ground. If a ground wire is used, it has to be attached to one of the four mounting points on the bottom plate of the reader and not to the mounting points on the front of the reader.


The method of mounting depends on whether the reader is in straight or right-angle configuration, regardless of the product variant.

## Mounting the Reader in Straight Configuration



Align the holes on the mounting surface with the mounting holes on the reader. Insert the M3X5 screws into the mounting holes.


## Mounting the Reader in Right-Angle Configuration



Align the holes on the mounting surface with the mounting holes on the reader. With the reader in right-angle position, only the back mounting holes can be used. To mount the device in right-angle position, use the M3X9 screws.

### Note:

Mounting the reader at a slight angle (15°) reduces reflections and improves performance.



## Setting Focus


There is a range of reading distances available for different code sizes and focus positions. To set focus on your reader, use the following options depending on whether you use a liquid lens or a manual focus lens.

DataMan readers are compatible with multiple different lenses. Each lens has a range of reading distances available for different code sizes and focus positions. Having accurate focus settings is essential to maximize read rates.

To set the focus on your reader, use the following options depending on whether you use a liquid lens or a manual focus lens.

**Note:**


The DataMan Setup Tool has focus sheets that can help you manually adjust lenses or swapping between them.




## Manual Focus Lens

Click the **Focus Feedback** button in the image panel in SetupTool to enable focus feedback.


This enables a color-coded focus feedback bar on the right side of the image panel. Once focus feedback is enabled, enter live mode and manually adjust the lens until the focus feedback bar is green.





## Focus Feedback

Focus is indicated by colors ranging from red (bad focus) to green (sharp focus). When focusing the reader, you need to adjust its position until the focus column becomes green.



## Best Practices

Both **Optimize Focus** and the **Focus Feedback** use the same procedure for testing the current focus. They consider various sub-regions of the image.

Follow these guidelines to maximize the performance of **Optimize Focus** and **Focus Feedback**:

- Use a focus target (such as the one supplied with this Reference Manual) that includes high-contrast features and is big enough that it fills at least a 100 x 100 pixel region in the center of the field of view at the desired working distance.
- Avoid floppy pieces of paper and make sure the target is perfectly flat.
- Make sure that the target is perfectly perpendicular to the optical axis of the reader.
- Make sure that the rest of the field of view, such as the part not covered by the focus target, does not contain any high-contrast features. For example, you would ideally fill the entire field of view with a white card or sheet of paper (to avoid shadows), and position the focus target in the middle.
- The supplied 120 x 120 mm focus target is appropriate for typical working distances. If you use such a working distance that the target does not completely fill the image, make sure that there are no high-contrast features visible outside of the target (see previous bullet).

---

**Note:**



- If you use the focus feedback indicator to adjust a manual focus lens, you must apply power to the reader before you remove the cover. If you remove the cover before applying power, the internal illumination will not function.
- If you use a Liquid Lens, make sure that the cover is mounted and connected before you apply power. If you attach or remove the front cover while the reader is powered, the focus setting is lost.

# Connection Options

This section summarizes connection options.

For more information on how to connect your DataMan reader to your network, see the *DataMan Communications and Programming Guide*.

## Connecting the Ethernet Cable to DataMan 280 Series Readers

**CAUTION:** The Ethernet cable shield has to be grounded at the far end. If the far end device is not grounded, add a ground wire in compliance with local electrical codes. The cable is typically plugged into a switch or router, which has to have a grounded Ethernet connector. Use a digital voltmeter to validate the grounding.

1. Connect the M12 connector of the Ethernet cable to the reader ENET connector.
2. Connect the RJ-45 connector of the Ethernet cable to a switch/router or PC, as applicable.

**Note:**

- Besides powering the DataMan 280 readers through a Breakout Cable, it is possible to power DataMan through PoE connection as well, in which case it is not necessary to use a Breakout Cable.
- Only DataMan 280 readers support PoE.



## DataMan 282 Readers LED Behavior with PoE

DataMan 282 Readers require 24 V DC to operate. If you try to power the reader with a PoE cable, the reader boots up, but the illumination shuts down. The error LED of the reader turns solid red to indicate an underpowered state. You can overwrite the behavior of the error LED in the **Inputs / Outputs** application step of the DataMan Setup Tool. For more information on how to configure the error LED, refer to the *DataMan Questions and Answers* document.

## Connecting the EtherCAT Cable to the DataMan 280 EtherCAT Reader

Connect the EtherCAT cable to the EtherCAT connector of the DataMan 280 EtherCAT Reader:



**Note:** Do not plug the EtherCAT cable into an Ethernet network. You could damage your Ethernet network and disable your EtherCAT set.

The DataMan 280 EtherCAT reader provides two 100 MBit EtherCAT ports in a single physical connector. One of the ports acts as input, and the other one as output:

- If you connect an M12 to RJ-45 Ethernet cable to the EtherCAT connector, you connect to the IN port.
- If you connect with the EtherCAT adapter cable, both the IN and OUT ports are available




The DataMan 280 EtherCAT supports the following physical topologies:

- Star
- Line
- Ring

**Note:** For detailed information on the supported EtherCAT configurations, see the *DataMan Industrial Protocols Manual*.

## Star EtherCAT Topology


The star topology connects each reader to the PLC individually. This topology offers increased availability, as each reader can be reached individually.



---


## Line EtherCAT Topology

The line topology connects the readers in daisy chain. The output of one adapter cable is plugged into the input of the next one. The line starts at the output from the PLC, and ends at the input connector of the last reader. This topology reduces the cabling needed to connect all readers.



## Ring EtherCAT Topology

The ring topology connects the readers in daisy chain. The output of one adapter cable is plugged into the input of the next one. The ring starts at the output from the PLC, and ends at the output of the last reader connected back to the PLC. This topology offers redundancy, since a reader can be reached from either direction.



## Connecting the Power and I/O Breakout Cable



**CAUTION:** To reduce emissions, connect the far end of the Breakout cable shield to frame ground.

---

**Note:**

- Perform wiring or adjustments to I/O devices when the reader is not receiving power.
- You can clip unused wires short or use a tie made of non-conductive material to tie them back. Keep bare wires separated from the +24 V DC wire.

1. Verify that the 24 V DC power supply is unplugged and not receiving power.
2. Attach the +24 V DC connector of the Power and I/O Breakout cable and Ground wires to the corresponding terminals on the power supply. For more information, see [Specifications on page 80](#).



**CAUTION:** Never connect voltages other than 24 V DC. Always observe the polarity shown.

3. Attach the M12 connector of the Power and I/O Breakout Cable to the 24 V DC connector of the reader.
4. Restore power to the 24 V DC power supply and turn it on if necessary.

## Using your Device through USB

You can use the USB connector of the DataMan 280 in the following ways:

- Emulating serial (USB-COM) functionality

The DataMan 280 establishes the connection through emulated serial port.

- Emulating Ethernet functionality

The DataMan 280 establishes the connection through emulated Ethernet.

- As HID (Human Interface Device)

If you use DataMan 280 in HID mode, the device serves as an emulated keyboard.



**Note:** To prevent issues, ensure that the USB connector is tightly screwed on.

### Emulating Serial Functionality

If you connect a USB-C cable, you can see a COM port in the Windows Device Manager, as a generic USB-COM port.

To emulate serial functionality:

1. Set the **USB Connection** properties in the **Serial** tab of the **Communication Settings** panel in DataMan Setup Tool.
2. Look at the Windows Device Manager to identify the proper device.
3. Enable the **Serial-over-USB** option in DataMan Setup Tool, because it is disabled by default.

### Emulating Ethernet Functionality


You have to configure the connection between the PC and the DataMan 280 to use the emulated Ethernet-over-USB functionality.

The DataMan 280 has the fixed IP address 192.168.111.2/24 through an emulated Ethernet connection.


#### Configure the PC-emulated Ethernet driver to be in the same LAN

1. Connect the PC to the DataMan 280 with an USB-C cable.
2. Open **Control Panel** and select **Network and internet**.
3. Select **Network and Sharing Center**, then select **Change adapter settings**.

4. Identify the virtual adapter. On the example image, it is Ethernet 5.




5. Right-click on the virtual adapter and select **Properties**. Assign a fixed IP to the network adapter starting with 192.168.111.



## Use Case Examples

### To connect to the DataMan Setup Tool:

1. Connect the PC to the DataMan 280 with a USB-C cable
2. Set up the Ethernet emulation as described in [Configure the PC-emulated Ethernet driver to be in the same LAN on page 65](#).
3. Open the DataMan Setup Tool.
4. Navigate to the **Home > Repair and Support** page, click **Add Network Device**, and enter the 192.168.111.2 IP address. Click **OK**.



5. Connect to the reader.

---

### To connect through Telnet:

1. Connect the PC to the DataMan 280 with an USB-C cable.
2. Set up the Ethernet emulation as described in [Configure the PC-emulated Ethernet driver to be in the same LAN on page 65](#).
3. Open a Telnet connection with the 192.168.111.2/23 IP address.


### To connect to the WebHMI:

1. Connect the PC to the DataMan 280 with an USB-C cable.
2. Set up the Ethernet emulation as described in [Configure the PC-emulated Ethernet driver to be in the same LAN on page 65](#).
3. Enable the WebHMI in DataMan Setup Tool. By default, this option is disabled.




**Note:** Note: The WebHMI takes a few seconds to launch.

4. Open a browser and enter 192.168.111.2 into the address bar to connect to the WebHMI through the virtual IP address.



WebHMI is a use case example. You can also use Telnet or DataMan Setup Tool for emulating Ethernet functionality.


- Telnet Open Telnet connection with 192.168.111.2/23 IP address.
- DataMan Setup Tool:
  - a. Click **Add Network Device** on the Home, Repair and Support page and enter the 192.168.111.2 IP address. Click **OK**.



- b. Connect to the reader.

## USB-KeyBoard (HID) Functionality

To use the DataMan 280 as an emulated keyboard, set the language of the keyboard in the DataMan Setup Tool. HID reports use the keyboard language set in the drop down menu.



To enable HID reports, tick the checkbox in DataMan Setup Tool.

### Note:



- Communication through HID reports is similar to using a physical keyboard.
- Using keyboard emulation with applications supporting hotkeys can result in unexpected behavior, depending on the data of the read codes.


# Using Your DataMan 280 Reader

This section provides information on the installation of the DataMan Setup Tool, trigger types, and protocols.


## WebUI and WebHMI Browser Interfaces

DataMan 280 series readers support connecting to WebHMI in a browser, and alternatively, to WebUI starting from firmware version 6.3.9.

WebUI and WebHMI are mutually exclusive, this means that you can only use WebUI or WebHMI on a reader. By default, WebUI is enabled on readers, and WebHMI has to be enabled first to use it.



WebUI



WebHMI

## Connect to DataMan WebUI

Connect to the DataMan WebUI using one of the following options:

### Web browser


1. Open a web browser.
2. Enter any of the following details:
  - The IP address of your reader.
  - Serial number: found on the label of the reader, followed by `.local`. For example, `1A2436XN005610.local`.
  - MAC address: found on the label of the reader, followed by `.local`. For example, `00D0243BF53C.local`.
  - Host name: the default host name is `DM290` and the first six characters of the MAC address, followed by `.local`. For example, `DM290-00D024.local`.



### Station Manager


1. Go to [support.cognex.com/en/downloads/edge-intelligence](https://support.cognex.com/en/downloads/edge-intelligence) and select Cognex Station Manager.
2. Download the Station Manager installer and follow the on-screen steps.
3. Find and select your reader.

- Click **Connect** and set up.



### DataMan Setup Tool

- Follow the steps described in [Installing the DataMan Setup Tool on page 72](#).
- Right-click on your reader and select **Open WebUI In Browser**.



## Connect to DataMan WebHMI

DataMan 280 series readers support connecting to WebHMI in a browser. By default, the WebHMI is disabled on DataMan 280 series readers and you have to enable WebHMI to use it.

If you leave WebHMI disabled, you can connect to the reader in WebUI.

To enable and connect to WebHMI:

- Enable WebHMI with one of the following methods:

**Note:** If you load an older configuration on the reader in which WebHMI was previously enabled, WebHMI remains enabled.

- DataMan Setup Tool**
  - Launch DataMan Setup Tool.
  - Go to the **Communications** step.
  - Under the **Web HMI** group, enable WebHMI.
- DataMan Control Command (DMCC)**

- a. Issue the `WEBHMI.ENABLE DMCC` on the reader.
2. Connect to WebHMI in a browser using the IP address of the reader.

## Installing the DataMan Setup Tool

Follow the steps below to install and connect your reader to the DataMan Setup Tool.

1. Check the DataMan **Release Notes** for a full list of system requirements.
2. Download the latest version of the DataMan Setup Tool from [support.cognex.com/downloads/dataman/software-firmware](https://support.cognex.com/downloads/dataman/software-firmware) and follow the on-screen steps.
3. Connect the 280 series reader to your PC.
4. Launch the DataMan Setup Tool and click **Refresh**. Detected devices appear under **COM ports** or **Network devices**, or both.
5. Select a reader from the list and click **Connect**.

## Trigger Types

The DataMan 280 readers support the following trigger modes:

- **Single** (external trigger): Acquires a single image and attempts to decode any symbol it contains, or more than one symbol in cases where multicode is enabled. The reader relies on an external trigger source.
- **Presentation**: Scans, decodes and reports a single code in the field of view. The reader relies on an internal timing mechanism to acquire images.
- **Manual**: Begins acquiring images when you press the trigger button on the reader, and continues acquiring images until a symbol is found and decoded or you release the button.
- **Burst** (external trigger): Performs multiple image acquisitions based on an external trigger and decodes any symbol appearing in a single image or within a sequence of images, or multiple symbols in a single image or within a sequence of images when multicode is enabled. You can control the number of images within each burst and the interval between image acquisitions.
- **Continuous** (external trigger): Begins acquiring images based on a single external trigger and continues to acquire and decode images until a symbol is found and decoded, or until multiple images containing as many codes as specified in multicode mode are located, or until the trigger is released. You can configure your reader to acquire images based on the start and stop signal from separate digital IO pulses.

## External Triggers

If you are using external triggering, you can use any of the following methods to trigger your reader.

- Press the trigger button on the reader.



- Send a pulse on the I/O cable.
  - Trigger +
  - Trigger -
- Send a trigger command over any serial connection.
- Press **CTRL+T** on the keyboard while the DataMan Setup Tool has the input focus.
- Click the **Trigger** button in the DataMan Setup Tool or in the DataMan WebUI.

**Note:** You can also initiate external triggering through industrial protocols from a programmable logic controller.

## Training the Reader


Training your reader with the expected symbology can make the time required to decode successive symbols more consistent. In addition, training may help increase decode yield.

To train your reader, place a code in front of the reader and do one of the following:

- Press and hold the trigger button for a minimum of three seconds.



- Click **Train Code** under **Actions** on the ribbon bar.



You can use training in **Single**, **Burst**, **Continuous** or **Self** trigger modes.

**Note:** Only a single symbol of each symbology kind can be trained.

## Manual Training

You can manually train your reader which is helpful if you do not have a barcode nearby or you need to train during a running production.

- Click **Advanced** under the **Code Details**.
- In the **Training** tab, you can manually train a code by entering the attributes.
- Check the **Is Valid** checkbox.

| Training                      |                                     |
|-------------------------------|-------------------------------------|
| Disable Untrained Symbologies | <input checked="" type="checkbox"/> |
| Incremental Training          | <input type="checkbox"/>            |
| <b>Data Matrix</b>            |                                     |
| Training                      | Trained <span>Untrain Code</span>   |
| <b>Manual Code Training</b>   |                                     |
| Number of Rows                | 18                                  |
| Number of Columns             | 18                                  |
| Module Size (pixels)          | 22.8                                |
| Polarity                      | Dark On Light                       |
| Mirrored                      | <input type="checkbox"/>            |
| Is Valid                      | <input checked="" type="checkbox"/> |

## Training Feedback

The second LED from left on the reader glows green to indicate that it is currently trained. If the reader has no trained code, the LED is off.




Connect the reader to the DataMan Setup Tool to untrain it and allow it to recognize other enabled symbologies.

## Incremental Training for Multiple Symbologies

If you want to train the reader to recognize multiple symbologies, you can present a single image showing all the desired symbologies and perform the training procedure previously described.

If you cannot present a single image showing all the necessary symbologies, you can enable incremental training under **Training** on the **Advanced** tab of the **Code Details** pane:



With incremental training enabled, you can train the reader using multiple images showing the symbologies you expect to decode. The reader will train each new symbology while retaining the existing trained symbologies.


## DM282 LED Configurations

In the DataMan Setup Tool, you can control the primary illumination color of the LED lights of the reader in the **Optimize Image** tab. The default color is red.

The following colors are available:


- Red
- Green
- Blue
- White

To change the color of the LEDs, click on one of the color icons:



In the **Inputs / Outputs** pane, you can assign a LED color for the input/output events. For example, you can set a color for a successful read and set a different color for an unsuccessful read.

1. Check the **Custom Indicator LED** checkbox.



- Pick a custom LED color in the **Custom LED Color Selector** column.

The screenshot shows the 'Inputs / Outputs' configuration window. On the left is a sidebar with 'Application Steps' including 'Optimize Image', 'Code Details', 'Application Details', 'Format Data', 'Inputs / Outputs' (selected), 'Communications', and 'Save Settings'. The main area has tabs for 'Basic', 'Advanced', 'Inputs', 'Outputs', 'Output Delay', 'Pulse Encoder', 'Height Sensor', and 'Buffering and Transfer'. The 'Outputs' tab is active, displaying a table with columns for 'TRIG Button', 'TUNE Button', 'Inputs', 'Outputs', 'Output Delay', 'Pulse Encoder', 'Height Sensor', 'Custom LED', and 'Custom LED Color'. The 'Custom LED Color' column is highlighted with a red box, and a dropdown menu is open showing a list of color options: Green, Red, Red, Red, Red, Red, Red, Red. The 'Green' option is selected.

**Note:**

If you choose the same color for the primary illumination and for the custom inputs/outputs LED, a warning appears next to the custom color. In this case, you either have to choose a different primary illumination color, or choose a different custom LED color for the inputs/outputs events.



This is a close-up of the 'Custom LED Color' dropdown menu. The 'White' option is selected and highlighted with a red box. A warning icon (exclamation mark in a triangle) is visible next to the 'White' option, indicating a conflict with the primary illumination color.


# Industrial Protocols

The reader supports the following industrial protocols:

- EtherNet/IP™, EDS and PLC
- PROFINET (Class B)
- SLMP Protocol
- Modbus TCP
- CC-Link
- EtherCAT

**Note:** Only the DataMan 280 EtherCAT supports the EtherCAT protocol.

Select industrial protocol samples and tools you want to use when you install the DataMan Setup Tool.



After enabling the selected industrial protocol, a reboot is required for the changes to take effect. Enable an industrial protocols on the reader with the following options:

- Enable the protocols on the **Communications** substep of the DataMan WebUI.
- Enable the protocols using the **Industrial Protocols** pane of the DataMan Setup Tool, under **Communications**.
- Scan the appropriate **Reader Configuration codes**. For more information, see *Reader Configuration Codes* available through the Windows **Start** menu, the DataMan Setup Tool **Help** menu, or DataMan documentation available on the [Cognex support site](#).
- Send the appropriate **DMCC** command. For more information, see *Command Reference* available through the Windows **Start** menu or the DataMan Setup Tool **Help** menu.

For more information on using the industrial protocols, see the *DataMan Industrial Protocols Manual* available through the Windows **Start** menu, the DataMan Setup Tool **Help** menu, or DataMan documentation available on the [Cognex support site](#).

# Specifications

The following sections list general specifications for the reader.

## DataMan 280 Series Reader

| Specification                    | DataMan 280<br>DataMan 280 EC                                                                                                                                                                                                                                                                                  | DataMan 282                                                                                                                 |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| Weight                           | 6.2 mm: 141 g<br>16 mm: 169 g<br>Right angle configuration adds 50 g                                                                                                                                                                                                                                           | HPIT: 290 g<br>Right angle configuration adds 50 g                                                                          |
| Power                            | 24 V DC +/- 10%, PoE (Power over Ethernet)                                                                                                                                                                                                                                                                     | 24 V DC $\pm$ 10%                                                                                                           |
| 24 V Supply                      | 24 V DC $\pm$ 10%<br>LPS or NEC class 2                                                                                                                                                                                                                                                                        |                                                                                                                             |
|                                  | Power consumption without USB device attached: <ul style="list-style-type: none"> <li>• Average <math>\leq</math> 5 W using High-Powered Light</li> <li>• Average <math>\leq</math> 6 W using High Frequency High-Powered Light</li> <li>• Peak <math>\leq</math> 1.6 A using internal illumination</li> </ul> | Power consumption: <ul style="list-style-type: none"> <li>• Average <math>\leq</math> 5 W</li> <li>• Peak 10.7 W</li> </ul> |
| Power over Ethernet Supply       | PoE Class 3 for DataMan 280<br>N/A for DataMan 280 EC                                                                                                                                                                                                                                                          | N/A                                                                                                                         |
| Operating Temperature            | 0-40°C (32-104°F)                                                                                                                                                                                                                                                                                              |                                                                                                                             |
| Storage Temperature              | -10-60°C (14-140°F)                                                                                                                                                                                                                                                                                            |                                                                                                                             |
| Humidity                         | <95% non-condensing                                                                                                                                                                                                                                                                                            |                                                                                                                             |
| Environmental                    | IP67                                                                                                                                                                                                                                                                                                           |                                                                                                                             |
|                                  | <b>Note:</b> IP67 rating applies only if all blind plugs and cables are attached properly, or the provided connector plug is installed. Also, make sure that the IP67-rated cover is installed properly.                                                                                                       |                                                                                                                             |
| Shock                            | IEC 60068-2-27 - 500 shocks in each polarity of each (X, Y, and Z) axis, 3000 shocks total, semi-sinusoidal, 11 g, 10 ms                                                                                                                                                                                       |                                                                                                                             |
| Shock (Shipping and Storage)     | ISTA-1A Standardized Testing - Packaged Products 150 lb or less                                                                                                                                                                                                                                                |                                                                                                                             |
| Vibration                        | IEC 60068-2-6: vibration test in each of the three main axis for 2 hours @ 10 Gs (10 to 500 Hz at 100m/s <sup>2</sup> / 15 mm)                                                                                                                                                                                 |                                                                                                                             |
| Vibration (Shipping and Storage) | FedEx Vibration Testing for packaged products 150 lbs or less                                                                                                                                                                                                                                                  |                                                                                                                             |
| RS-232                           | RxD, TxD according to TIA/EIA-232-F                                                                                                                                                                                                                                                                            |                                                                                                                             |

| Specification                    | DataMan 280<br>DataMan 280 EC                                                                                                                                                                                                                                            | DataMan 282 |
|----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|
| Codes                            | <b>1-D barcodes:</b> Codabar, Code 39, Code 128, Code 93, Code 25, Interleaved 2 of 5, Postal Codes, UPC/EAN/JAN, MSI<br><b>2-D barcodes:</b> Data Matrix (IDMax and IDQuick: ECC 0, 50, 80, 100, 140, and 200), QR Code, microQR, PDF 417, AztecCode, DotCode, MaxiCode |             |
| High-Speed Outputs<br>0, 1, 2, 3 | $I_{MAX}$ : 50 mA                                                                                                                                                                                                                                                        |             |
|                                  | $V_{OL}$ : $\leq \pm 3$ V @ 50 mA                                                                                                                                                                                                                                        |             |
| Inputs<br>0 (Trigger), 1, 2, 3   | $V_{IL}$ : $\leq \pm 6$ V                                                                                                                                                                                                                                                |             |
|                                  | $V_{IH}$ : $\geq \pm 12$ V                                                                                                                                                                                                                                               |             |
|                                  | $I_{TYP}$ : 4.2 mA @ 24 V                                                                                                                                                                                                                                                |             |
| Ethernet                         | 10/100/1000. Full duplex or half duplex.                                                                                                                                                                                                                                 |             |
| EtherCAT                         | N/A for DataMan 280 and 282<br>For details on the EtherCAT interface, see <a href="#">Connecting the EtherCAT Cable to the DataMan 280 EtherCAT Reader on page 62</a> .                                                                                                  |             |

## DataMan 280 Series Reader Image Sensor

| Specification                        | DataMan 280<br>DataMan 280 EC                                                                                                                                                                                     | DataMan 282                                                                                                 |
|--------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| Image Sensor                         | 1/3-inch CMOS, global shutter                                                                                                                                                                                     |                                                                                                             |
| Image Sensor Properties              | Diagonal size: 6.21 mm<br>Pixel size: 3.45 $\mu$ m (H) x 3.45 $\mu$ m (V)                                                                                                                                         | Diagonal size: 6.17 mm<br>Pixel size: 2.8 $\mu$ m (H) x 2.8 $\mu$ m (V)                                     |
| Image Resolution (pixels)            | 1440 x 1080 (1.6 MP)                                                                                                                                                                                              | 1920 x 1080 pixels (2 MP)                                                                                   |
| Electronic Shutter Speed             | Minimum exposure: 43 $\mu$ s<br>Maximum exposure: 200 ms (with external illumination)                                                                                                                             | Minimum exposure: 30 $\mu$ s<br>Maximum exposure: 200 ms (with external illumination)                       |
| Image Acquisition at Full Resolution | Maximum: 45 Hz                                                                                                                                                                                                    |                                                                                                             |
| Lens Type                            | <ul style="list-style-type: none"> <li>6.2 mm (3 pos or LLM) with IR blocking filter</li> <li>16 mm (manual or LLM) with IR blocking filter</li> <li>6.2 mm UV, 6.2 mm</li> <li>16 mm IR, C-Mount acc.</li> </ul> | <ul style="list-style-type: none"> <li>8 mm</li> <li>12 mm</li> <li>16 mm High Speed Liquid Lens</li> </ul> |

## LED Wavelengths

The following table shows LED types and the related dominant wavelengths.


| LED | $\lambda$ [nm] |
|-----|----------------|
| RED | 617            |

|          |                           |
|----------|---------------------------|
| RED HPIL | 617                       |
| BLUE     | 470                       |
| WHITE    | 6500K (Color temperature) |
| IR       | 850                       |
| IR HPIL  | 850                       |
| UV       | 365                       |

# Acquisition Trigger Input

The reader features one acquisition trigger input, which is optically isolated. You can configure the acquisition trigger input to trigger from an NPN (current sinking) or PNP (current sourcing) device.


- To trigger from an NPN type photoelectric sensor or PLC output, connect COMMON IN to +24 VDC and connect IN 0 to the output of the photoelectric sensor. When the output turns ON, it pulls TRIGGER down to 0 VDC, turning the opto-coupler ON.
- To trigger from a PNP photoelectric sensor or PLC output, connect IN 0 to the output of the photoelectric sensor and connect COMMON IN to 0 VDC. When the output turns ON, it pulls TRIGGER up to +24 VDC, turning the opto-coupler ON.




# High-Speed Outputs

| Specification | Description                                                                                                                                                                                                                          |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Voltages      | $V_{MAX}$ : 26 VDC through external load<br>$V_{OL}$ : $\leq \pm 3\text{ V @ }50\text{ mA}$                                                                                                                                          |
| Current       | $I_{MAX}$ : 50 mA maximum sink or source current<br>Each line is protected against over-current, short circuits and transients from switching inductive loads.<br>High current inductive loads require an external protection diode. |

For NPN lines, the external load should be connected between the output and the positive supply voltage (< 26 VDC). The output pulls down to less than 3 VDC when ON, which causes current to flow through the load. When the output is OFF, no current flows through the load.




For PNP lines, the external load should be connected between the output and the negative supply voltage (0 VDC). When connected to a 24 VDC power supply, the output pulls up greater than 21 VDC when ON, and current flows through the load. When the output is OFF, no current flows through the load.




## High Speed Output Wiring


To connect to an NPN-compatible PLC input, connect one of the reader's high-speed outputs directly to the PLC input. When enabled, the output pulls the PLC input down to less than 3 VDC.



To connect to a PNP-compatible PLC input, connect one of the reader's high-speed outputs directly to the PLC input. When enabled, the output pulls the PLC input up to greater than 21 VDC.




To connect the high-speed outputs to a relay, LED or similar load, connect the negative side of the load to the output and the positive side to +24VDC. When the output switches on, the negative side of the load is pulled down to less than 3 VDC, and 21 VDC appears across the load. Use a protection diode for a large inductive load, with the anode connected to the output and the cathode connected to +24 VDC.



## Ethernet Cable

The Ethernet cable provides Ethernet connectivity to the reader. The Ethernet cable is used to connect the reader to other network devices.



**CAUTION:** The Ethernet cable shield has to be grounded at the far end. If the far end device is not grounded, add a ground wire in compliance with local electrical codes. The cable is typically plugged into a switch or router, which has to have a grounded Ethernet connector. Use a digital voltmeter to validate the grounding.


**Note:**

- Cables are sold separately.
- The wiring for this cable follows standard industrial Ethernet M12 specifications. It differs from the 568B standard.

# EtherCAT Adapter Cable

The EtherCAT adapter cable breaks out the EtherCAT input and output ports of the DataMan 280 EtherCAT reader to individual connectors:

- The P1 EtherCAT output is an M12 D-coded female connector that provides access to the EtherCAT output port of the reader.
- The P2 EtherCAT input is an M12 D-coded female connector that provides access to the EtherCAT input port of the reader.
- The P3 adapter input is an M12 X-coded male connector that connects to the EtherCAT connector on the reader.




| P3 Adapter Input Pin Number | Wire Color   | Signal | P1 EtherCAT Output Pin Number |
|-----------------------------|--------------|--------|-------------------------------|
| 1                           | White/Orange | RX1+   | 2                             |
| 2                           | Orange       | RX1-   | 4                             |
| 3                           | White/Green  | TX1+   | 1                             |
| 4                           | Green        | TX1-   | 3                             |
| P3 Adapter Input Pin Number | Wire Color   | Signal | P2 EtherCAT Input Pin Number  |
| 5                           | Blue         | RX2+   | 1                             |
| 6                           | White/Blue   | RX2-   | 3                             |
| 7                           | White/Brown  | TX2+   | 4                             |
| 8                           | Brown        | TX2-   | 2                             |

# CCB-M12x12Fy-xx

The Power and I/O Breakout cable provides access to trigger and high-speed outputs. For RS-232, use the Power Supply return path for ground.

The figure on the left shows the plug on the device.



| Pin# | Signal Names | Wire Color |
|------|--------------|------------|
| 1    | Out 2/In 2   | White      |
| 2    | TxD          | Green      |
| 3    | RxD          | Pink       |
| 4    | Out 3/In 3   | Yellow     |
| 5    | In 1         | Grey       |
| 6    | Common In    | Black      |
| 7    | +24 VDC      | Brown      |
| 8    | GND          | Blue       |
| 9    | Common Out   | Purple     |
| 10   | In 0         | Red        |
| 11   | Out 0        | Grey/Pink  |
| 12   | Out 1        | Red/Blue   |


**Note:**

- Cables are sold separately.
- Perform wiring or adjustments to I/O devices when the reader is not receiving power.
- You can cut exposed wires short or trim wire ends. You also can tie the wires back if you use a tie made of non-conductive material. Keep bare wires separated from the +24 V DC wire.

# CCBL-05-01

The Power and I/O Breakout cable provides access to trigger and high-speed outputs. For RS-232, use the Power Supply return path for ground.

The figure on the left shows the plug on the device.



| Pin# | Signal Names | Wire Color   |
|------|--------------|--------------|
| 1    | Out 2/In 2   | Yellow       |
| 2    | TxD          | White/Yellow |
| 3    | RxD          | Brown        |
| 4    | Out 3/In 3   | White/Brown  |
| 5    | In 1         | Violet       |
| 6    | Common In    | White/Violet |
| 7    | +24 VDC      | Red          |
| 8    | GND          | Black        |
| 9    | Common Out   | Green        |
| 10   | In 0         | Orange       |
| 11   | Out 0        | Blue         |
| 12   | Out 1        | Grey         |


**Note:**

- Cables are sold separately.
- Perform wiring or adjustments to I/O devices when the reader is not receiving power.
- You can cut exposed wires short or trim wire ends. You also can tie the wires back if you use a tie made of non-conductive material. Keep bare wires separated from the +24 V DC wire.

# CCB-PWRIO-05

The Power and I/O Breakout cable provides access to trigger and high-speed outputs. For RS-232, use the Power Supply return path for ground.

The figure on the left shows the plug on the device.



| Pin# | Signal Names | Wire Color   |
|------|--------------|--------------|
| 1    | Out 2/In 2   | Yellow       |
| 2    | TxD          | White/Yellow |
| 3    | RxD          | Brown        |
| 4    | Out 3/In 3   | White/Brown  |
| 5    | In 1         | Violet       |
| 6    | Common In    | White/Violet |
| 7    | +24 VDC      | Red          |
| 8    | GND          | Black        |
| 9    | Common Out   | Green        |
| 10   | In 0         | Orange       |
| 11   | Out 0        | Blue         |
| 12   | Out 1        | Grey         |

**Note:**

- Cables are sold separately.
- Perform wiring or adjustments to I/O devices when the reader is not receiving power.
- You can cut exposed wires short or trim wire ends. You also can tie the wires back if you use a tie made of non-conductive material. Keep bare wires separated from the +24 V DC wire.

# Cleaning and Maintenance

## Clean the Housing

To clean the outside of the reader housing, use a small amount of mild detergent cleaner or isopropyl alcohol on a cleaning cloth. Do not pour the cleaner on the reader housing.

---

 **CAUTION:** Do not attempt to clean any DataMan product with harsh or corrosive solvents, including lye, methyl ethyl ketone (MEK) or gasoline.

---

## Clean the Reader Image Sensor Window

To remove dust from the outside of the image sensor window, use a pressurized air duster. The air must be free of oil, moisture or other contaminants that could remain on the glass and possibly degrade the image. Do not touch the glass window. If oil or smudges remain, use a cotton bud and alcohol (ethyl, methyl, or isopropyl) to clean the window. Do not pour the alcohol on the window.

## Clean the Reader Lens Cover

To remove dust from the lens cover, use a pressurized air duster. The air must be free of oil, moisture or other contaminants that could remain on the lens cover. To clean the plastic window of the lens cover, use a small amount of isopropyl alcohol on a cleaning cloth. Do not scratch the plastic window. Do not pour the alcohol on the plastic window.

# Regulations and Conformity

**Note:** For the most current CE and UKCA declaration and regulatory conformity information, see the Cognex support site: [cognex.com/support](http://cognex.com/support).

DataMan 280 readers have Regulatory Model numbers 50208, 50210, 50215, 50216, 50211 and 50213 and meet or exceed the requirements of all applicable standards organizations for safe operation. However, as with any electrical equipment, the best way to ensure safe operation is to operate them according to the agency guidelines that follow. Please read these guidelines carefully before using your device.

| Safety and Regulatory                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Manufacturer                                                                                 | Cognex Corporation<br>One Vision Drive<br>Natick, MA 01760 USA                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| CE                                                                                           | DataMan 280 1.6 MP: Regulatory Model 50208<br>DataMan 280 1.6 MP L-shaped: Regulatory Model 50210<br>DataMan 280 2 MP: Regulatory Model 50215<br>DataMan 280 2 MP L-shaped: Regulatory Model 50216<br>DataMan 280 EC Straight: Regulatory Model 50211<br>DataMan 280 EC L-Shaped: Regulatory Model 50213<br>This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take immediate measures. This equipment complies with the essential requirements of the EU Directive 2014/30/EU. Declarations are available from your local representative.                                                                              |
| EU RoHS                                                                                      | Compliant to the most recent applicable directive.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| FCC                                                                                          | FCC Part 15, Class A<br>This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. |
| Korea<br> | This device is certified for office use only and if used at home, there can be frequency interference problems.<br>A급 기기(업무용 방송통신기자재): 이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.<br>DataMan 280 1.6 MP: R-R-CGX-50208<br>DataMan 280 1.6 MP L-shaped: R-R-CGX-50210<br>DataMan 280 2 MP: R-R-CGX-50215<br>DataMan 280 2 MP L-shaped: R-R-CGX-50216<br>DataMan 280 EC Straight: R-R-CGX-50211<br>DataMan 280 EC L-Shaped: R-R-CGX-50213                                                                                                                                                                                                                                  |

| Safety and Regulatory |                                                                                                                                                                                                                                                                                                                                             |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| TÜV                   | DataMan 280 1.6 MP: Regulatory Model 50208<br>DataMan 280 1.6 MP L-shaped: Regulatory Model 50210<br>DataMan 280 2 MP: Regulatory Model 50215<br>DataMan 280 2 MP L-shaped: Regulatory Model 50216<br>DataMan 280 EC Straight: Regulatory Model 50211<br>DataMan 280 EC L-Shaped: Regulatory Model 50213                                    |
|                       | NRTL: TÜV SÜD SCC/NRTL OSHA Scheme for UL/CAN 61010-1.                                                                                                                                                                                                                                                                                      |
|                       | CB report available upon request. TÜV SÜD, IEC/EN 61010-1.                                                                                                                                                                                                                                                                                  |
| UK<br>CA              | DataMan 280 1.6 MP: Regulatory Model 50208<br>DataMan 280 2 MP L-shaped: Regulatory Model 50216<br>DataMan 280 EC Straight: Regulatory Model 50211<br>DataMan 280 EC L-Shaped: Regulatory Model 50213                                                                                                                                       |
|                       | This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take immediate measures. This equipment complies with the essential requirements of the Electromagnetic Compatibility Regulations 2016. Declarations are available from your local representative. |

## 中国大陆RoHS (Information for China RoHS Compliance)

根据中国大陆《电子信息产品污染控制管理办法》(也称为中国大陆RoHS), 以下部份列出了本产品中可能包含的有毒有害物质或元素的名称和含量。



|                           | Hazardous Substances 有害物质 |                   |                      |                                            |                                           |                                                   |
|---------------------------|---------------------------|-------------------|----------------------|--------------------------------------------|-------------------------------------------|---------------------------------------------------|
| Part Name<br>部件名称         | Lead (Pb)<br>铅            | Mercury (Hg)<br>汞 | Cadmium<br>(Cd)<br>镉 | Hexavalent<br>Chromium<br>(Cr (VI))<br>六价铬 | Polybrominated<br>biphenyls (PBB)<br>多溴联苯 | Polybrominated<br>diphenyl ethers (PBDE)<br>多溴二苯醚 |
| Regulatory<br>Model 50215 | X                         | O                 | O                    | O                                          | O                                         | O                                                 |
| Regulatory<br>Model 50216 |                           |                   |                      |                                            |                                           |                                                   |
| Regulatory<br>Model 50211 |                           |                   |                      |                                            |                                           |                                                   |
| Regulatory<br>Model 50213 |                           |                   |                      |                                            |                                           |                                                   |

This table is prepared in accordance with the provisions of SJ/T 11364.

这个标签是根据 SJ / T 11364 的规定准备的。

O: Indicates that said hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB / T26572 - 2011.

表示本部件所有均质材料中含有的有害物质低于 GB / T26572 - 2011 的限量要求。

X: Indicates that said hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB / T26572 - 2011.

表示用于本部件的至少一种均质材料中所含的危害物质超过 GB / T26572 - 2011 的限制要求。

## For European Community Users

Cognex complies with Directive 2012/19/EU OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 4 July 2012 on waste electrical and electronic equipment (WEEE).

This product has required the extraction and use of natural resources for its production. It may contain hazardous substances that could impact health and the environment, if not properly disposed.

In order to avoid the dissemination of those substances in our environment and to diminish the pressure on the natural resources, we encourage you to use the appropriate take-back systems for product disposal. Those systems will reuse or recycle most of the materials of the product you are disposing in a sound way.



The crossed out wheeled bin symbol informs you that the product should not be disposed of along with municipal waste and invites you to use the appropriate separate take-back systems for product disposal.

If you need more information on the collection, reuse, and recycling systems, please contact your local or regional waste administration.

You may also contact your supplier for more information on the environmental performance of this product.

